

Garmin International, Inc.
1200 E. 151st Street
Olathe, Kansas 66062 U.S.A.

FAA APPROVED

AIRPLANE FLIGHT MANUAL SUPPLEMENT
or
SUPPLEMENTAL AIRPLANE FLIGHT MANUAL
for the
Garmin GTN 625, 635, 650, 725, or 750 GPS/SBAS Navigation System
as installed in

Make and Model Airplane

Registration Number: _____ Serial Number: _____

This document serves as an Airplane Flight Manual Supplement or as a Supplemental Airplane Flight Manual when the aircraft is equipped in accordance with Supplemental Type Certificate SA02019SE-D for the installation and operation of the Garmin GTN 625, 635, 650, 725, or 750 GPS/SBAS Navigation System. This document must be incorporated into the FAA Approved Airplane Flight Manual or provided as an FAA Approved Supplemental Airplane Flight Manual.

The information contained herein supplements the information in the FAA Approved Airplane Flight Manual. For limitations, procedures, loading and performance information not contained in this document, refer to the FAA Approved Airplane Flight Manual, markings, or placards.

FAA Approved by: Erik Frisk

Erik Frisk
ODA STC Unit Administrator
Garmin International, Inc.
ODA-240087-CE

Date: 03-JAN-2020

LOG OF REVISIONS				
Revision Number	Page		Description	FAA Approved
	Date	Number		
1	03/18/11	All	Complete Supplement	<i>Robert Grove</i> ODA STC Unit Administrator Garmin International, Inc. ODA-240087-CE Date: <u>03/18/2011</u>
2	12/18/12		See Revision 3	<u>Michael Warren</u> ODA STC Unit Administrator Garmin International, Inc. ODA-240087-CE Date: <u>12/18/2012</u>
3	03/26/13		See Revision 4	<u>Michael Warren</u> ODA STC Unit Administrator Garmin International, Inc. ODA-240087-CE Date: <u>04/12/2013</u>
4	11/24/14	7 11 16 18 20 20 & 21 26 27 32 34	<u>Table 1</u> <ul style="list-style-type: none">Added new functions <u>Section 1.4</u> <ul style="list-style-type: none">New section <u>Section 2.7</u> <ul style="list-style-type: none">Modified limitation <u>Section 2.12</u> <ul style="list-style-type: none">Added wire obstacles <u>Section 2.21</u> <ul style="list-style-type: none">Modified limitation <u>Section 2.22 & 2.23</u> <ul style="list-style-type: none">Added limitations <u>Section 3.2.10</u> <ul style="list-style-type: none">Added Flight Stream 210 to procedure <u>Section 4.1</u> <ul style="list-style-type: none">Removed telephone audio deactivation procedure <u>Section 7.5</u> <ul style="list-style-type: none">Added wire obstacles <u>Section 7.9</u> <ul style="list-style-type: none">Added Flight Stream 210 	<u>Michael Warren</u> ODA STC Unit Administrator Garmin International, Inc. ODA-240087-CE Date : <u>11/25/2014</u>

LOG OF REVISIONS				
Revision Number	Page		Description	FAA Approved
	Date	Number		
5	02/25/16	34	<u>Section 7.10</u> • Added wire obstacles	<i>Michael Warren</i> ODA STC Unit Administrator Garmin International, Inc. ODA-240087-CE Date : <u>02/25/2016</u>
		37	<u>Section 7.17</u> • Added section	
		All	<u>All Sections</u> • Reformatted and updated sections to better coincide with the VFR AFMS. <u>Section 2</u> • Added RF leg description and limitations • Added QFE limitations • Added Autopilot limitations • Added polar operation limitation • Added text regarding new data units in the GTN • Added Fuel Range Ring description and limitations • Added Flight Stream 210 limitation <u>Section 4</u> • Added autopilot capability assessment regarding RF legs • Updated installer descriptions of configuration checkboxes • Added Search and Rescue autopilot note • Added RNP 1.0 installation options <u>Section 7</u> • Added GMA 35c information • Removed references to GDL 88 and replaced with generic ADS-B	

LOG OF REVISIONS				
Revision Number	Page		Description	FAA Approved
	Date	Number		
		32	<u>Section 7.9</u> • Added Flight Stream 510	
		33	<u>Section 7.10</u> • Reworded	
		34	<u>Table 4</u> • Added PTC	
		38	<u>Section 7.19</u> • Flight Stream 510 content added	
		41-42	<u>Sections 7.25-7.26</u> • New sections	
7	10/17/17	6-8	<u>Sections 1.5</u> • New definitions	<u>Erik Frisk</u> ODA STC Unit Administrator Garmin International, Inc. ODA-240087-CE Date : <u>11-01-2017</u>
		9	<u>Section 2.1</u> • Updated CRG Revisions	
		10	<u>Section 2.4</u> • Updated FDE compliance text	
		12	<u>Section 2.6</u> • Updated software grid	
		13	<u>Section 2.10</u> • Renamed section	
		19-20	<u>Section 2.32-2.33</u> • New sections	
		22	<u>Section 3.2.1-2</u> • Updated text	
		32	<u>Section 7.27</u> • Updated PG Revisions	
		45	<u>Section 7.27</u> • New section	
8	08/08/18	6-9	<u>Section 1.5</u> New abbreviation added	<u>Erik Frisk</u> ODA STC Unit Administrator Garmin International, Inc. ODA-240087-CE Date : <u>08-08-2018</u>
		10	<u>Section 2.1</u> • Updated CRG Revisions	

LOG OF REVISIONS				
Revision Number	Page		Description	FAA Approved
	Date	Number		
		13	<u>Section 2.6</u> • Updated software grid	
		14	<u>Section 2.9</u> • Changed approach requirements for VOR or ADF approaches	
		15	<u>Section 2.11</u> • All text updated	
		16	<u>Section 2.14</u> • Title change <u>Section 2.15</u> • User airport text added	
		19	<u>Section 2.30</u> • Updated charts text	
		20	<u>Section 2.32</u> • Added new text	
		25	<u>Section 3.2.11</u> • New text <u>Section 3.2.14</u> • New section added	
		26	<u>Section 3.2.15</u> • New section added	
		30	<u>Section 4.6</u> • New section added	
		31	<u>Section 4.9</u> • New section added	
		33	<u>Section 7.1</u> • Updated PG versions	
		34	<u>Section 7.5</u> • Additional options	
		40	<u>Section 7.14</u> • Text updated	
		44	<u>Section 7.23</u> • Updated text add bullet	
		46-48	<u>Section 7.28 – 7.31</u> • New sections added	

LOG OF REVISIONS				
Revision Number	Page		Description	FAA Approved
	Date	Number		
9	01/03/20	12	<u>Section 2.5</u> • Added statement to clarify when CDI key is enabled.	See Page i
		13	<u>Section 2.6</u> • Updated applicable software.	
		33	<u>Section 7.3</u> • Added language to clarify when CDI auto-switching will occur	
		44	<u>Section 7.23</u> • Added Default FPA to list of crossfilled items	
		46	<u>Section 7.28</u> • Removed recommendation to manually sync FPA	

Table of Contents

SECTION	PAGE
Section 1. General	1
1.1 Garmin GTN Navigators	1
1.2 System Capabilities	3
1.3 Electronic Flight Bag	6
1.4 Electronic Checklists	6
1.5 Definitions	6
Section 2. LIMITATIONS	10
2.1 Cockpit Reference Guide	10
2.2 Kinds of Operation	10
2.3 Minimum Equipment	10
2.4 Flight Planning	11
2.5 System Use	12
2.6 Applicable System Software	13
2.7 MMC / SD Database Cards	13
2.8 Navigation Database	13
2.9 Ground Operations	14
2.10 Instrument Approaches	14
2.11 QFE Barometric Setting	15
2.12 RF Legs	15
2.13 Autopilot Coupling	15
2.14 Terrain Alerting Function (All Units)	16
2.15 TAWS Function (Optional)	16
2.16 Polar Operations	16
2.17 Datalink Weather Display (Optional)	17
2.18 Traffic Display (Optional)	17
2.19 StormScope® Display (Optional)	17
2.20 Flight Planner/Calculator Functions	18
2.21 Fuel Range Rings	18
2.22 Glove Use / Covered Fingers	18
2.23 Demo Mode	18
2.24 Active Weather Radar	18
2.25 Telephone Audio	19
2.26 Multi Crew Aircraft (GMA 35 Only)	19
2.27 Wire Obstacle Database	19
2.28 Portable Electronic Devices	19
2.29 Database Updates	19
2.30 Charts Database (Dual GTN7XX and TXi GDU)	19
2.31 Automatic Speech Recognition	20
2.32 OBS Mode	20
2.33 Advisory Visual Approaches	20
Section 3. EMERGENCY PROCEDURES	21
3.1 Emergency Procedures	21
3.2 Abnormal Procedures	22

Section 4. NORMAL PROCEDURES	27
4.1 Unit Power On	27
4.2 Before Takeoff	27
4.3 HSI and EHSI Operation	28
4.4 Autopilot Operation	28
4.5 Coupling the Autopilot during approaches	29
4.6 Coupling the Autopilot for Descent VNAV	30
4.7 Coupling the Autopilot during Search and Rescue Operations	30
4.8 Database Conflict Resolution	31
4.9 Cold Weather Compensation	31
Section 5. PERFORMANCE	32
Section 6. WEIGHT AND BALANCE	32
Section 7. SYSTEM DESCRIPTIONS	33
7.1 Pilot's Guide	33
7.2 Leg Sequencing	33
7.3 Auto ILS CDI Capture	33
7.4 Activate GPS Missed Approach	33
7.5 Terrain Proximity, Terrain Alerting, and TAWS	34
7.6 GMA 35/35c Audio Panel (Optional)	35
7.7 Traffic System (Optional)	35
7.8 StormScope® (Optional)	36
7.9 Power	36
7.10 Databases and Flight Plan Waypoints/Procedures	37
7.11 External Switches	38
7.12 Airspace Depiction and Alerts	38
7.13 Garmin ADS-B Traffic System Interface (Optional)	39
7.14 GWX 70/75 Weather Radar (Optional)	40
7.15 Charts (Optional)	40
7.16 Transponder Control (Optional)	40
7.17 Telephone Audio (Optional)	40
7.18 Depiction of Obstacles and Wires	41
7.19 Flight Stream 210/510 (Optional)	42
7.20 Map Page	43
7.21 User Defined Waypoints	43
7.22 Times and Distances	43
7.23 GTN-GTN Crossfill	44
7.24 Direct-To Operations	44
7.25 Automatic Speech Recognition (ASR)	45
7.26 European Visual Reporting Points	46
7.27 Advisory Visual Approaches	46
7.28 Descent VNAV	46
7.29 Along Track Waypoints	47
7.30 Database Provided Altitudes	48
7.31 Database Sync with G500/600 or G500/600/700TXi GDUs	48

Section 1. General

1.1 Garmin GTN Navigators

The Garmin GTN navigation system is a GPS system with a Satellite Based Augmentation System (SBAS), comprised of one or more Garmin TSO-C146c GTN 625, 635, 650, 725, or 750 navigator(s) and one or more Garmin approved GPS/SBAS antenna(s). The GTN navigation system is installed in accordance with AC 20-138A.

	GTN 625	GTN 635	GTN 650	GTN 725	GTN 750
GPS SBAS Navigation: <ul style="list-style-type: none"> Oceanic, enroute, terminal, and non-precision approach guidance Precision approach guidance (LP, LPV) 	X	X	X	X	X
VHF Com Radio, 118.00 to 136.990, MHz, 8.33 or 25 kHz increments		X	X		X
VHF Nav Radio, 108.00 to 117.95 MHz, 50 kHz increments			X		X
LOC and Glideslope non-precision and precision approach guidance for Cat 1 minimums, 328.6 to 335.4 MHz tuning range			X		X
Moving map including topographic, terrain, aviation, and geopolitical data	X	X	X	X	X
Display of datalink weather products, SiriusXM, FIS-B, Connex (all optional)	X	X	X	X	X
Control and display of airborne weather radar (optional)				X	X
Display of terminal procedures data (optional)				X	X
Display of traffic data, including ADS-B (optional)	X	X	X	X	X
Display of StormScope® data (optional)	X	X	X	X	X
Display of marker beacon annunciators (optional)	X*	X*	X*	X	X
Remote audio panel control (optional)				X	X
Remote transponder control (optional)	X	X	X	X	X
Remote audio entertainment datalink control (optional)	X	X	X	X	X
TSO-C151c Class B TAWS (optional)	X	X	X	X	X
Supplemental calculators and timers	X	X	X	X	X
Control of GSR 56 Iridium Satellite Phone and SMS Text	X	X	X	X	X
Control of Flight Stream 210 (optional)	X	X	X	X	X
Control of Flight Stream 510 (optional)	X	X	X	X	X

* Display of marker beacon annunciations on the GTN 6XX is only possible when installed with a Garmin GMA 350 audio panel.

Table 1 – GTN Functions

The GPS navigation functions and optional VHF communication and navigation radio functions are operated by dedicated hard keys, a dual concentric rotary knob, or the touchscreen.



Figure 1 - GTN 750 Control and Display Layout




Figure 2 - GTN 635/650 Control and Display Layout

1.2 System Capabilities

This Flight Manual Supplement documents the installed capabilities of the GTN specific to the aircraft for which this manual is created.

NOTE

In sections which contain a square checkbox (☐) the installer will have placed an “X” in the boxes next to the capabilities applicable to the installation.

The GTN system and associated navigation interface in this aircraft have the following capabilities, in addition to the core multifunction display capability:

- ☐ VHF Communication Radio
- ☐ Primary VHF Navigation
- ☐ Primary GPS Navigation (Enroute) and Approach Capability (LP/LNAV) – See below
- ☐ Primary GPS Approach Capability with Vertical Guidance (LNAV/VNAV, LPV) – See below
- ☐ TSO-C151c Terrain Awareness and Warning System – See section 2.15
- ☐ Enroute Baro-VNAV

GPS/SBAS TSO-C146c Class 3 Operation

The GTN complies with AC 20-138A and has airworthiness approval for navigation using GPS and SBAS (within the coverage of a Satellite Based Augmentation System complying with ICAO Annex 10) for IFR enroute, terminal area, and non-precision approach operations (including those approaches titled “GPS”, “or GPS”, and “RNAV (GPS)” approaches). The Garmin GNSS navigation system is composed of the GTN navigator and antenna, and is approved for approach procedures with vertical guidance including “LPV” and “LNAV/VNAV” and without vertical guidance including “LP” and “LNAV”.

The Garmin GNSS navigation system complies with the equipment requirements of AC 90-105 and meets the equipment performance and functional requirements to conduct RNP terminal departure and arrival procedures and RNP approach procedures including procedures with RF legs subject to the limitations herein. Part 91 subpart K, 121, 125, 129, and 135 operators require operational approval from the FAA.

The Garmin GNSS navigation system complies with the equipment requirements of AC 90-100A for RNAV 2 and RNAV 1 operations. In accordance with AC 90-100A, Part 91 operators (except subpart K) following the aircraft and training guidance in AC 90-100A are authorized to fly RNAV 2 and RNAV 1 procedures. Part 91 subpart K, 121, 125, 129, and 135 operators require operational approval from the FAA.

Applicable to dual installations consisting of two Garmin

GNSS units: The Garmin GNSS navigation system has been found to comply with the requirements for GPS Class II oceanic and remote navigation (RNP-10) without time limitations in accordance with AC 20-138A and FAA Order 8400.12A. The Garmin GNSS navigation system can be used without reliance on other long-range navigation systems. This does not constitute an operational approval.

The Garmin GNSS navigation system has been found to comply with the navigation requirements for GPS Class II oceanic and remote navigation (RNP-4) in accordance with AC 20-138A and FAA Order 8400.33. The Garmin GNSS navigation system can be used without reliance on other long-range navigation systems. Additional equipment may be required to obtain operational approval to utilize RNP-4 performance. This does not constitute an operational approval.

The Garmin GNSS navigation system complies with the accuracy, integrity, and continuity of function, and contains the minimum system functions required for P-RNAV operations in accordance with JAA Administrative & Guidance Material Section One: General Part 3: Temporary Guidance Leaflets, Leaflet No 10 (JAA TGL-10 Rev 1). The GNSS navigation system consists of one or more TSO-C146c Class 3 approved Garmin GTN Navigation Systems. The Garmin GNSS navigation system complies with the accuracy, integrity, and continuity of function, and contains the minimum system functions required for B-RNAV operations in accordance with EASA AMC 20-4. The Garmin GNSS navigation system complies with the equipment requirements for P-RNAV and B-RNAV/RNAV-5 operations in accordance with AC 90-96A CHG 1. This does not constitute an operational approval.

Garmin International holds an FAA Type 2 Letter of Acceptance (LOA) in accordance with AC 20-153 for database integrity, quality, and database management practices for the navigation database. Flight crew and operators can view the LOA status at FlyGarmin.com then select “Type 2 LOA Status.”

Navigation information is referenced to the WGS-84 reference system.

Note that for some types of aircraft operation and for operation in non-U.S. airspace, separate operational approval(s) may be required in addition to equipment installation and airworthiness approval.

Advanced RNP Capabilities

The GTN includes 3 out of 6 of the features required for operations in airspace requiring Advance RNP based on the *ICAO document 9613 Performance Based Navigation (PBN) Manual, fourth edition, 2013* and is therefore not approved for Advanced RNP operations. The following table describes the six Advanced RNP capabilities and the GTN capabilities.

Advanced RNP Feature	GTN Capability
RF legs	Available if enabled for installation. See Section 2.12 for limitations.
Parallel offsets	Available.
Scalable RNP	GTN provides CDI scalability in compliance with TSO-C146c. RNP scalability is not available.
RNAV holding	Available.
Fixed radius transitions	Not available in GTN.
Time of arrival control (TOAC)	Not available in GTN.

1.3 Electronic Flight Bag

The GTN 750/725 are operationally suitable as Class 3 Hardware, Type B Software in accordance with AC 120-76B EFB electronic aeronautical information when using current FliteChart or ChartView data.

Use of the Flight Stream interface and data for the purpose of Electronic Flight Bag applications is not approved as part of this STC. Additional approval may be required to obtain operational approval for use of the Flight Stream and supplied data to supplement EFB systems.

1.4 Electronic Checklists

The GTN checklist functions are designed to DO-178B software design assurance level B and support a minor failure classification. While this STC does not grant operational approval for operators requiring such approval, there are no limitations precluding operators from obtaining their own operational approval for the checklist function.

1.5 Definitions

The following terminology is used within this document:

ADF:	Automatic Direction Finder
ADS-B:	Automatic Dependent Surveillance Broadcast
AEG:	Aircraft Evaluation Group (FAA)
APR:	Approach
ASR:	Automated Speech Recognition
ATK:	<u>A</u> long <u>T</u> rac <u>K</u>
CDI:	Course Deviation Indicator
DME:	Distance Measuring Equipment
ECAC:	European Civil Aviation Conference
EFB:	Electronic Flight Bag
EGNOS:	European Geostationary Navigation Overlay Service
EHSI:	Electronic Horizontal Situation Indicator
FPA:	Flight Path Angle
FIS-B:	Flight Information Services Broadcast
GAGAN:	GPS Aided GEO Augmented Navigation
GDU:	Garmin Display Unit
GMA:	Garmin Multimedia Audio
GNSS:	Global Navigation Satellite System
GPA:	Glidepath Angle
GPS:	Global Positioning System
GPSS:	GPS Roll Steering
GTN:	Garmin Touchscreen Navigator

HOT:	Hazardous Obstacle Transmission wires
HSI:	Horizontal Situation Indicator
IAP:	Instrument Approach Procedure
IFR:	Instrument Flight Rules
ILS:	Instrument Landing System
IMC:	Instrument Meteorological Conditions
LDA:	Localizer Directional Aid
LNAV:	Lateral Navigation
LNAV +V:	Lateral Navigation with advisory Vertical Guidance
L/VNAV:	Lateral/Vertical Navigation
LOC:	Localizer
LOC-BC:	Localizer Backcourse
LP:	Localizer Performance
LPV:	Localizer Performance with Vertical Guidance
LP +V:	Localizer Performance with Advisory Vertical Guidance
MLS:	Microwave Landing System
MMC:	Multi-Media Card
NOTAM:	Notice to Airmen
OBS:	Omni Bearing Selector
PED:	Portable Electronic Device
PTC:	Push-To-Command
RAIM:	Receiver Autonomous Integrity Monitoring
RF Leg:	Radius-To-Fix Leg of a Charted Instrument Procedure
RFL:	Reverse Frequency Lookup
RMT:	Remote
RNAV:	Area Navigation
RNP:	Required Navigational Performance
SAR:	Search and Rescue
SBAS:	Satellite Based Augmentation System
SD:	Secure Digital
SDF:	Simplified Directional Facility
SUSP:	Suspend
TACAN:	Tactical Air Navigation System
TAS:	Traffic Awareness System
TAWS:	Terrain Awareness and Warning System
TCAS:	Traffic Collision Avoidance System
TCH:	Threshold Crossing Height
TFR:	Temporary Flight Restriction

TIS:	Traffic Information Service
VHF:	Very High Frequency
VFR:	Visual Flight Rules
VGSI:	Visual Glide-Slope Indicator
VLOC:	VOR/Localizer
VMC:	Visual Meteorological Conditions

VNAV: Vertical Navigation
VOR: VHF Omnidirectional Range
VRP: Visual Reporting Point
WAAS: Wide Area Augmentation System
WFDE: WAAS Fault Data Exclusion
XFR: Transfer

Section 2. LIMITATIONS

2.1 Cockpit Reference Guide

The Garmin GTN 6XX or GTN 7XX Cockpit Reference Guide, part number and revision listed below (or later revisions), *must* be immediately available to the flight crew whenever navigation is predicated on the use of the GTN.

- GTN 6XX Cockpit Reference Guide P/N 190-01004-04 Rev M
- GTN 7XX Cockpit Reference Guide P/N 190-01007-04 Rev L

2.2 Kinds of Operation

This AFM supplement does not grant approval for IFR operations to aircraft limited to VFR operations.

2.3 Minimum Equipment

The GTN must have the following system interfaces fully functional in order to be used for primary navigation during IFR operations:

Interfaced Equipment	Number installed	Number Required for IFR
External HSI/CDI/EHSI	1 or more	1
External GPS Annunciator	See Note 1	1

Table 2 – Required Equipment

Note 1: Certain installations require an external GPS annunciator panel. If installed, this annunciator must be fully functional to use the GTN GPS navigation for IFR operations.

Single engine piston aircraft under 6,000 lbs. maximum takeoff weight:

Required Equipment for IFR operations utilizing GPS navigation: Single GTN Navigator

All other aircraft:

Required Equipment for IFR operations utilizing GPS navigation: Single GTN Navigator plus a second source of GPS navigation or a separate source of VHF navigation. The separate source of VHF navigation must not be the primary GTN, but it may be a secondary GTN.

Operation in remote or oceanic operation requires two sources of GPS navigation.

2.4 Flight Planning

For flight planning purposes, in areas where SBAS coverage is not available, the flight crew must check RAIM availability. An acceptable means of compliance for FDE prediction programs is to use a certified service which meets the requirements of FAA AC 20-138 and FAA AC 90-105A for prediction.

The following table describes some of the available RAIM prediction programs.

Prediction Program	Internet address or program details	Coverage Area
Garmin RAIM Prediction Tool	https://fly.garmin.com/fly-garmin/support/raim/	Worldwide
Garmin WFDE Prediction program	PC-based program included in GTN trainer v3.00 – 6.30. Instructions provided via Garmin part number 190-00643-01	Worldwide
FAA Service Availability Prediction Tool	http://sapt.faa.gov	US Only
Flight Service Station	1-800-WXBRIEF https://www.1800wxbrief.com	US Only
AUGER GPS RAIM Prediction Tool	http://augur.ecacnav.com/augur/app/home	ECAC Airspace Only

This RAIM availability requirement is not necessary if SBAS coverage is confirmed to be available along the entire route of flight.

For flight planning purposes, for operations within the U.S. National Airspace System on RNP and RNAV procedures when SBAS signals are not available, the availability of GPS RAIM shall be confirmed for the intended route of flight. In the event of a predicted continuous loss of RAIM of more than five minutes for any part of the intended route of flight, the flight shall be delayed, canceled, or rerouted on a track where RAIM requirements can be met. The flight may also be re-planned using non-GPS based navigational capabilities.

For flight planning purposes for operations within European B-RNAV/RNAV-5 and P-RNAV airspace, if more than one satellite is scheduled to be out of service, then the availability of GPS RAIM shall be confirmed for the intended flight (route and time). In the event of a predicted continuous loss of RAIM of more than five minutes for any part of the intended flight, the flight shall be delayed, canceled, or rerouted on a track where RAIM requirements can be met.

Applicable to dual installations consisting of two Garmin GNSS units:

For flight planning purposes, for operations where the route requires Class II navigation the aircraft's operator or flight crew must use the Garmin WFDE Prediction program to demonstrate that there are no

outages on the specified route that would prevent the Garmin GNSS navigation system to provide GPS Class II navigation in oceanic and remote areas of operation that requires RNP-10 or RNP-4 capability. If the Garmin WFDE Prediction program indicates fault exclusion (FDE) will be unavailable for more than 34 minutes in accordance with FAA Order 8400.12A for RNP-10 requirements, or 25 minutes in accordance with FAA Order 8400.33 for RNP-4 requirements, then the operation must be rescheduled when FDE is available.

Both Garmin GPS navigation receivers must be operating and providing GPS navigation guidance for operations requiring RNP-4 performance.

North Atlantic (NAT) Minimum Navigational Performance Specifications (MNPS) Airspace operations per AC 91-49 and AC 120-33 require both GPS/SBAS receivers to be operating and receiving usable signals except for routes requiring only one Long Range Navigation sensor. Each display computes an independent navigation solution based on its internal GPS receiver.

Whenever possible, RNP and RNAV routes including Standard Instrument Departures (SIDs), Standard Terminal Arrival (STAR), and enroute RNAV “Q” and RNAV “T” routes should be loaded into the flight plan from the database in their entirety, rather than loading route waypoints from the database into the flight plan individually. Selecting and inserting individual named fixes from the database is permitted, provided all fixes along the published route to be flown are inserted. Manual entry of waypoints using latitude/longitude or place/bearing is prohibited.

It is not acceptable to flight plan a required alternate airport based on RNAV(GPS) LP/LPV or LNAV/VNAV approach minimums. The required alternate airport must be flight planned using an LNAV approach minimums or available ground-based approach aid.

Navigation information is referenced to the WGS-84 reference system, and should only be used where the Aeronautical Information Publication (including electronic data and aeronautical charts) conform to WGS-84 or equivalent.

2.5 System Use

In installations with two GTNs and an external GPS annunciator (See Table 2) the GTN connected to the external GPS annunciator must be used as the navigation source for all IFR operations.

The only approved sources of course guidance are on the external CDI, HSI, or EHSDI display. The moving map and CDI depiction on the GTN display are for situational awareness only and are not approved for course guidance.

If the GTN is interfaced with an external indicator capable of performing its own source selection, the GTN CDI Key will be disabled. The GTN will display “GPS” even when the external indicator has VLOC selected.

2.6 Applicable System Software

This AFMS/AFM is applicable to the software versions shown in Table 3.

The Main and GPS software versions are displayed on the start-up page immediately after power-on. All software versions displayed in Table 3 can be viewed on the System – System Status or Connex Setup pages.

Software Item	Software Version <i>(or later FAA Approved versions for this STC)</i>
Main SW Version	6.70
GPS SW Version	5.3
Com SW Version	2.30
Nav SW Version	6.03
Flight Stream 210	2.90
Flight Stream 510	2.6X

Table 3 - Software Versions

2.7 MMC / SD Database Cards

It is required that the SD database card or Flight Stream 510 (MMC) be present in the GTN at all times. The SD or MMC device must not be removed or inserted during flight or while the GTN is powered on.

NOTE

Removal of the SD or MMC device will result in certain features and databases not being available and may slow system performance.

2.8 Navigation Database

GPS/SBAS based IFR enroute, oceanic, and terminal navigation is prohibited unless the flight crew verifies and uses a valid, compatible, and current navigation database or verifies each waypoint for accuracy by reference to current approved data.

“GPS”, “or GPS”, and “RNAV (GPS)” instrument approaches using the Garmin navigation system are prohibited unless the flight crew verifies and uses the current navigation database. GPS based instrument approaches must be flown in accordance with an approved instrument approach procedure that is loaded from the navigation database.

Discrepancies that invalidate a procedure should be reported to Garmin International. The affected procedure is prohibited from being flown using data from the navigation database until a new navigation database is installed in the aircraft and verified that the discrepancy has been corrected. Navigation database discrepancies can be reported at FlyGarmin.com by selecting “Aviation Data Error Report.” Flight crew and operators can view navigation database alerts at FlyGarmin.com then select “NavData Alerts.”

If the navigation database cycle will change during flight, the flight crew must ensure the accuracy of navigation data, including suitability of navigation facilities used to define the routes and procedures for flight. If an amended chart affecting navigation data is published for the procedure, the database must not be used to conduct the procedure.

See Section 2.29 for limitations regarding database update procedures.

2.9 Ground Operations

Do not use SafeTaxi or ChartView functions as the basis for ground maneuvering. SafeTaxi and ChartView functions do not comply with the requirements of AC 20-159 and are not qualified to be used as an airport moving map display (AMMD). SafeTaxi and ChartView are to be used by the flight crew to orient themselves on the airport surface to improve flight crew situational awareness during ground operations.

2.10 Instrument Approaches

- a) Instrument approaches using GPS guidance may only be conducted when the GTN is operating in the approach mode. (LNAV, LNAV +V, L/VNAV, LPV, LP, or LP +V)
- b) When conducting instrument approaches referenced to true North, the NAV Angle on the System -Units page must be set to **True**.
- c) The navigation equipment required to join and fly an instrument approach procedure is indicated by the title of the procedure and notes on the IAP chart. Navigating the final approach segment (that segment from the final approach fix to the missed approach point) of an ILS, LOC, LOC-BC, LDA, SDF, MLS, VOR, TACAN approach, or any other type of approach not approved for GPS, is not authorized with GPS navigation guidance. GPS guidance can only be used for approach procedures with GPS or RNAV in the procedure title. When using the Garmin LOC/GS receivers to fly the final approach segment, LOC/GS navigation data must be selected and presented on the CDI of the pilot flying. When using the VOR or ADF receiver to fly the final approach segment of a VOR or NDB approach, GPS may be the selected navigation source so long as the VOR or NDB station is operational and the signal is monitored for final approach segment alignment.
- d) Advisory vertical guidance deviation is provided when the GTN annunciates LNAV + V or LP +V. Vertical guidance information displayed on the VDI in this mode is only an aid to help flight crews comply with altitude restrictions. When using advisory vertical guidance, the flight crew must use the primary barometric altimeter to ensure compliance with all altitude restrictions.
- e) Not all published Instrument Approach Procedures (IAP) are in the navigation database. Flight crews planning to fly an RNAV instrument approach must ensure that the navigation database contains the planned RNAV Instrument Approach Procedure and that approach procedure must be loaded from the navigation database into the GTN system flight plan by its name. Pilots are prohibited from flying any approach path that contains manually entered waypoints.

- f) IFR approaches are prohibited whenever any physical or visual obstruction (such as a throw-over yoke) restricts pilot view or access to the GTN and/or the CDI.

2.11 QFE Barometric Setting

When flying procedures requiring the use of QFE barometric settings, the pilot must ensure that the barometric setting for the source interfaced with the GTN is set to QFE as appropriate. GTN does not support barometric VNAV for QFE operations.

2.12 RF Legs

This STC does not grant operational approval for RF leg navigation for those operators requiring operational approval. Additional FAA approval may be required for those aircraft intending to use the GTN as a means to provide RNP 1 navigation in accordance with FAA Advisory Circular AC 90-105.

The following limitations apply to procedures with RF legs:

- Aircraft is limited to 180 KIAS while on the RF leg
- RF legs are limited to RNP 1 procedures. RNP AR and RNP <1 are not approved
- Primary navigation guidance on RF legs must be shown on an EHSI indicator with auto-slew capability turned ON
- GTN Moving Map, EHSI Map, or Distance to Next Waypoint information must be displayed to the pilot during the RF leg when flying without the aid of the autopilot or flight director.
- The active waypoint must be displayed in the pilot's primary field of view.

2.13 Autopilot Coupling

The flight crew may fly all phases of flight based on the navigation information presented to the flight crew; however, not all modes may be coupled to the autopilot. All autopilots may be coupled in Oceanic (OCN), Enroute (ENR), and Terminal (TERM) modes.

This installation is limited to:

- ☐ Lateral coupling only for GPS approaches. Coupling to the vertical path for GPS approaches is not authorized.

It is possible to create flight plan waypoint sequences, including Search and Rescue patterns, which exceed the autopilot's bank angle capabilities. The pilot shall monitor autopilot performance with regard to flight path deviation.

2.13.1 RNP 1.0 RF Leg Types

AC 90-105 states that procedures with RF legs must be flown using either a flight director or coupled to the autopilot.

This STC has demonstrated acceptable crew workload and Flight Technical Error for hand flown procedures with RF legs when the GTN installation complies with limitation set forth in Section 2.12 of this document. It is recommended to couple the autopilot for RF procedures, if available, but it is not required to do so. See section 4.5 of this manual to determine if this capability is supported in this installation.

2.14 Terrain Alerting Function (All Units)

Terrain, point obstacle, and wire obstacle information appears on the map and terrain display pages as red and amber terrain, obstacles, or wires and is depicted for advisory use only. Aircraft maneuvers and navigation must not be predicated upon the use of the terrain display. Terrain, obstacle and wire information is advisory only and is not equivalent to warnings provided by TAWS.

The terrain display is intended to serve as a situational awareness tool only. By itself, it may not provide either the accuracy or the fidelity on which to base decisions and plan maneuvers to avoid terrain or obstacles.

NOTE

Terrain and TAWS are separate features and mutually exclusive. If “TAWS B” is shown on the bottom right of the dedicated terrain page, then TAWS is installed.

2.15 TAWS Function (Optional)

Flight crews are authorized to deviate from their current ATC clearance to the extent necessary to comply with TAWS warnings. Navigation must not be predicated upon the use of TAWS.

TAWS shall be inhibited when landing at an airport that is not included in the airport database, or is not designated as a User Airport in the GTN.

If an external TAWS annunciator panel is installed in the aircraft, this annunciator panel must be fully functional in order to use the TAWS system.

NOTE

Terrain and TAWS are separate features and mutually exclusive. If “TAWS B” is shown on the bottom right of the dedicated terrain page, then TAWS is installed.

2.16 Polar Operations

Use of the GTN for primary navigation for latitudes above 89.00° N and below 89.00° S is prohibited.

2.17 Datalink Weather Display (Optional)

This limitation applies to datalink weather products from SiriusXM via a GDL 69/69A, FIS-B via a GDL 88 or GTX 345, and Connex via a GSR 56.

Do not use data link weather information for maneuvering in, near, or around areas of hazardous weather. Information provided by data link weather products may not accurately depict current weather conditions.

Do not use the indicated data link weather product age to determine the age of the weather information shown by the data link weather product. Due to time delays inherent in gathering and processing weather data for data link transmission, the weather information shown by the data link weather product may be significantly older than the indicated weather product age.

Do not rely solely upon data link services to provide Temporary Flight Restriction (TFR) or Notice to Airmen (NOTAM) information. Not all TFRs and NOTAMS can be depicted on the GTN.

Datalink text weather is decoded for the convenience of the pilot, however it is possible that the decoding may be affected by anomalies in the data or differences in the units of measure between the decoding system and the text weather source. All text weather displayed on the GTN also includes the raw weather text for pilot review.

2.18 Traffic Display (Optional)

Traffic may be displayed on the GTN when connected to an approved optional TCAS I, TAS, TIS, or ADS-B traffic device. These systems are capable of providing traffic monitoring and alerting to the flight crew. Traffic shown on the display may or may not have traffic alerting available. The display of traffic is an aid to visual acquisition and may not be utilized for aircraft maneuvering.

Traffic is displayed in feet regardless of the unit settings for altitude. If the units for altitude are different than feet, a “FT” label will appear on the traffic icon on and main map page, and the dedicated traffic page will include an “ALT IN FT” notification.

2.19 StormScope® Display (Optional)

StormScope® lightning information displayed by the GTN is limited to supplemental use only. The use of the StormScope® lightning data on the display for hazardous weather (thunderstorm) penetration is prohibited. StormScope® lightning data on the display is intended only as an aid to enhance situational awareness of hazardous weather, not penetration. It is the flight crew’s responsibility to avoid hazardous weather using official weather data sources.

When the GTN StormScope® page is operating without a heading source, as indicated by the “HDG N/A” label at the upper right corner of the StormScope® page, strikes must be cleared after each heading change.

2.20 Flight Planner/Calculator Functions

The Fuel Planning page uses Fuel on Board or Fuel Flow as received from an on board fuel totalizer, as entered by the pilot at system startup, or as entered by the pilot when on the Fuel Planning page. This *is not* a direct indication of actual aircraft fuel flow or fuel on board and those values are only used for the Fuel Planning page. The fuel required to destination is only a calculated and predicted value based on the data entered into the planner. It is not a direct indication of how much fuel the aircraft will have upon reaching the destination.

2.21 Fuel Range Rings

The fuel range rings displayed on the moving map are intended for situational awareness and do not represent a direct indication of endurance or fuel remaining. The distance between the segmented green reserve ring and the yellow zero fuel ring is 45 minutes by default. The reserve value can be changed from the GTN map setup menu.

Fuel range data is derived by the interfaced fuel totalizer data. Data entered in the Fuel Planning pages will not update the fuel range ring.

2.22 Glove Use / Covered Fingers

No device may be used to cover fingers used to operate the GTN unless the Glove Qualification Procedure located in the Pilot's Guide/Cockpit Reference Guide has been successfully completed. The Glove Qualification Procedure is specific to a pilot / glove / GTN 725, 750 or GTN 625, 635, 650 combinations.

2.23 Demo Mode

Demo mode may not be used in flight under any circumstances.

2.24 Active Weather Radar

Radar is broadcasting energy while in Weather or Ground mapping modes. If the GTN 750/725 system is configured to control an airborne weather radar unit, observe all safety precautions, including:

- Do not operate in the vicinity of refueling operations.
- Do not operate while personnel are in the vicinity (approximately 20 feet) of the radar sweep area.

CAUTION

If a radar system is installed, it generates microwave radiation and improper use, or exposure, may cause serious bodily injury. Do not operate the radar equipment until you have read and carefully followed the safety precautions and instructions in the weather radar user manual and/or pilot's guide.

2.25 Telephone Audio

Telephone audio must not be distributed to the pilot or co-pilot unless a phone call is active.

CAUTION

Failure to turn off telephone audio when the telephone is not in use may result in telephone ringer or text message aural notifications being received during critical phases of flight.

2.26 Multi Crew Aircraft (GMA 35 Only)*

For aircraft type certified with more than one required pilot, or operations requiring more than one pilot, the “Group Co-Pilot with Passenger” audio panel option shall not be activated. This option is found in the Intercom Setup Menu when a Garmin GMA 35 audio panel is installed.

2.27 Wire Obstacle Database

Only the “Obstacle/HOT Line” database may be used. Use of the “Obstacle/Wire” database is prohibited. The database version can be viewed on the start-up database verification or System- System Status pages.

2.28 Portable Electronic Devices

This STC does not relieve the operator from complying with the requirements of 91.21 or any other operational regulation regarding portable electronic devices.

The Flight Stream interface and data provided to a portable electronic device is not approved to replace any aircraft display equipment, including navigation or traffic/weather display equipment.

2.29 Database Updates

Database updates via MMC / SD card or Flight Stream wireless transfers must be done while the aircraft is on the ground and stationary. In-flight database transfers or updates are prohibited in flight unless part of the Database SYNC function that occurs in the background to move databases from one LRU to another.

2.30 Charts Database (Dual GTN7XX and TXi GDU)

When the aircraft installation includes 2 GTNs capable of displaying charts (GTN 700, 725 or 750) and crossfill is enabled between the GTNs, the GTNs must have identical charts types (ChartView or FliteCharts) and charts cycles installed. Failure to have identical charts could affect the chart lookup features and automatic chart selection.

Additionally, when the GTN and TXi are installed in the same cockpit, it is required that the GTN and TXi have the same chart types and cycles to ensure appropriate lookup and chart syncing/streaming functionality. If Chart Streaming or Database Sync functions are disabled, this limitation does not apply.

* Includes GMA 35 and GMA 35c Audio Panels

2.31 Automatic Speech Recognition

Pilots may not use the ASR function to operate the GTN/GMA unless they have completed the ASR Qualification Procedure located in the GTN Cockpit Reference Guide successfully. The ASR Qualification Procedure is specific to each pilot / headset / aircraft combination.

2.32 OBS Mode

Use of OBS mode for flight plan segments greater than 250_{NM} is prohibited. OBS Mode is not available between the FAF and MAP of any instrument approach.

2.33 Advisory Visual Approaches

All advisory visual approaches shall be conducted in VMC. Advisory visual approaches are intended to be used as an aid to situational awareness and do not guarantee terrain or obstruction clearance along the approach path. Use of advisory visual approaches in IMC is prohibited.

Section 3. EMERGENCY PROCEDURES

3.1 Emergency Procedures

3.1.1 TAWS WARNING

Red annunciator and aural “PULL UP”:

Autopilot..... **DISCONNECT**
Aircraft Controls..... **INITIATE MAXIMUM POWER CLIMB**
Airspeed..... **BEST ANGLE OF CLIMB SPEED**

After Warning Ceases:

Altitude..... **CLIMB AND MAINTAIN SAFE ALTITUDE**
Advise ATC of Altitude Deviation, if appropriate.

NOTE

Only vertical maneuvers are recommended, unless either operating in visual meteorological conditions (VMC), or the flight crew determines, based on all available information, that turning in addition to the vertical escape maneuver is the safest course of action, or both.

NOTE

TAWS annunciators external to the GTN may not indicate the exact threat causing the alert. Example: WIRE alerts may be annunciated as TERR or OBSTACLE on external devices.

3.2 Abnormal Procedures

3.2.1 LOSS OF GPS/SBAS NAVIGATION DATA

When the GPS/SBAS receiver is inoperative or GPS navigation information is not available or invalid, the GTN will enter one of two modes: Dead Reckoning mode (DR) or Loss Of Integrity mode (LOI). The mode is indicated on the GTN by an amber “DR” and/or “LOI”.

If the LOI annunciation is displayed, revert to an alternate means of navigation appropriate to the route and phase of flight. If LOI occurs while the GTN is in the ENR or OCN phase of flight, it may also display DR.

If the DR annunciation is displayed, the map will continue to be displayed with an amber “DR” overwriting the ownship icon. Course guidance will be removed on the CDI. Aircraft position will be based upon the last valid GPS position, then estimated by Dead Reckoning methods. Changes in true airspeed, altitude, heading, or winds aloft can affect the estimated position substantially.

If Alternate Navigation Sources (ILS, LOC, VOR, DME, ADF) Are Available:

Navigation..... USE ALTERNATE SOURCES

If No Alternate Navigation Sources Are Available:

DEAD RECKONING (DR) MODE:

Navigation..... USE GTN

NOTE

All information normally derived from GPS will become less accurate over time.

LOSS OF INTEGRITY (LOI) MODE (no DR annunciated on the GTN):

Navigation..... FLY TOWARDS KNOWN VISUAL CONDITIONS

NOTE

All information derived from GPS will be removed.

NOTE

The airplane symbol is removed from all maps. The map will remain centered at the last known position. “NO GPS POSITION” will be annunciated in the center of the map.

3.2.2 GPS APPROACH DOWNGRADE

During a LPV, LP +V, LNAV/VNAV, or LNAV +V approach, if GPS accuracy requirements cannot be met by the GPS receiver, the GTN will downgrade the approach. The downgrade will remove vertical deviation indication from the VDI and change the approach annunciation to LNAV. The approach may be continued using the LNAV only minimums. If the VISUAL approach is downgraded, the GTN will remove the vertical deviation indication from the VDI, but continue to annunciate VISUAL in amber.

During a GPS approach in which GPS accuracy requirements cannot be met by the GPS receiver for any GPS approach type, the GTN will flag all CDI guidance and display a system message “ABORT APPROACH-GPS approach no longer available”. Immediately upon viewing the message, the unit will revert to Terminal navigation mode alarm limits. If the position integrity is within these limits lateral guidance will be restored and the GPS may be used to execute the missed approach, otherwise alternate means of navigation must be utilized.

3.2.3 LOSS OF COM RADIO TUNING FUNCTIONS

If alternate COM is available:

Communications **USE ALTERNATE COM**

If no alternate COM is available:

COM RMT XFR key (if installed).....**PRESS AND HOLD FOR 2 SECONDS**

NOTE

This procedure will tune the active COM radio the emergency frequency 121.5, regardless of what frequency is displayed on the GTN. Certain failures of the tuning system will automatically tune 121.5 without flight crew action.

3.2.4 LOSS OF AUDIO PANEL FUNCTIONS (GMA 35 Only)[†]

Audio Panel Circuit Breaker **PULL**

NOTE

This procedure will force the audio panel into fail safe mode which provides only the pilot with communications and only on a single COM radio. If any non GTN 750 COM is installed, communication will be only on that radio. If only a GTN 750 is installed in the aircraft, then the pilot will have only the GTN 750 COM available. No other audio panel functions including aural alerting and the crew and passenger intercom will function.

[†] Includes GMA 35 and GMA 35c Audio Panels

3.2.5 TAWS CAUTION (Terrain or Obstacle Ahead, Sink Rate, Don't Sink)
When a TAWS CAUTION occurs, take corrective action until the alert ceases. Stop descending or initiate either a climb or a turn, or both as necessary, based on analysis of all available instruments and information.

NOTE

TAWS annunciators external to the GTN may not indicate the exact threat causing the alert. Example: WIRE alerts may be annunciated as TERR or OBSTACLE on external devices.

3.2.6 TAWS INHIBIT

The TAWS Forward Looking Terrain Avoidance (FLTA) and Premature Descent Alerts (PDA) functions may be inhibited to prevent alerting, if desired. Refer to GTN Cockpit Reference Guide for additional information.

To Inhibit TAWS:

- Home Hardkey **PRESS**
- Terrain Button **PRESS**
- Menu Button **PRESS**
- TAWS Inhibit Button..... **PRESS TO ACTIVATE**

3.2.7 TER N/A and TER FAIL

If the amber **TER N/A** or **TER FAIL** status annunciator is displayed, the system will no longer provide TAWS alerting or display relative terrain and obstacle elevations. The crew must maintain compliance with procedures that ensure minimum terrain and obstacle separation.

3.2.8 DATA SOURCE - HEADING SOURCE INOPERATIVE OR CONNECTION TO GTN LOST MESSAGE

Without a heading source to the GTN, the following limitations apply:

- Roll steering will not be provided to the autopilot for heading legs. The autopilot must be placed in HDG mode for heading legs.
- Map cannot be oriented to Heading Up.
- Overlaying traffic data from a TAS/TCAS I or Garmin ADS-B-IN unit interfaced to an on board traffic system will not be displayed on the main map display. The flight crew must use the dedicated traffic page on the GTN system to display TAS/TCAS I or Garmin ADS-B-IN traffic data.
- All overlaying StormScope® data on the main map display will be removed. The flight crew must use the dedicated StormScope® page on the GTN system to display StormScope® data.
- Onboard weather radar overlay on the main map will not be displayed. The flight crew must utilize the dedicated weather radar page on the GTN system to view weather radar data from the onboard weather radar.

StormScope® must be operated in accordance with Section 7.8 when no heading is available.

3.2.9 ASR (VOICE COMMAND) SYSTEM FAILURES

In the event the ASR system fails and there is a need to disable the voice command inputs to the GTN:

To Disable ASR:

Home Hardkey..... **PRESS**
System Button..... **PRESS**
Voice Commands Button..... **PRESS**
Voice Commands Enable Button..... **TOGGLE OFF**

3.2.10 LOSS OF GTN TOUCH CONTROL

In the event the GTN becomes unusable due to uncommanded page changes, the ASR function may be the source.

To Disable ASR:

Audio Panel Circuit Breaker..... **PULL**
Home Hardkey..... **PRESS**
System Button..... **PRESS**
Voice Commands Button..... **PRESS**
Voice Commands Enable Button..... **TOGGLE OFF**
Audio Panel Circuit Breaker..... **PUSH**

**3.2.11 DATA SOURCE – PRESSURE ALTITUDE SOURCE
INOPERATIVE OR CONNECTION TO GTN LOST MESSAGE**

If the GTN is being used to forward pressure altitude to a transponder, the transponder will not be receiving pressure altitude from the GTN while that message is present.

**3.2.12 UNRECOVERABLE LOSS OF ALL ELECTRICAL
GENERATORS OR ALTERNATORS**

Remove power from all equipment which is not necessary for flight, including GTN #2 (NAV/GPS 2, COM 2) and the Flight Stream 210 (BT LINK), if installed.

3.2.13 IN-AIR RESTART OF GTN

In the event of a GTN restart in the air, the crew should utilize the CANCEL button if presented with the database update screen after the GTN is restarted. This will ensure restoration of the navigation functions as soon as possible.

3.2.14 BARO-ALT INPUT FAILURE

Barometric altitude is required for descent VNAV functionality and automatic sequencing of altitude terminated legs. If the BARO altitude input to the GTN has failed, enroute barometric VNAV will not be available. The pilot will also be required to manually sequence any altitude terminated legs.

3.2.15 TEMPERATURE INPUT FAILURE

Temperature input is required for the VNAV Transition to Approach functionality. In the event of a temperature input failure, VNAV transition to approach should be disregarded. The crew must ensure that vertical guidance from descent VNAV to approach guidance is appropriate and that if an autopilot is in use, the crew intercepts the approach vertical guidance from below.

Section 4. NORMAL PROCEDURES

Refer to the GTN Cockpit Reference Guide defined in Section 2.1 of this document or the Pilot’s Guide defined in Section 7.1 for normal operating procedures and a complete list of system messages and associated flight crew actions. This includes all GPS operations, VHF communication and navigation, traffic, data linked weather, StormScope®, TAWS, and Multi-Function Display information.

The GTN requires a reasonable degree of familiarity to avoid becoming too engrossed at the expense of basic instrument flying in IMC and basic see-and-avoid in VMC. Garmin provides training tools with the Pilot’s Guide and PC based simulator. Pilots should take full advantage of these training tools to enhance system familiarization.

4.1 Unit Power On

Databases	REVIEW DATES
Self-Test.....	VERIFY OUTPUTS TO NAV INDICATORS
Self-Test - TAWS Remote Annunciator:	
PULL UP	ILLUMINATED
TERR	ILLUMINATED
TERR N/A	ILLUMINATED
TERR INHB	ILLUMINATED
Self-Test - GPS Remote Annunciator:	
VLOC	ILLUMINATED
GPS	ILLUMINATED
LOI or INTG	ILLUMINATED
TERM	ILLUMINATED
WPT	ILLUMINATED
APR	ILLUMINATED
MSG	ILLUMINATED
SUSP or OBS	ILLUMINATED

4.2 Before Takeoff

System Messages and Annunciators	CONSIDERED
--	-------------------

4.3 HSI and EHSI Operation

If an HSI is used to display navigation data from the GTN the pilot should rotate the course pointer as prompted on the GTN.

If an EHSI is used to display navigation data from the GTN the course pointer may autoslew to the correct course when using GPS navigation. When using VLOC navigation the course pointer will not autoslew and must be rotated to the correct course by the pilot. For detailed information about the functionality of the EHSI system, refer to the FAA approved Flight Manual or Flight Manual Supplement for that system.

CAUTION

The pilot must verify the active course and waypoint for each flight plan leg. The pilot must verify proper course selection each time the CDI source is changed from GPS to VLOC.

See Section 4.5 for RF leg capabilities related to EHSI.

4.4 Autopilot Operation

The GTN may be coupled to an optional autopilot, if installed in the aircraft, when operating as prescribed in the LIMITATIONS section of this manual.

Autopilots coupled to the GTN system in an analog (NAV) mode will follow GPS or VHF navigation guidance as they would with existing VOR receivers.

Autopilots that support GPSS or GPS Roll Steering in addition to the analog course guidance will lead course changes, fly arcing procedures, procedure turns, and holding patterns if coupled in a roll steering mode.

The GTN supports autopilot roll steering for heading legs when an approved heading source is interfaced to the GTN. This heading interface can also provide map orientation, traffic and StormScope heading data and wind calculations.

CAUTION

The GTN does not provide course deviation to the autopilot for heading legs. Some autopilots do not allow the use of roll steering when course deviation is not provided.

- ☐ This installation *has* a heading source. The GTN will provide roll steering on heading legs for the autopilot.
- ☐ This installation *does not have* a heading source. The crew cannot use the GTN roll steering to fly heading legs with the autopilot.

For autopilot operating instructions, refer to the FAA approved Flight Manual or Flight Manual Supplement for the autopilot.

4.5 Coupling the Autopilot during approaches

CAUTION

When the CDI source is changed on the GTN, autopilot mode may change. Confirm autopilot mode selection after CDI source change on the GTN. Refer to the FAA approved Flight Manual or Flight Manual Supplement for the autopilot.

Analog only autopilots should use APR mode for coupling to LNAV approaches. Autopilots which support digital roll steering commands (GPSS) may utilize NAV mode and take advantage of the digital tracking during LNAV only approaches.

- This installation prompts the flight crew and requires the pilot to enable the approach outputs just prior to engaging the autopilot in APR mode.

To couple an approach:

Once established on the final approach course with the final approach fix as the active waypoint, the GTN will issue a flashing message indication.

Flashing Message Button **PRESS**
“Enable APR Output” Button..... **PRESS**

If coupled, Autopilot will revert to ROL mode at this time.

Autopilot..... **ENGAGE APPROACH MODE**

- This installation supports coupling to the autopilot in approach mode once vertical guidance is available.

To couple an approach:

Once established on the final approach course with the final approach fix as the active waypoint, the GTN will enable vertical guidance.

Vertical Guidance**CONFIRM AVAILABLE**
Autopilot..... **ENGAGE APPROACH MODE**

- The installation *does not* support any vertical capture or vertical tracking.

The GTN allows for the utilization of IFR procedures that include RF (Radius to Fix) legs as part of RNP 1.0 capabilities.

- ☐ This installation is equipped to support coupled RF leg navigation up to RNP 1.0.
- ☐ This installation is equipped to support *un-coupled* RF leg navigation up to RNP 1.0.
- ☐ This installation *does not* support RF leg navigation.

4.6 Coupling the Autopilot for Descent VNAV

The GTN outputs VNAV deviations to properly configured Garmin G500/600 GDU, G500/600/700TXi GDU, or G5 displays. In order to provide autopilot coupling to the baro VNAV guidance, the interface must also include either a Garmin GFC500 or GFC600 with VNAV capability. If VNAV is enabled on the GTN in these installations, VNAV guidance may be coupled to the autopilot using the VNAV function of the GFC.

- ☐ This installation is equipped and configured to provide VNAV display and autopilot coupling.
- ☐ This installation is equipped and configured to provide VNAV *display only*.
- ☐ This installation *does not* support VNAV display or coupling.
- ☐ This installation is configured with VNAV Transition to Approach.

4.7 Coupling the Autopilot during Search and Rescue Operations

Search and Rescue (SAR) patterns created in the GTN flight plan may include turns that cannot be accomplished with standard autopilot turn rates. Monitor autopilot performance relative to the desired path if coupled when using Search and Rescue patterns.

4.8 Database Conflict Resolution

When a conflict occurs between databases on different GTNs that are utilizing Database SYNC the pilot should resolve that conflict by pressing the “Resolve Conflict” button on the GTN that has the desired databases. This would be the GTN with the newest database on the SD card or Flight Stream 510. After initiating the conflict resolution, the pilot can view the SYNC status of the database on the other GTN by viewing the System -> Standby Database page. Once the database SYNC is complete, the receiving GTN must be restarted to install the new database and complete the conflict resolution process.

NOTE

The databases on the receiving LRU will be overwritten by the databases from the LRU from which the “Resolve Conflicts” action was initiated.

4.9 Cold Weather Compensation

The GTN can compute altitudes for cold weather compensation for applicable IFR approaches. If the instrument approach chart requires temperature compensation, the pilot should enter the destination airport temperature into the GTN. Approach altitudes provided on the map and flight plan are adjusted based on the pilot entered temperature and the altitudes on the flight plan page are appended with a snowflake icon.

Pilots must coordinate with ATC when flying temperature compensated procedures.

Pilots must manually adjust the approach minimums as applicable. The GTN does not provide temperature compensated approach minimum values. Garmin G500/600/700TXi systems can provide compensated minimum values when interfaced with a GTN.

- ☐ This installation supports cold weather compensated intermediate approach and minimums altitudes.
- ☐ This installation supports cold weather compensated *intermediate approach altitudes and missed approach altitudes only*.
- ☐ This installation does not support cold weather compensation.

Section 5. PERFORMANCE

No change.

Section 6. WEIGHT AND BALANCE

See current weight and balance data.

Section 7. SYSTEM DESCRIPTIONS

7.1 Pilot's Guide

The Garmin GTN 6XX or GTN 7XX Pilot's Guide, part number and revision listed below, contain additional information regarding GTN system description, control and function. The Pilot's Guides *do not* need to be immediately available to the flight crew.

- | | |
|-------------------------|---------------------------------|
| • GTN 6XX Pilot's Guide | P/N 190-01004-03 Rev M or later |
| • GTN 7XX Pilot's Guide | P/N 190-01007-03 Rev O or later |

7.2 Leg Sequencing

The GTN supports all ARINC 424 leg types. Certain leg types require altitude input in order to sequence (course to altitude, for example). If a barometric corrected altitude source is not interfaced to the GTN, a popup will appear prompting the flight crew to manually sequence the leg once the altitude prescribed in the procedure is reached.

- ☐ This installation *has* a barometric corrected altitude source. The GTN will automatically sequence altitude legs.
- ☐ This installation *does not have* a barometric corrected altitude source. The flight crew will be prompted to manually sequence altitude legs.

7.3 Auto ILS CDI Capture

Auto ILS CDI Capture can automatically switch the CDI from GPS to VLOC before the Final Approach fix. This feature is only available on installations that meet any of the following conditions:

- Equipped with GFC 600
- GTN CDI key enabled

On these installations the auto-switching will only occur if the following conditions are met:

- ILS Autoswitch setting enabled on GTN
- ILS/LOC approach loaded and activated
- Correct nav frequency tuned on GTN NAV radio
- Aircraft established on the final approach course

Auto ILS CDI Capture will not automatically switch from GPS to VLOC for LOC-BC or VOR approaches.

7.4 Activate GPS Missed Approach

- ☐ This installation *will* autoswitch from VLOC to GPS when the “Activate GPS Missed Approach” button is pressed.

- This installation *will not* autoswitch from VLOC to GPS when the “Activate GPS Missed Approach” button is pressed. The pilot must manually switch from VLOC to GPS if GPS guidance is desired after the missed approach point.

7.5 Terrain Proximity, Terrain Alerting, and TAWS

CAUTION

Not all obstacles and wires are contained in the Obstacle/HOT Line database. The system provides depiction (and alerts, if TAWS is installed) only for obstacles and wires contained in the database.

NOTE

The area of coverage may be modified as additional terrain data sources become available.

- This installation supports *Terrain Proximity*. *No aural or visual alerts* for terrain or obstacles are provided. Terrain Proximity *does not* satisfy the TAWS requirement of 91.223.
- This installation supports *Terrain Alerting*. Aural and visual alerts are provided. Terrain Alerting *does not* satisfy the TAWS requirement of 91.223.
- This installation supports *TAWS B*. Aural and visual alerts *will be* provided. This installation *does* support the TAWS requirement of 91.223.

Terrain on the dedicated terrain page or main map overlay is depicted in the following manner:

- Terrain more than 1,000 feet below the aircraft is not depicted or depicted as black.
- Terrain between 1,000 feet and 100 feet below the aircraft is depicted as amber.
- Terrain within 100 feet below the aircraft, or above the aircraft, is depicted as red.

Obstacles and wires on the dedicated terrain page or main map are depicted in the following manner:

- Obstacles and wires more than 2,000 feet below the aircraft are not depicted.
- Obstacles and wires between 2,000 feet and 1,000 feet below the aircraft are depicted as white.
- Obstacles and wires between 1,000 feet and 100 feet below the aircraft are depicted as amber.
- Obstacles and wires within 100 feet below the aircraft, or above the aircraft, are depicted as red.

Multiple obstacles may be depicted using a single obstacle icon and an asterisk to indicate obstacle grouping is occurring. The color of the asterisk indicates the relative altitude of the tallest obstacle in the group. The asterisk does not indicate any information about the relative altitude or number of obstacles not being displayed in the obstacle group.

The Garmin GTN 6XX or GTN 7XX Cockpit Reference Guide or Garmin GTN 6XX or GTN 7XX Pilot's Guide provides additional information regarding terrain and obstacle colors and grouped obstacle icons.

7.6 GMA 35/35c Audio Panel (Optional)

The GTN 725 and 750 can interface to a GMA 35/35c remotely mounted audio panel and marker beacon receiver. Controls for listening to various radios, activating the cabin speaker, clearance playback control, and marker beacon are accessed by pressing the "Audio Panel" button on the GTN display screen. Optional Bluetooth pairing functionality can be accessed from the associated System /Connex Setup page (GMA 35c only). Volume controls for the audio panel are accessed by pressing the "Intercom" button on the GTN display screen.

Aircraft alerting audio may be routed through the GMA 35/35c audio panel. There are no pilot controls for alert audio volumes. In the event of a loss of GMA35/35c function alert audio routed through the audio panel may not be heard.

7.7 Traffic System (Optional)

This system is configured for the following type of traffic system. The Garmin GTN 6XX or GTN 7XX Cockpit Reference Guide or Garmin GTN 6XX or GTN 7XX Pilot's Guide provides additional information regarding the functionality of the traffic device.

- ☐ No traffic system is interfaced to the GTN.
- ☐ A TAS/TCAS I traffic system is interfaced to the GTN.
- ☐ A TIS traffic system is interfaced to the GTN.
- ☐ A TCAD traffic system is interfaced to the GTN.
- ☐ A Garmin ADS-B traffic system is interfaced to the GTN.
- ☐ A Garmin ADS-B traffic system is interfaced to the GTN. The ADS-B traffic system is also interfaced to an on-board traffic system.

7.8 StormScope® (Optional)

When optionally interfaced to a StormScope® weather detection system, the GTN may be used to display the StormScope® information. Weather information supplied by the StormScope® will be displayed on the StormScope® page of the GTN system. For detailed information about the capabilities and limitations of the StormScope® system, refer to the documentation provided with that system.

Heading Up mode:

If the GTN system is receiving valid heading information, the StormScope® page will operate in the heading up mode as indicated by the label “HDG UP” presented at the upper right corner of the display. In this mode, information provided by the StormScope® system is displayed relative to the nose of the aircraft and *is* automatically rotated to the correct relative position as the aircraft turns.

Heading Not Available mode:

If the GTN system is not receiving valid heading information, either because a compatible heading system is not installed, or the interfaced heading system has malfunctioned, the StormScope® page will continue to operate without a heading source and indicate “HDG N/A” in the upper right corner of the GTN display. In this mode, information provided by the StormScope® system is displayed relative to the nose of the aircraft but *is not* automatically rotated to the correct relative position as the aircraft turns. When operating in this mode, StormScope® strikes must be cleared after each turn the aircraft performs.

7.9 Power

- Power to the GTN is provided through a circuit breaker labeled NAV/GPS (1/2).
- Power to the optional GTN COM is provided through a circuit breaker labeled COM (1/2).
- Power to the optional GMA 35 is provided through a circuit breaker labeled AUDIO.
- Power to the optional Flight Stream 210 is provided through a circuit breaker labeled BT LINK.
- Power to the optional Flight Stream 510 is provided through the GTN MMC/SD card slot and protected via the GTN circuit breaker.

7.10 Databases and Flight Plan Waypoints/Procedures

Database versions (or cycles) and effective dates are displayed on the start-up database verification page immediately after power-on for those databases with an effective or expiration date. Databases with no effective or expiration date (e.g. - terrain database) are considered effective upon installation in the GTN. Database information can also be viewed on the System – System Status page.

The Obstacle Database has an area of coverage that includes the United States and Europe and is updated as frequently as every 56 days. The HOT Line wire database only includes the continental United States and portions of Canada/Mexico.

Only the Obstacle/HOT Line wire database may be used in accordance with the limitation found in Section 2.27.

If a stored flight plan contains a waypoint or procedure that does not correspond to a waypoint or procedure in the navigation database in use, the waypoint or procedure will become locked (depicted as “lockd”) in the flight plan. Flight plans with locked waypoints may be placed in the active flight plan portion of the system but no navigation will be provided. The locked waypoint/procedure must be resolved by removing or replacing it with the correct waypoint/procedures in the flight plan before the system will provide navigation.

7.11 External Switches

External switches may be installed and interfaced to the GTN. These switches may be stand alone or integrated with a TAWS or GPS annunciator. Table 4 lists the switches and function they perform:

Switch Label	Function
CDI	Toggles between GPS / VLOC sources. This switch may be part of an external annunciator panel.
COM CHAN DN	Toggles down through the preset com frequencies.
COM CHAN UP	Toggles up through the preset com frequencies.
COM RMT XFR	Transfers the COM active / standby frequencies.
NAV RMT XFR	Transfers the NAV active / standby frequencies.
OBS	Performs an OBS or SUSP function. This switch is part of an external annunciator panel and is placarded with the following: “Green OBS indicates OBS or SUSP mode – GTN annunciator bar indicates which is active. Push OBS button to change OBS or SUSP mode.”
OBS/SUSP	Performs an OBS or SUSP function.
TERR INHB	Toggles the TAWS Inhibit function on/off. This switch is part of an external annunciator panel. The terrain display is still presented if TAWS is Inhibited.
PTC	Push-to-Command switch for Voice Command input to the GMA and the GTN.

Table 4 – External Switches

7.12 Airspace Depiction and Alerts

The GTN aides the flight crew in avoiding certain airspaces with Smart Airspace and airspace alerts. Smart Airspace de-emphasizes depicted airspace that is not near the aircraft’s current altitude. Airspace Alerts provide a message indication to the flight crew when the aircraft’s current ground track will intercept an airspace type that has been selected for alerting.

NOTE

Smart Airspace and Airspace Alerts are separate features. Turning on/off Smart Airspace does not affect Airspace Alerts, and vice versa.

7.13 Garmin ADS-B Traffic System Interface (Optional)

A Garmin ADS-B traffic system may be interfaced to the GTN. The *nose* of the ownship symbol on both the GTN main map page and dedicated traffic page serves as the actual location of your aircraft. The *center* of the traffic target icon serves as the reported location for the target aircraft. Motion vectors for traffic may be displayed in either absolute or relative motion. The location of the traffic targets relative to the ownship are the same, regardless of the selected motion vector.

Absolute motion vectors are colored either cyan or white, depending on unit configuration. Absolute motion vectors depict the reported track of the traffic target referenced to the ground. An absolute motion vector pointed towards your ownship symbol *does not* necessarily mean the traffic target is getting closer to your aircraft.

Relative motion vectors are always colored green and depict the motion of the traffic target relative to your ownship symbol. The direction the traffic target is pointed may vary greatly from the motion vector and a target may be getting closer to your aircraft independent of the direction the target is pointed. A green relative motion vector pointed towards your ownship indicates that the traffic target *is* converging on your aircraft.

If more than one target is occupying the same area of the screen, the GTN will combine the two or more traffic targets into one traffic group. The presence of an asterisk to the left of a target indicates that traffic has been grouped. The highest priority traffic target in the group is displayed to the pilot. When applied to airborne targets the asterisk will be displayed in white or cyan depending on the traffic depiction color used in the installation. The asterisk will be brown for grouped ground targets. The asterisk will not turn amber, even if an alerted target is included in the group.

An alerted target may be placed in the same group as non-alerted targets. In this case, the alerted target will be displayed. Two alerted targets will not be placed in the same group. All alerted targets will be displayed on the screen.

Traffic targets displayed on the dedicated traffic page may be selected in order to obtain additional information about a traffic target or to view all targets in a grouped target. When a grouped target is selected, the “Next” button on the dedicated traffic page will cycle through all targets located in close proximity to where the screen has been touched.

7.14 GWX 70/75 Weather Radar (Optional)

The GWX 70/75 Weather Radar uses Doppler technology to optionally provide advanced features to the flight crew such as turbulence detection and ground clutter suppression. Turbulence detection can detect turbulence up to 40nm from the aircraft and will be displayed at radar ranges of 160nm or less.

NOTE

Turbulence detection does not detect all turbulence especially that which is occurring in clear air. The display of turbulence indicates the possibility of severe or greater turbulence, as defined in the Aeronautical Information Manual.

7.15 Charts (Optional)

The GTN 750/725 can display both procedure charts and weather data on the main map page at the same time. When datalink NEXRAD or Precipitation is overlaid on the main map page, the weather data is displayed *below* an overlaid procedure chart. When airborne weather radar is overlaid on the main map page, the radar data is displayed *above* an overlaid procedure chart.

7.16 Transponder Control (Optional)

The GTN can be interfaced to a Garmin transponder for control and display of squawk code, mode, and additional transponder functions. The activation of the “Enable ES” button on the transponder page does not indicate the aircraft is in full compliance with an ADS-B Out solution in accordance with TSO-C166b (1090ES). Consult your transponder documentation for additional information.

7.17 Telephone Audio (Optional)

Telephone audio distribution to the crew defaults to OFF on each power cycle of the GTN. Prior to utilizing the telephone function, the crew must distribute telephone audio to the desired recipients. If the crew is utilizing the telephone function it is required that the telephone audio be turned off upon completing telephone usage.

7.18 Depiction of Obstacles and Wires

7.18.1 Dedicated Terrain Page

The dedicated Terrain page will always depict point obstacles at zoom scales of 10 nm or less and depict wire obstacles at zoom scales of 5 nm or less. The obstacle or wire overlay icon (see Figure 3) will be shown near the bottom of the display when the obstacle or wire depiction is active based on the zoom scale.

NOTE

Only obstacles and wires within 2,000 feet vertically of the aircraft will be drawn on the Terrain page. It is therefore possible to have an obstacle or wire overlay icon displayed with no obstacles or wires being depicted on the display.



Figure 3 – Obstacle Overlay Icon (Left), Wire Overlay Icon (Right)

7.18.2 Map Page

The Map page may be configured to depict point obstacles and wire obstacles at various zoom scales by the pilot by using the Map page menu. The obstacle or wire overlay icon (see Figure 4) will be shown near the bottom of the display when the obstacle or wire overlay is active based on the current zoom scale and setting selected by the pilot.

The settings chosen by the pilot on the Map page menu (including obstacle and wire display ranges) are saved over a power cycle.

NOTE

Only obstacles and wires within 2,000 feet vertically of the aircraft will be drawn on the Map page. It is therefore possible to have an obstacle or wire overlay icon displayed with no obstacles or wires being depicted on the display.

NOTE

The Map page may be configured by the pilot to not show any obstacles or wires at any zoom scale.



Figure 4 – Obstacle Overlay Icon (Left), Wire Overlay Icon (Right)

7.19 Flight Stream 210/510 (Optional)

The Flight Stream product line uses a wireless transceiver to provide data to and from a GTN to personal electronic devices (PEDs).

The Flight Stream 210 is a remotely mounted unit that provides the capability to interface Portable Electronic Devices (PEDs) to the GTN via Bluetooth. The Flight Stream 510 is mounted in the GTN SD card slot and includes a Bluetooth and Wi-Fi transceiver.

Data such as traffic, flight plan, datalink weather, entertainment audio information, and attitude information is sent from the Flight Stream to the PED. The PED is capable of sending flight plans and databases (510 only) to the Flight Stream which will then be available on the GTN. Limitations regarding database operations are found in Section 2.29.

Garmin provides a list of tested and compatible devices that can be used with the Flight Stream. Connection to the Flight Stream may be possible with devices other than those on the supported device list, but Bluetooth® and/or Wi-Fi stability and wireless data integrity cannot be guaranteed.

For details about the Garmin supported devices and apps for use with the Flight Stream product line, please visit: http://garmin.com/connext/supported_devices

7.20 Map Page

7.20.1 Configuration

The moving map and weather pages are capable of displaying a large quantity and variety of data. Map data is layered to ensure that data which is typically more critical is drawn above less critical data, however at some zoom scales and configurations the map may be cluttered with large amounts of data. Controls are provided on the Map and Weather pages for the pilot to select which data displayed, the declutter level, and the zoom scales at which data is added to or removed from the display. It is the responsibility of the pilot to select settings for the map page that will provide the display of data most appropriate to the operation being conducted.

7.20.2 Flight Plan Depiction

The map page depicts the current active flight plan. When an off-route Direct To is active the flight plan will no longer be depicted on the map.

7.20.3 Fuel Range Ring

The distance between the segmented green reserve ring and the yellow zero fuel ring is 45 minutes at the current aircraft groundspeed by default. The pilot may change the fuel reserve time value on the map setup menu. Changes to the fuel reserve time are persisted over GTN power cycles.

Visibility of the fuel range ring may be affected by the underlying map data selectable by the pilot. The pilot may make changes to the topographic or terrain data in order or more clearly observe the fuel range ring at any time.

Fuel range data is derived from the interfaced fuel totalizer data. Data entered in the Fuel Planning pages will not update the fuel range ring.

7.21 User Defined Waypoints

When a User Defined Waypoint is created, a default name will automatically be provided, and the pilot is given the option to enter a different name for the waypoint. Pages which have the autofill function will prevent some waypoint names from being used. If it is desired to name the waypoint with a subset of the name of an existing waypoint in the database then this must be accomplished on the Waypoint Info / User Waypoints page.

Waypoints which are created when a Search and Rescue pattern is created are not considered User Waypoints and therefore functions associated with User Waypoints are not provided for these waypoints.

7.22 Times and Distances

Time and Distance data to the next waypoint is always calculated from the present position to that waypoint and does not account for the path which may be flown (such as intercepting a course) to reach the waypoint.

When navigating using GPS guidance most legs are TO type legs where distance to the next waypoint decreases along the route. However, some procedures include FROM type legs. When navigating on a leg that is a FROM leg indications that it is a FROM leg include the TO/FROM flag indicating FROM and distances increasing in distance fields.

7.23 GTN-GTN Crossfill

Specific data will sync between GTNs when installed in a dual GTN configuration. If data is not included in this list, it is not crossfilled. The following data will crossfill between the two GTNs with CROSSFILL ON or OFF:

- User Waypoints
- FPL Catalog
- Traffic Alerts
- Missed Approach Popups
- Altitude Leg Popups
- Heading
- Date/Time Conventions
- CDI Scale
- Default FPA

The following unit changes will crossfill:

- Temperature
- NAV Angle
- Fuel

The following items are crossfilled only when the GTNs are set to CROSSFILL ON:

- User Holds
- Approaches
- Flight Plan Changes
- Direct-To
- Selected OBS Course Changes

7.24 Direct-To Operations

When conducting Direct-To operations the Flight Plan tab provides a list of waypoints in the flight plan for which Direct-To is available. Some entries in the flight plan such as Holds and Course Reversals are not eligible for Direct-To and the pilot must instead select the associated waypoint if Direct-To operation is desired.

7.25 Automatic Speech Recognition (ASR)

ASR allows the pilot to interact with the GMA and GTN via voice commands. Commands are constructed around the “Verb – Noun – (Suffix)” syntax for most ASR commands.

- **“SHOW”** Commands – Used to show pages or data fields on the GTN
- **“SAY”** Commands – Used to instruct the ASR engine to say certain phrases related to the flight
- **“TUNE”** Commands – Used to tune certain frequencies into the standby position of the ASR GTN (usually GTN #1)

The “Page” suffix is used in conjunction with the “Show” phrase to command pages to be displayed on the GTN. (e.g.- “Show Main Map Page”)

Audio Panel commands are available to switch audio sources.

- **“SELECT”** to choose which radio the MIC will be selected
- **“TOGGLE”** to toggle the monitor of a specific NAV/COM radio
- **“DISTRIBUTE”** to change the source of audio for the respective seat positions
- **“MUTE”** to mute audio inputs on the audio panel for the respective seat positions

Supplemental commands that allow map zooming, and page navigation are also available.

- **“BACK”**
- **“CANCEL”**
- **“ZOOM IN”**
- **“ZOOM OUT”**

Each command is initiated via the Push-to-Command (PTC) switch. Aural tones will indicate to the pilot the status of the command. A positive tone (low to high) will indicate the system executed a command. A negative tone (high to low) will indicate the system did not understand the command or could not execute due to system state or configuration. “SAY” commands do not provide aural tones as feedback.

The pilot must maintain vigilance regarding ASR command information. Due to the nature of voice recognition, there are times when ASR will interpret a command differently than the pilot intended. The pilot should always cross check the ASR response to the information contained within the GTN as appropriate to ensure in-flight information is accurately understood. If a conflict exists between information gathered via ASR and that available in the GTN system, the pilot should defer to the GTN system information.

Prior to using ASR, the pilot must complete the ASR Qualification Procedure from the GTN Cockpit Reference Guide.

The Command History Page details the commands received by ASR for that power cycle. A full list of commands and guidance for using ASR can be found in the *GTN 6XX/7XX Telligence Voice Command Guide*, 190-01007-50.

When using ASR for “TUNE” commands, it is recommended that the pilot enable Reverse Frequency Lookup (RFL) on the associated GTN.

7.26 European Visual Reporting Points

If the GTN is interfaced with a G500/600 PFD/MFD, and a flight plan in the GTN contains a VRP, the G500/600 must have a database that contains the VRP in order to appropriately display the VRP on the MFD map. If the database on the PFD/MFD does not contain the VRP, the VRP will display on the MFD map as an intersection.

7.27 Advisory Visual Approaches

The GTN will provide advisory visual approaches to many runways in the aviation database. Lateral guidance for the visual approach is aligned with the runway bearing. Vertical guidance is provided for those runways with VGSI information for distances up to 4.0NM from the runway. If a terrain database is installed in the GTN, the GTN provides vertical guidance up to 28NM from the runway end unless the computed glideslope would impact terrain or obstacles from the database. If the projected impact point is under 28NM and greater than 4NM, the flight plan line for the approach is shortened to indicate where vertical guidance is active for the approach. If the terrain impact point is less than 4NM from the runway and there is no VGSI data available, vertical guidance is not provided for that approach. Lateral guidance is still available when vertical guidance is removed.

CDI and VDI indications are equivalent to those of other GPS-based approaches (e.g.- LPV or LNAV+V). The GTN annunciates “VISUAL” in the annunciator bar to indicate a visual approach is active.

When loading, or activating the approach, the GPA and TCH information for that approach will be displayed on a popup. If there is no vertical guidance available, the popup will display “(NO VERTICAL GUIDANCE)”.

Visual approaches are intended to be used as an aid to situational awareness. Visual approaches are advisory in nature and do not guarantee terrain and obstacle clearance for the approach runway.

7.28 Descent VNAV

The GTN can provide multi-waypoint descent baro-VNAV guidance for the enroute and initial approach phases of flight. Altitudes associated with instrument procedures are retrieved from the navigation database when the procedure is added to the flight plan.

Altitudes in cyan on the GTN are valid VNAV guidance waypoints and the GTN will provide vertical guidance based on the displayed altitude constraints and default flight path angle (FPA). Altitude colored white are advisory only.

The following are recommendations for using descent VNAV:

- The pilot should verify all altitudes for procedures after loading the procedure into the flight plan.
- When the GTN is installed with a multiple TXi PFDs, it is highly recommended that GDU BARO SYNC be enabled and used during all VNAV operations.

In aircraft where there are multiple GDUs and two GTNs, VNAV will use the barometer setting from the pilot's side GDU for both GTNs. In the event the pilot's side GDU has failed, the GTNs will use the co-pilot's GDU barometer setting.

Descent VNAV is limited to flight path angles (FPA) of -6° or less, and vertical speed required of no less than -4000 fpm. If a flight plan change is made during a VNAV descent, VNAV will be recalculated and could result in active VNAV path changes. If the current VNAV FPA is less than -1° , a new VNAV path may be computed during a flight plan change and result in a new Top of Descent point. This can also occur during VNAV Direct-To operations.

VNAV constraints are not allowed inside the FAF. VNAV altitudes are not saved in the flight plan catalog.

When VNAV is disabled by the pilot, it will be automatically re-enabled when the pilot initiates a lateral Direct-To to a waypoint.

7.29 Along Track Waypoints

The GTN allows for the creation of flight plan waypoints that are based off an offset distance from a waypoint in the flight and places the new along track waypoint (ATK) in the flight plan. Once placed in the flight plan, the pilot may navigate using that waypoint in the same manner as other flight plan waypoints.

Along track waypoints cannot be created on a Vectors to Final (VTF) approach and are limited to the lateral constraints of the flight plan. This means that the pilot cannot place an ATK before the first waypoint of a flight plan or after the last waypoint of a flight plan.

ATKs are fixed once placed and will not move if the referenced waypoint is changed or removed from the flight plan. ATKs are not saved in the flight plan catalog. ATKs cannot reference another ATK in the flight plan.

7.30 Database Provided Altitudes

When the GTN provides altitude data for waypoints included in IFR procedures, the altitudes provided are those shown on the procedure chart for “Turbojet” or “Jet” aircraft. If altitudes for other aircraft such as “Turboprop” or “Prop” are required, the crew must manually edit the waypoint altitude.

7.31 Database Sync with G500/600 or G500/600/700TXi GDUs

When a GTN hosts a Flight Stream 510 for database syncing to GDUs, the GTN and GDU must be configured for the same chart database type (FliteCharts or ChartView). If the GDU and GTN are not configured for the same chart type, charts database sync and Chart Streaming will not be available.