To update your Jeppesen®, Obstacle, or Terrain database, you need to connect your GPS unit to your computer. You also need to connect to the Internet.

Access the Garmin Web site: http://www.garmin.com.
When the page opens, click **Avionics**. AVIONICS
Then click **Aviation Database Updates** near the bottom of the page.

You can also type the following link into your Web browser:
http://shop.garmin.com/aviation/databases/

Click **Next** to get started.

Step One

Click the drop-down menu. Select your GPS unit. Then click .

Step Two

If available, select the database type you want to update: Jeppesen, Obstacle, or Terrain. Then click . Otherwise, go directly to Step Three.

Step Three

Click Continue .

Step Four

Click one of the buttons
to select a coverage area.

*If you are updating an Obstacle database,
only one coverage area is available.*

Step Five

scroll bar

Read the License Agreement. Click the arrows on the scroll bar to view the entire agreement.

If you agree to the terms, click **I agree to the above terms and want to download the file.**

Step Six

Keep your Internet Browser open during this step!

❶ Click **Save**.

*Your computer may display a different screen from what is shown here. If so, you may need to click **OK** to proceed.*

❷ Click the menu and select **Desktop**.

❸ Then click **Save.**

❹ Click **Close**.
(if necessary)

Step Seven

Go back to your Internet Browser window. Then click [Continue].
The page below appears.

If you are a
returning customer,
enter your password
and click [Continue].

If you are a
new customer, click
Enter Customer Info.

Step Eight

If you are a returning customer, verify your personal information. If you are a new customer, enter your personal information. Then click Continue.

Step Nine

Locate the AVDWebUpdater file you saved in Step Six (on the Desktop of your computer). Double-click the file to open it. The file looks like this:

If you have trouble opening the file, you may need to go back to the Internet and download it again. See Steps Five and Six.

 Click **Setup**.

Be sure to keep your Internet Browser open during this step!

Step Ten

At this time, turn your GPS on and connect it to your computer if you have not already done so. Refer to your Owner's Manual for instructions. Then click **Next**.

Step Eleven

Make sure the name of your GPS unit appears and click **Next**. If not, check the connection and click **Find Device**.

Step Twelve

The Unit ID for your GPS unit appears. Click **Copy**. Then click **Next**.

Step Thirteen

Go back to your Internet Browser window.

Click inside the **Enter Unit ID** field. Then click the right mouse button. Select **Paste** from the menu that appears. Your Unit ID appears in the field. Click Continue .

Step Fourteen

Enter Coupon Code here.

Click to select a payment option. If you have a Coupon for a free Jeppesen Update, click **Redeem a Coupon** and enter the Coupon Code in the space provided. Then click [Continue].

If you are paying by credit card, enter your credit card information. Review and confirm your payment information. Then click **Purchase** or **Redeem Coupon**.

Step Fifteen

Your unlock code, password, and order number appear. Print this page for your records, and keep the codes in a safe place!

Now, you need to transfer your Unlock Code to the AVDWebUpdater.

Click the mouse and drag it over the Unlock Code to highlight it. Then click the right mouse button and select **Copy** from the menu that appears.

You can also write down the Unlock Code so you can type it in later.

Step Sixteen

Go back to the AVDWebUpdater.

Click inside the field. Click the right mouse button and select **Paste** from the menu that appears, or type in your Unlock Code. Then click **Next**.

Follow the instructions and then click **Finish**.

If you have an iQue 3600a, synchronize now (press the HotSync button) to finish transferring data to your unit.