

GDL 30/30A

owner's manual



© 2005, 2008 Garmin Ltd. or its subsidiaries

Garmin International, Inc.
1200 East 151st Street,
Olathe, Kansas 66062, USA
Tel. (913) 397.8200 or (800) 800.1020
Fax (913) 397.8282

Garmin (Europe) Ltd.
Liberty House
Hounsdown Business Park,
Southampton, Hampshire, SO40 9RB UK
Tel. +44 (0) 870.8501241 (outside the UK)
0808 2380000 (within the UK)
Fax +44 (0) 870.8501251

Garmin Corporation
No. 68, Jangshu 2nd Road,
Shijr, Taipei County, Taiwan
Tel. 886/2.2642.9199
Fax 886/2.2642.9099

All rights reserved. Except as expressly provided herein, no part of this manual may be reproduced, copied, transmitted, disseminated, downloaded or stored in any storage medium, for any purpose without the express prior written consent of Garmin. Garmin hereby grants permission to download a single copy of this manual onto a hard drive or other electronic storage medium to be viewed and to print one copy of this manual or of any revision hereto, provided that such electronic or printed copy of this manual must contain the complete text of this copyright notice and provided further that any unauthorized commercial distribution of this manual or any revision hereto is strictly prohibited.

Information in this document is subject to change without notice. Garmin reserves the right to change or improve its products and to make changes in the content without obligation to notify any person or organization of such changes or improvements. Visit the Garmin Web site (www.garmin.com) for current updates and supplemental information concerning the use and operation of this and other Garmin products.

Garmin® is a trademark of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. GPSMAP® and myGarmin™ are trademarks of Garmin Ltd. or its subsidiaries. These trademarks may not be used without the express permission of Garmin.

INTRODUCTION

The GDL 30/30A Marine Weather/Audio Satellite Receiver provides graphical and textual marine XM WX weather information to be viewed on your Garmin Marine Network chartplotters. Operation of the GDL 30 requires a subscription to the XM WX Satellite Weather service. Additionally, the GDL 30A offers music, news, and talk programming capability with a subscription to the XM Radio service.

This manual covers the XM weather and audio features of the GDL 30/30A when viewed on a GPSMAP 3000 Series Garmin Marine Network chartplotter. To understand the XM weather and audio features of the GDL 30/30A when viewed on a GPSMAP 4000 or 5000 series chartplotter, see the 4000 or 5000 series Owner's Manual.

To install the GDL 30/30A, reference the printed installation instructions.

Product terminology used throughout this manual

- This manual refers to the GDL 30 Marine Weather Satellite Receiver as GDL 30 and the GDL 30A Marine Weather/Audio Satellite Receiver as GDL 30A. It covers instructions for both units (GDL 30/30A). Unless otherwise specified, unit operations are the same on both models.
- Garmin Marine Network Chartplotters are Multi-Function Display units such as the GPSMAP 3005C, and GPSMAP 3006C/3010C. They are referred to as chartplotters throughout this manual.

Product Registration

Help us better support you by completing our online registration today! Connect to our Web site at <http://my.garmin.com>. Keep the original sales receipt, or a photocopy, in a safe place.

Important Numbers

For future reference, write down the important numbers associated with your GDL 30/30A.

Serial number

(located on the bottom of the unit)

Unique XM IDs are associated with your GDL 30/30A. XM Satellite Radio uses these ID numbers to activate and deactivate your XM weather and XM audio (if applicable). To locate the ID number(s) on your unit, see [page 23](#).

XM WX Weather ID

XM Radio ID

(GDL 30A only)

Contact Garmin

Contact Garmin if you have any questions while using your GDL 30/30A. In the USA contact Garmin Product Support by phone: (913) 397-8200 or (800) 800-1020, Monday–Friday, 8 AM–5 PM Central Time; or go to www.garmin.com/support/.

Contact XM

To set up your XM account call (800) 800-9200. For XM weather information, visit www.xmwxweather.com.

Introduction	i	Atmosphere	10
Product terminology used throughout this manual	i	Wind.....	10
Product Registration	i	Pressure.....	11
Important Numbers	i	Visibility	12
Serial number.....	i	Fronts.....	13
XM WX Weather ID.....	i	Sea Surface	15
XM Radio ID.....	i	Temperature.....	15
Contact Garmin	i	Wave Height	15
Contact XM	i	Wave Period.....	16
Unit Overview	1	Wave Direction	16
Packing List and Accessories	1	Main Menu	17
Caring for the Unit	1	Weather Tab	17
Cleaning the Case	1	Current	17
Water Immersion	1	Forecast.....	18
Storage	1	Sea Surface	19
Servicing Your Unit	1	Forecast Map	20
Installing and Activating the Unit	2	Setup	21
Using XM WX Weather	3	XM Tab	22
Preset Weather Displays	3	Information	23
Selecting a preset weather display	3	Appendix	24
To select a preset weather display:	3	Blink Codes	24
Customizing the Preset Weather Displays.....	4	Weather-Related Broadcast Rates	24
The Weather Features	5	GDL 30/30A Specifications	25
Precipitation	5	GA 31 Antenna Specifications.....	25
NEXRAD.....	5	Product Safety and Regulatory Information	26
Cloud Tops.....	6	Weather and Sea Surface information	26
Cells.....	7	Caution	26
Lightning	8	Software	27
Hurricanes.....	9	Software Versions	27
		Limited Warranty	28
		Index	29

UNIT OVERVIEW



Packing List and Accessories

Before installing your unit, please check to see that your package includes the following items. If any parts are missing, contact your Garmin dealer immediately.

Standard Package

- GDL 30 or 30A unit
- 7-pin power cable
- Garmin marine network cable (6 ft)
- Installation Instructions
- Owner's Manual
- GA 31 Antenna with cable
- Audio cable (GDL 30A only)
- Grommet

Optional Accessories

- GMS 10 Network Port Expander
- Garmin marine network cables (20 ft and 40 ft)

Caring for the Unit

The case is constructed of high-quality materials and does not require user maintenance, except cleaning.

Cleaning the Case

Clean the unit's outer casing using a cloth dampened with a mild detergent solution and then wipe dry. Avoid chemical cleaners and solvents that may damage plastic components.

Water Immersion

The unit is waterproof to IEC Standard 60529 IPX7. It can withstand immersion in 1 meter of water for 30 minutes. Prolonged submersion can cause damage to the unit. After submersion, be certain to wipe and air dry the unit before reuse.

Storage

Do not store the unit where exposure to temperature extremes may occur, as permanent damage may result.

Servicing Your Unit

The Garmin GDL 30/30A has no user-serviceable parts. Should you ever encounter a problem with your unit, take it to an authorized Garmin dealer for repairs or contact Garmin Product Support.

The GDL 30/30A is fastened shut with screws. Any attempt to open the case to change or modify the unit in any way voids your warranty and may result in permanent damage to the equipment.

INSTALLING AND ACTIVATING THE GDL 30/30A

Step 1: Install the unit

Use the GDL 30/30A Installation Instructions to make the appropriate wiring connections.

Step 2: Set up the XM account

Have your XM Weather ID ready (and XM Radio ID, if applicable). Contact XM Satellite Radio by phone at **800-985-9200**. After providing the required information, the XM representative activates the account and sends out an XM signal to activate the GDL 30/30A.

For answers to other XM questions, call the above number or visit www.xmwxweather.com.

Step 3: Confirm all components of your service package

XM WX Weather: Ensure your chartplotter turned on so you receive the XM signal. The XM signal is received when the components of the selected service package appear in the **Weather Products** list. Do not turn off the chartplotter until the name of the selected service package appears in the **Service Level** field (see [page 23](#)).



NOTE: on a 4000 or 5000 series chartplotter, your service package appears on the system information screen (**Configure > System > System Information > Weather Subscription**)

XM Radio: Highlight the **Audio** sub tab and verify that channels 7, 9, 47, and 122 are being received (see [page 22](#)). This indicates that all channels on XM's basic radio service are being received. If within an hour the XM WX Weather and/or the XM Radio service has not activated, call XM customer care at **800-985-9200** to refresh the signal.

Step 4: Save the service package

After the service package name appears, turn off the entire marine network using the chartplotter's power key.

Step 5: Use your new XM services

When you turn on the GDL 30/30A after completing Step 4, you are ready to view weather features on the chartplotter and customize the new radio stations (GDL 30A only).

USING XM WX WEATHER

This manual describes the use of XM WX Weather and XM Audio functions (GDL 30A only) on a GPSMAP 3000 Series chartplotter. If you have a GPSMAP 4000 or 5000 Series chartplotter, please use your chartplotter's Owner's Manual for instructions on using XM WX Weather and XM Audio.


Preset Weather Displays

Selecting a preset weather display


There are three preset weather displays, General, Sea State, and Storms. The name of the selected preset appears in the lower left corner of the screen. Use presets to view different types of weather information quickly.

To select a preset weather display:


1. Press the **Wthr Options** soft key.
2. Press the **Next Preset** soft key to cycle through the three presets.



General



Sea State



Storms

Customizing the Preset Weather Displays

The preset weather displays can be customized. Each preset has three subcategories: Precipitation, Atmosphere, and Sea Surface. Each category contains display settings for that topic. The name of the preset can be changed and any of the weather features can be selected for display. For detailed information on customizing the preset weather displays, please see the chartplotter's Owner's Manual.

The image displays three overlapping screenshots of the weather display customization interface, each showing a different subcategory: Precipitation, Atmosphere, and Sea Surface.

Precipitation Settings:

- GENERAL: Precipitation (selected), Atmosphere, Sea Surface
- NEXRAD / Cloud Tops: All Ranges
- NEXRAD: NEXRAD
- Storm Cells: Off
- Lightning: Off
- Hurricanes: Off

Atmosphere Settings:

- GENERAL: Precipitation, Atmosphere (selected), Sea Surface
- Wind: Off
- Pressure: Off
- Visibility: Off
- Fronts: All Ranges
- City Conditions: Auto

Sea Surface Settings:

- GENERAL: Precipitation, Atmosphere, Sea Surface (selected)
- Temperature: Off
- Wave Height: Off
- Wave Period: Off
- Wave Direction: Off

Each screenshot includes a map of the central United States showing weather features like precipitation (green/red areas) and fronts (red lines).

THE WEATHER FEATURES


Following is a brief description of each weather feature. The weather features are divided into three sub categories, Precipitation, Atmosphere, and Sea State.

Precipitation

The Precipitation category contains NEXRAD/Cloud Tops, Storm Cells, Lightning, and Hurricanes. Each feature can be turned on, off, or set to display at a selected zoom range.

NEXRAD


NEXRAD is an acronym for NEXt Generation Weather RADar. The NEXRAD feature displays precipitation from very light rain and snow up to strong thunderstorms in varying shades and colors. A legend showing the colors for Rain, Mix, and Snow can be displayed by pressing the ADJ key and selecting Weather Legend. NEXRAD can be displayed independently or with Cloud Tops.




Cloud Tops

Cloud Tops displays the varying level of cloud tops in shades of gray. Cloud Tops can be displayed independently or with NEXRAD information.

Cloud Tops Legend



Cloud Tops




Cloud Tops with NEXRAD

Storm Cells

The Storm Cells feature displays storms as well as the storm's projected path in the immediate future. It also shows the size of the storm cell. The direction of the red cone indicates the projected path of the storm cell. The red bars that appear in the middle of the cone indicate where the storm will be in the future. Each bar represents 15 minutes.




The red bars that appear in the middle of the cone in this storm indicate where the storm will be in the next hour.




Hurricanes

The Hurricanes feature shows the current position of a hurricane as well as its projected path (indicated by a red line). The darkened squares that appear (as in the examples in the left-hand column below) along the red line display the projected locations received from the National Hurricane Center. The Center provides four forecasts at 12-hour intervals as well as a fifth forecast at a 24-hour interval.


In this example, this hurricane is projected to travel West-Southwest before moving in a Northwesterly direction.



This example shows Hurricane Charley's projected path through Florida in August 2004. Wind and storm cells are also visible.



In this example of Hurricane Charley in August, 2004, NEXRAD data, wave height, and wind are shown.





Atmosphere

The Atmosphere category contains Wind, Pressure, Visibility, Fronts and City Conditions. Each feature can be turned on, off, or set to appear at a selected zoom range.

Wind

The Wind feature displays wind speed and direction. Wind direction is indicated by a circle with a wind barb. The circle points into the wind with the barb as a tail. Wind speed is indicated by different flags attached to the barb.




20-knot winds blowing to the Southwest.

Pressure


This feature displays pressure isobars and pressure centers on the chartplotter's map. The isobars connect points of equal pressure. Pressure readings can help determine weather and wind conditions in an area. High pressure areas are generally associated with fair weather. Low pressure areas are generally associated with clouds and the chance of precipitation. Isobars that are packed closely together show a strong pressure gradient. Strong pressure gradients are associated with areas of stronger winds.

Pressure units can be displayed in Millibars (mb), Inches of Mercury (in), and Hectopascals (hPa). See the chartplotter's Owner's Manual for more information.

Pressure Isobars




Strong Pressure Gradient




Visibility

Visibility is the maximum horizontal distance that can be seen. Isobars on the Visibility feature show a change in visibility. In the example below, visibility ranges from .5 miles to 3 miles.




This image shows NEXRAD, Cloud Tops, and Visibility. Displaying multiple features may help to provide a clearer picture of the weather conditions in the area.



Fronts


The Fronts feature displays the lines indicating the leading edge of an air mass that is replacing another. This feature also displays pressure centers. Pressure centers are represented by a large Red “L” for low pressure centers or a large Blue “H” for high pressure centers. Pressure centers represent an area where pressure is measured to be either the highest or lowest relative to the surrounding area.



Indicates a Low Pressure Center. A Low Pressure Center is an area where the measured pressure is lowest relative to the surrounding area. Moving away from a Low Pressure Center in any horizontal direction results in increased pressure. Winds flow counterclockwise around Low Pressure Centers in North America.




Indicates a High Pressure Center. Similar to a Low Pressure Center, a High Pressure Center is an area where the measured pressure is highest relative to the surrounding area. Moving away from a High Pressure Center in any horizontal direction results in decreased pressure. Winds flow clockwise around High Pressure Centers in North America.



City Conditions

This feature displays the current weather conditions at selected cities throughout North America. The current weather condition for an area is depicted by an icon.

City Condition Icons



Sea Surface



The Sea Surface category contains Temperature, Wave Height, Wave Period, and Wave Direction. Each feature can be turned on, off, or set to display at a selected zoom range.

Temperature

The Temperature feature displays the water's surface temperature. The temperature breaks are indicated by isobars.

Wave Height

The Wave Height feature displays wave heights. The wave heights for an area are separated by isobars.




Wave Period

The Wave Period feature provides the time (in seconds) between successive waves.


Wave Direction

The Wave Direction feature shows the direction in which a wave is moving, as indicated by the direction of the red arrow.

Wave Period feature



Wave Direction feature



MAIN MENU

Weather Tab

The GDL 30/30A provides current weather conditions, forecast information, and sea surface information from the weather center nearest to your present location or a location selected using the Find Information Page. To display the Weather tab, press and hold the **ADJ/MENU** key to display the Menu Menu. Using the **ROCKER**, highlight the Weather tab. Five sub tabs are available: Current, Forecast, Sea Surface, Forecast Map, and Setup.

Current

The Current sub tab displays current weather conditions observed at the weather data location closest to your current position or a location selected using the Find Information Page.

The screenshot shows the 'Weather' sub-tab selected in the 'Normal Operation' menu. The 'Current' sub-tab is active, displaying weather data for the nearest location: Olathe, Johnson Co Exec Air, KS. The data includes Temperature (82°F), Dew Point (66°F), Winds (167^M 17kt), Wind Gust (---kt), Visibility (4.3nm), Pressure (29.82in), and Haze (empty field). The 'Wind Gust' and 'Haze' fields are circled in red in the original image to indicate they are empty.

Normal Operation	Current	Forecast	Sea Surface	Forecast Map	Setup
Celestial	Nearest To				
Trip	Current Position				
Weather	01:53PM at Olathe, Johnson Co Exec Air, KS				
Database	Temperature 82°F				
Points	Dew Point 66°F				
Routes	Winds 167 ^M 17kt				
Tracks	Wind Gust ---kt				
DSC	Visibility 4.3nm				
Card	Pressure 29.82in				
Setup	Haze				
Alarms					
System					
Pages					
Map					

If a condition field is empty, data for that field is not available at this time.

Find Weather Information

The screenshot shows the 'Find Weather Information' page with search options: Current Position, Map Position, Waypoints, and Cities. The 'Current Position' option is highlighted in yellow. To the right is a map of the Kansas City area with various cities and landmarks labeled, including St. Joseph, Topeka, Kansas City, Gap, Harry S. Truman Reser, Stockton Lake, and Joplin.

*To search for data at a location other than your current location, highlight **Current Position** and press **ENTER**. With the Find Weather Information Page displayed, highlight a search option and press **ENTER**. With a new location selected, all information shown in the sub tab categories relates to the selected location.*

Forecast

The Forecast sub tab includes two panels that display forecast information for the location selected in the Current sub tab. The top panel displays the high/low temperature, chance of precipitation, and weather condition (cloudy, sunny, thunderstorms). The number of days that appear in this panel depend on the data available from the responding weather service center. If more than four days of forecasts appear, use the **ROCKER** to move down the list.

The bottom panel on the Forecast sub tab features a detailed 24-hour forecast for winds, wind gust, and visibility. In order to see all of this information, use the **ROCKER** key to move down the list. If a condition field is empty, data for that field is not currently available.

Normal Operation

Reference: **Current** **Forecast** Sea Surface Forecast Map Setup

GPS: Kansas City, MO

Tide	11-MAY-05	88°F / 67°F	10%	Partly Cloudy
Celestial	12-MAY-05	82°F / 58°F	40%	Mostly Cloudy
Trip	13-MAY-05	70°F / 51°F	60%	Thunderstorms
Weather	14-MAY-05	70°F / 48°F	20%	Partly Cloudy

Database

Points

Routes

Tracks

DSC

Card

Setup

Alarms

24 hour forecast for: Kansas City Downtown Air, MO

Forecast for:	12:00 ^{PM}	
Winds	077 ^M	10kt
Wind Gust	----kt	
Visibility	5.2nm	
Haze		

The scroll bars indicate that additional information is available. To scroll through the information, highlight the list.

24 hour forecast for: Kansas City Downtown Air, MO

Forecast for:	12:00 ^{PM}	
Winds	167 ^M	12kt
Wind Gust	18.0kt	
Visibility	5.2nm	or more

Changing to at:	06:00 ^{PM}	
Winds	147 ^M	11kt
Wind Gust	----kt	
Visibility	5.2nm	or more

Changing to at:	03:00 ^{AM}	
Winds	147 ^M	11kt
Wind Gust	----kt	
Visibility	5.2nm	or more

Changing to at:	09:00 ^{AM}	
Winds	157 ^M	15kt
Wind Gust	22.0kt	
Visibility	5.2nm	or more

Sea Surface

The Sea Surface sub tab provides weather data of specific importance to mariners. This data comes from a variety of data sources that are nearest to your current or selected location. If a condition field is empty, data for that condition is not currently available.

Normal Operation


Reference

Current
Forecast
Sea Surface
Forecast Map
Setup

GPS	01:00PM 421.6nm 051°M From Current Position		
Tide	Temperature	42°F	
Celestial	Dew Point	41°F	
Trip	Winds	347°M	23kt
Weather	Wind Gust	27.2kt	
Database	Visibility	----nm	
Points	Pressure	30.08in	+0.05in
Routes	Water Temperature	42°F	
Tracks	Waves	4.3ft	00:00:05
DSC	Tide Measurement	----ft	
Card			
Setup			
Alarms			

Forecast Map

The Forecast Map sub tab displays Fronts, High and Low Pressure Centers, and City Conditions. The map zoom range can be changed using the Range keys. There are three icons at the top of the map. These icons are used to show or play the forecast conditions for the next 48 hours.



Setup

The Setup sub tab provides access to the three preset weather displays: General, Sea State, and Storms. The preset weather displays can be customized from this tab. The Setup tab contains a map that displays any changes that are made. Legends for all weather conditions are also shown. For detailed information on customizing the preset weather displays, see the chartplotter's Owner's Manual.

Normal Operation

Reference | Current | Forecast | Sea Surface | Forecast Map | **Setup**

Weather Presets

- GENERAL
- SEA STATE
- STORMS

Legend:

- Pressure: _____
- Visibility: _____
- Temperature: _____
- Wave Height: _____
- Wave Period: _____
- NEXRAD: _____
- Rain: [Color scale] Light Heavy
- Mix: [Color scale]
- Snow: [Color scale]
- Cloud Tops: [Color scale] Low High


Map: GENERAL. Shows a weather map with high (H) and low (L) pressure systems, isobars (e.g., 30.5, 30.3, 30.1, 29.9, 29.7, 29.9), and city names including Hudson Bay, James Bay, Chicago, Minneapolis, St. Louis, St. Paul, Dallas, Dallas, Diamondhead, Monterrey, Mexico City, and Havana.

XM Tab

To display the XM tab, press and hold the **ADJ/MENU** key to display the Menu Menu. Using the **ROCKER**, scroll through the tabs and highlight the XM tab. The XM tab contains two sub tabs, Audio and Information. The Audio sub tab is used to tune and customize the XM Radio feature (only available on GDL 30A). The Information sub tab contains the Radio ID numbers and information about the XM service being received.


Audio (for GDL 30A only)

The Audio sub tab provides access to the XM Radio feature. From this tab, stations can be scanned, selected, and added to a Favorites List. Also, the Audio Output can be turned on and off. If the GDL 30A is properly connected, the Audio Output should be set to On. If CHECK ANTENNA appears in the Tuning field, double-check to make certain the GA 31 antenna has been properly installed and that the audio cable is securely connected to your GDL 30A and to your stereo receiver. For more information on using the XM Radio feature, refer to the chartplotter Owner's Manual.




If your GDL 30A is properly connected, you will see "On" in the Audio Output box and "XM Preview" in the Radio Tuning box.

Audio Tab



Information

The Information sub tab contains the Weather and Audio Radio ID Numbers that are needed to subscribe to XM Service. Your XM Weather Service Level and a list of Weather Products that are being received appear here as well. These weather products determine and display the weather information on the chartplotter.



The Radio ID numbers are required when setting up the XM service. Copy these numbers and have them available before contacting XM.



NOTE: To obtain the XM Weather and Radio IDs from a 4000 or 5000 series chartplotter, select **Configure > System > System Information**.

APPENDIX

Blink Codes

The GDL 30/30A turns on and off when the chartplotter to which it is connected is turned on or off. The two-color (Green/Red) Status LED on the GDL 30/30A indicates the current operational status of the module. Codes are:



Green blinking, on for 1 second, off for 1/2 second (slow blink)

Status: GDL 30/30A is on and is receiving an XM signal.




Red blinking, on for 1/10 second, off for 1/10 second (very fast blink)

Status: System alarm. The display device gives a message indicating the type of failure.



Solid Red (no blink)

Status: Software failure - Call Garmin Product Support.



Status Indicator LED

Weather-Related Broadcast Rates

Feature	Broadcast Rate (minutes)
<i>NEXRAD</i>	5
<i>Cloud Tops</i>	15
<i>Storm Cells</i>	1.25
<i>Lightning</i>	5
<i>Wind</i>	12
<i>Pressure</i>	12
<i>Hurricanes</i>	12
<i>Visibility</i>	12
<i>Fronts</i>	12
<i>Sea Surface Temperature</i>	12
<i>Wave Height</i>	12
<i>Wave Period</i>	12
<i>Wave Direction</i>	12
<i>Current Conditions</i>	12
<i>Forecasts</i>	12
<i>Sea Surface Conditions</i>	12

GDL 30/30A Specifications

Physical

Size:	6 ³ / ₄ " L x 4 ³ / ₄ " W x 2.00" H (17.2 cm x 12.1 cm x 5.1 cm)
Weight:	1.5 lbs. (.680 kg)
Case:	Fully gasketed, high-impact plastic and aluminum alloy, waterproof to IEC 60529 IPX7
Temp Range:	5°F to 158°F (-15°C to 70°C)

Power

Source:	10-35 Vdc
Usage:	18 watts max
Fuse:	AGC/3AG - 2.0 Amp

Data Output

Source:	Proprietary Garmin data format.
---------	---------------------------------

Audio

Output Level:	300mV rms into 47 kohm
Frequency Response:	10-20,000 Hz, ± 1 dB
Harmonic Distortion:	<0.5%



NOTE: When using the Chartplotter and GDL 30/30A on battery power only (engines off) for extended periods of time, be sure there is enough available amperage to run the units for the time period. Running other onboard devices at the same time may lower the available amperage, causing the Chartplotter and/or GDL 30/30A to shut off. Check with your local marine dealer/installer if problems persist.

GA 31 Antenna Specifications

Physical

Size:	3 ⁹ / ₁₆ "D x 4 ¹ / ₄ "H (9.1 cm x 10.8 cm)
Weight:	1.0 lbs. (0.45 kg)
Operating Range:	-40°F to +176°F (-40°C to +80°C)
Waterproof:	-1 meter submersion for 30 minutes IEC 60529 IPX7
Mount Thread Size:	1" diameter at 14 threads/inch
Cable:	Foil-shielded center conductor 18 AWG
Dynamics:	999 knots, 40g

Product Safety and Regulatory Information

The GPS system is operated by the United States government, which is solely responsible for its accuracy and maintenance. The system is subject to changes which could affect the accuracy and performance of all GPS equipment. Although the Garmin GDL 30/30A is a precision electronic NAVigation AID (NAVAID), any NAVAID can be misused or misinterpreted and, therefore, become unsafe.

The electronic chart is an aid to navigation and is designed to facilitate the use of authorized government charts, not replace them. Only official government charts and notices to mariners contain all information needed for safe navigation. As always, the user is responsible for prudent use of this information.

Use the GDL 30/30A at your own risk. To reduce the risk of unsafe operation, carefully review and understand all aspects of this Owner's Manual. If necessary, thoroughly practice operation using the simulator mode prior to actual use.

When in actual use, carefully compare indications from the unit to all available navigation sources, including the information from other NAVAIDs, visual sightings, and charts. For safety, always resolve any discrepancies before continuing navigation.

Weather and Sea Surface information

The GDL 30/30A receives XM Weather Radio data and shows it on your chartplotter. The weather data for each feature comes from reputable weather data centers such as the National Weather Service and the Hydrometeorological Prediction Center. (See the XM WX Satellite Weather Web site at <http://weather.xmradio.com/weather> for more information.) Any weather feature can change in appearance or interpretation if the source that provides the information changes. XM Weather Radio data is broadcast at set rates (see [page 24](#) for all weather-related broadcast rates). For example, NEXRAD Radar data is broadcast at five minute intervals. When the marine network is turned on or when a new feature is selected, the GDL 30/30A has to receive new data before it can be displayed. For this reason you may experience a delay before weather data or a new feature appears on the map.

Caution

IT IS THE USER'S RESPONSIBILITY TO USE THIS PRODUCT PRUDENTLY. THIS PRODUCT IS INTENDED TO BE USED ONLY AS A NAVIGATIONAL AID AND MUST NOT BE USED FOR ANY PURPOSE REQUIRING PRECISE MEASUREMENT OF DIRECTION, DISTANCE, LOCATION, OR TOPOGRAPHY.

Software

Software Versions

The GDL 30/30A is designed to work with software version 2.0 and higher on the GPSMAP 3005C/3006C/3010C. See the chartplotter Owner's Manual for instructions on determining the chartplotter software version. Visit our Web site at www.garmin.com/support/download.jsp for software updates (excluding map data).

Software License Agreement

BY USING THE GDL 30/30A, YOU AGREE TO BE BOUND BY THE TERMS AND CONDITIONS OF THE FOLLOWING SOFTWARE LICENSE AGREEMENT. PLEASE READ THIS AGREEMENT CAREFULLY.

Garmin grants you a limited license to use the software embedded in this device (the "Software") in binary executable form in the normal operation of the product. Title, ownership rights, and intellectual property rights in and to the Software remain in Garmin.

You acknowledge that the Software is the property of Garmin and is protected under the United States of America copyright laws and international copyright treaties. You further acknowledge that the structure, organization, and code of the Software are valuable trade secrets of Garmin and that the Software in source code form remains a valuable trade secret of Garmin. You agree not to decompile, disassemble, modify, reverse assemble, reverse engineer, or reduce to human readable form the Software or any part thereof or create any derivative works based on the Software. You agree not to export or re-export the Software to any country in violation of the export control laws of the United States of America. FCC Compliance



The GDL 30/30A complies with Part 15 of the FCC interference limits for Class B digital devices FOR HOME OR OFFICE USE. These limits are designed to provide more reasonable protection against harmful interference in a residential installation, and are more stringent than "outdoor" requirements.

Operation of this device is subject to the following conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment generates, uses, and can radiate radio frequency energy and may cause harmful interference to radio communications if not installed and used in accordance with the instructions. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The GDL 30/30A does not contain any user-serviceable parts. Repairs should only be made by an authorized Garmin service center. Unauthorized repairs or modifications could result in permanent damage to the equipment, and void your warranty and your authority to operate this device under Part 15 regulations.

Limited Warranty

This Garmin product is warranted to be free from defects in materials or workmanship for one year from the date of purchase. Within this period, Garmin will at its sole option repair or replace any components that fail in normal use. Such repairs or replacement will be made at no charge to the customer for parts or labor, provided that the customer shall be responsible for any transportation cost. This warranty does not cover failures due to abuse, misuse, accident or unauthorized alteration or repairs.

THE WARRANTIES AND REMEDIES CONTAINED HEREIN ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES EXPRESS OR IMPLIED OR STATUTORY, INCLUDING ANY LIABILITY ARISING UNDER ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, STATUTORY OR OTHERWISE. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, WHICH MAY VARY FROM STATE TO STATE.

IN NO EVENT SHALL GARMIN BE LIABLE FOR ANY INCIDENTAL, SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES, WHETHER RESULTING FROM THE USE, MISUSE, OR INABILITY TO USE THIS PRODUCT OR FROM DEFECTS IN THE PRODUCT. Some states do not allow the exclusion of incidental or consequential damages, so the above limitations may not apply to you.

Garmin retains the exclusive right to repair or replace the unit or software or offer a full refund of the purchase price at its sole discretion. SUCH REMEDY SHALL BE YOUR SOLE AND EXCLUSIVE REMEDY FOR ANY BREACH OF WARRANTY.

To obtain warranty service, contact your local Garmin authorized dealer or call Garmin Product Support for shipping instructions and an RMA tracking number. The unit should be securely packed with the tracking number clearly written on

the outside of the package. The unit should then be sent, freight charges prepaid, to any Garmin warranty service station. A copy of the original sales receipt is required as the proof of purchase for warranty repairs.

Online Auction Purchases: Products sold through online auctions are not eligible for rebates or other special offers from Garmin. Online auction confirmations are not accepted for warranty verification. To obtain warranty service, an original or copy of the sales receipt from the original retailer is required. Garmin will not replace missing components from any package purchased through an online auction.

International Purchases: A separate warranty is provided by international distributors for units purchased outside the United States. This warranty is provided by the local in-country distributor and this distributor provides local service for your unit. Distributor warranties are only valid in the area of intended distribution. Units purchased in the United States or Canada must be returned to the Garmin service center in the United Kingdom, the United States, Canada, or Taiwan for service.

The Garmin GDL 30/30A has no user-serviceable parts. Should you ever encounter a problem with your unit, please take it to an authorized Garmin dealer for repairs.

The GDL 30/30A is fastened shut with screws. Any attempt to open the case to change or modify the unit in any way will void your warranty and may result in permanent damage to the equipment.

INDEX

A

atmosphere 10
 audio 22
 audio radio ID number 23

B

blink codes 24
 broadcast rates 24

C

check antenna 22
 city conditions 14
 cloud tops 6
 contact XM satellite radio 2
 current 17
 current submenu tab 17, 20
 customizing the preset weather displays 4

F

FCC 27
 forecast 18
 forecast map 20
 forecast submenu tab 18
 fronts 13
 fronts map 13

H

high pressure center 13
 hurricanes 9
 hurricanes map 9

I

introduction i
 isobars 11

L

legend 21
 lightning 8
 lightning bolt icons 8
 low pressure center 13

M

main menu 17

N

NEXRAD 5

P

packing list 1
 precipitation 5
 preset weather displays 3
 pressure 11
 pressure gradient 11
 pressure map 11
 product safety 26

S

sea surface 15, 19
 sea surface maps
 Wave Height 15
 sea surface submenu tab 19
 sea surface temperature 15
 selecting a preset weather display 3
 service level 23
 setup 21
 set up the XM account 2
 software license agreement 27
 software versions 27
 specifications 25
 storm cells 6

V

visibility 12

W

warranty 28
 wave direction 16
 wave height 15
 wave height map 15
 wave period 16
 weather features 5
 weather ID number 23
 weather maps
 Fronts 13
 Hurricanes 9
 Pressure 11

weather products 23
 Weather tab 17, 22
 weather tab 17
 wind 10
 wind barb 10
 wind speed 10

X

XM radio 2, 22
 XM tab 22
 XM weather/radio
 800 number 2
 XM WX weather 2

**For the latest free software updates (excluding map data) throughout the life of your
Garmin products, visit the Garmin Web site at www.garmin.com.**



© 2005-8 Garmin Ltd. or its subsidiaries

Garmin International, Inc.
1200 East 151st Street, Olathe, Kansas 66062, USA

Garmin (Europe) Ltd.
Liberty House, Hounsdown Business Park, Southampton, Hampshire, SO40 9RB UK

Garmin Corporation
No. 68, Jangshu 2nd Road, Shijr, Taipei County, Taiwan

www.garmin.com

Part Number 190-00336-00 Rev. F