



FitPlan Go for Android User's Guide



Blank Page

**FltPlan Account**

**Airports**

**Maps**

**NavLogs**

**External**

**Checklists**

**Binders**

**Weather**

**Flight Tracking**

**Tools**

**Scratch Pad**

**Downloads**

**Settings**

**Index**

Blank Page

© 2022 Garmin Ltd. or its subsidiaries. All rights reserved.

This manual reflects the operation of the current FltPlan System, including FltPlan Go. Some differences in operation may be observed when comparing the information in this manual to earlier or later versions.

Garmin International, Inc., 1200 East 151st Street, Olathe, Kansas 66062, U.S.A.

Garmin AT, Inc., 2345 Turner Road SE, Salem, OR 97302, U.S.A.

Garmin (Europe) Ltd., Liberty House, Hounsdown Business Park, Southampton, Hampshire SO40 9LR U.K.

Garmin Corporation, No. 68, Zhangshu 2nd Road, Xizhi District, New Taipei City, Taiwan

Web Site Address: [flygarmin.com](http://flygarmin.com)

Except as expressly provided herein, no part of this manual may be reproduced, copied, transmitted, disseminated, downloaded or stored in any storage medium, for any purpose without the express written permission of Garmin. Garmin hereby grants permission to download a single copy of this manual and of any revision to this manual onto a hard drive or other electronic storage medium to be viewed for personal use, provided that such electronic or printed copy of this manual or revision must contain the complete text of this copyright notice and provided further that any unauthorized commercial distribution of this manual or any revision hereto is strictly prohibited.

Garmin® is a registered trademark of Garmin Ltd. or its subsidiaries. This trademark may not be used without the express permission of Garmin.

Rev	Date	Description
A	June, 2022	Production Release.

**FLTPLAN ACCOUNT**

Register FltPlan.com Account.....3  
 Request Permission to File Flight Plans .....3  
 Pre-Flight Device .....4  
 FltPlan Go Sign-In.....4  
 Pre-Flight Device .....4  
 FltPlan Go Sign-In.....4  
 Home Menu .....6  
     Home Menu Icons .....6

**AIRPORTS**

Header Menu.....8  
     History .....8  
     Favorites .....9  
     View on Map.....9  
     Search Airports.....9  
     Runway Wind Calculator.....11  
     Airports Near Me .....13  
     Add To Binders .....14  
     Airport Diagram .....14  
     FBOs .....19  
     Information .....20  
     Frequencies .....21  
     Runways .....22  
     Procedures .....22  
     Weather .....24  
     MOS.....25  
     NOTAMs.....26  
     Remarks .....27  
     View In Browser.....27

**MAPS**

Header Menu.....29  
     Airports Near Me .....29  
     Map Options .....30  
     Split Screen .....35  
     Zoom .....37  
     Connectivity.....37  
     My Routes.....38  
     Distance Measuring Tool .....40  
     Timer.....41  
     Account.....41  
     Layers.....41  
     Route .....50  
     Edit .....51  
     METARs.....65  
     MOS.....66  
     Winds.....68  
     Weather (WX) .....70  
     XM (Optional) .....72

ADS-B .....72  
 Head-Up Display (HUD).....74  
 Auto Center .....74

**NAVLOGS**

NavLog Options .....76  
 Split Screen Options.....76  
 My NavLogs/WX .....81  
 NavLog Information.....82  
 Auto Syncing NavLogs .....89

**EXTERNAL**

Internal Devices .....92  
 External Devices.....92  
 Simulators.....93

**CHECKLISTS**

Checklist for Aircraft .....95  
     Checking Off Items.....95  
     Skipping Items .....95  
     Text to Speech.....96  
     Reset List .....96  
     Creating Checklist on FltPlan.com .....97

**BINDERS**

Adding New Binder .....106  
 Edit Binders .....107  
     Renaming or Deleting Binders .....107  
     Adding To Binders .....107  
     My Documents.....109  
     Add File to My Documents .....110  
     Filter My Documents .....111  
     Viewing Binder Files.....111  
     Uploading Files to FltPlan Go.....111

**WEATHER**

Refresh Data .....113  
 My Airports / Routes.....113

**FLIGHT TRACKING**

Refresh Data .....115  
 My Aircraft.....115  
 Flight Tracking Map .....116  
     Switching Aircraft.....116  
     Map Options .....117

**TOOLS**

Tools.....119  
     Pre-Departure Clearance (PDC) Service.....120  
     eLogbook .....121  
     Cloud Tops .....125  
     Weight & Balance .....125

Contacts.....	129
<b>Calculators.....</b>	<b>130</b>
Numeric .....	130
Fahrenheit/Celsius Temperature Conversion.....	130
ISA Temperature Conversion .....	131
Density Altitude.....	132
Fuel Conversion .....	134
Equal Time Point .....	136
Runway Winds .....	137
Airport Winds.....	139

---

**SCRATCH PAD**

---

My Doodles.....	140
-----------------	-----

---

**DOWNLOADS**

---

<b>Failed Downloads .....</b>	<b>143</b>
<b>Update All.....</b>	<b>143</b>
<b>Cancel All.....</b>	<b>144</b>
<b>Delete .....</b>	<b>144</b>
Maps.....	145
Procedures .....	148
Documents.....	150
A/FD.....	151
Miscellaneous .....	152

---

**SETTINGS**

---

Toggle Sleep Mode.....	153
Enable Night Mode .....	153
Toggle Background GPS .....	153
Minimum Runway Length (ft) .....	153
Receive Notifications .....	153
Email Support .....	153
Messages From FltPlan.com.....	153
Privacy Policy .....	154
Help Guide & Tutorial .....	154
Open Source Licenses .....	154
App Version.....	154

---

**INDEX**

---

<b>Index.....</b>	<b>Index-1</b>
-------------------	----------------

The FltPlan Go app is a companion to the [FltPlan](#) website. If you are not a registered user for [FltPlan](#), please complete the following steps prior to using the FltPlan Go app:

## REGISTER FLTPLAN.COM ACCOUNT

To create your free account, go to [www.FltPlan.com](http://www.FltPlan.com) and click the **Create Account** link at the top of the FltPlan Welcome page. Create your username and password on the **New Registration** page.



**NOTE:** *Usernames and passwords must be between 8 and 64 characters, contain one uppercase, one lowercase, and one special character.*



**NOTE:** *You must complete your username and password and accept the FltPlan disclaimer before you can advance to the registration form.*

Enter all pertinent information on the registration form in order to file IFR and VFR flight plans. You must enter your name in one of the PIC name slots. You can enter up to ten (10) different PIC names and ten (10) different aircraft registration numbers. Performance data is supplied for a variety of aircraft types. You can use the generic performance data provided for your aircraft, or customize it to match the way you fly. For more information on entering and editing performance data for your aircraft, refer to the [FltPlan.com User Tutorial](#).

Once you complete the registration form, you will arrive at the **Main Menu** page. FltPlan allows you to create and store IFR flight plans up to 180 days in advance.



**NOTE:** *Flight plans can only be created, stored, and filed if you have entered all of the pertinent info on the Pilot/User Info page and have entered at least one aircraft into your account*



**NOTE:** *FltPlan can be used by anyone to file an IFR or VFR flight plan, but you must be a pilot with a current aviation certificate and aviation medical.*

## REQUEST PERMISSION TO FILE FLIGHT PLANS

The following steps must be completed prior to creating and filing flight plans:

### Check the accuracy of your PIC/User Info:

- 1) From the FltPlan.com Main Page, select **Main Menu > Settings > User/Pilot Info**.
- 2) Enter First & Last Name, Complete Address, Aircraft Home Base, Phone Number, and Email.
- 3) Check the box that says "I give FltPlan.com authorization to file flight plans on my behalf."
- 4) Once the authorization request is received and processed, FltPlan will send instructions via email regarding account activation.



**NOTE:** *FltPlan.com will NOT file your flight plans if the required information is incomplete, or the authorization box is not checked.*



**NOTE:** *For Corporate email account users, please make sure that all FltPlan email addresses, [Info@FltPlan2.com](mailto:Info@FltPlan2.com), [Info@FltPlan.com](mailto:Info@FltPlan.com), and [FltPlan.Support@garmin.com](mailto:FltPlan.Support@garmin.com), are white listed to ensure these emails are not identified as SPAM.*

### Watch Help Videos:

- 1) [How to Create a Flight Plan](#).
- 2) Additional videos are available on the [Video Support Page](#).

## PRE-FLIGHT DEVICE

Make the most of what FltPlan Go has to offer, and download/update the following information from FltPlan before departure:

- NavLogs
- Charts & Maps
- Airport & FBO Information
- Trip-related Documents
- Create/Edit Checklists
- Update/Calculate Weight & Balance Information

## FLTPLAN GO SIGN-IN

Now that a FltPlan.com account has been established and verified, the next step is to download the FltPlan Go app from the appropriate app store supported by the device being used for flight. With the FltPlan Go app running, sign into your FltPlan.com account:

### Signing Into FltPlan.com on FltPlan Go app:

- 1) Within the FltPlan Go app, select the **FltPlan.com** icon on the lefthand menu.
- 2) Tap the **Sign In** button in the top right corner.
- 3) Enter User Name and Password > **Sign In**.

**Or:** If you do not already have a FltPlan.com account, tap the **Create Your Account** button to register via the instructions listed earlier in this document.

Touch to Move  
'Forward' & 'Back'

Touch to Refresh  
Touch to View 'Home' Page

Touch to View

Touch to Add  
Account or Logout  
Touch to Create  
Flight Plan  
Touch to Exit App &  
View in Web Browser

FitPlan.com

CE-680 Sovereign PIC  
Earn over \$180K!

ETE	Call Sign	PIC/SIC	Quick Change/Modify	Display NavLog	File	Messages	FBO Brief	FRAT	EDCT	Notes
1:02	N2345B	Joe P/-	QC	NavLog	Exp.	-		Needs Updating		add notes
0:44	N2345B	Joe P/-	QC	NavLog	Exp.	-		Needs Updating		add notes
1:31	N2345B	Joe P/Test	QC	NavLog	Exp.	-				add notes
3:00	N2345B	Joe P/-	QC	NavLog	Exp.	-				add notes
1:31	N2345B	Joe P/-	QC	NavLog	Exp.	-				add notes
1:07	N2345B	Joe P/Test	QC	NavLog	Exp.	-				add notes
1:10	N2345B	Joe P/-	QC	NavLog	Exp.	-				add notes
0:07	N2345B	Josh /-	QC	NavLog	Exp. VFR Flight Plan	-				add notes
3:44	N2345B	Joe P/-	QC	NavLog	Exp.	-				add notes
1:01	N2345B	Joe P/-	QC	NavLog	Exp.	-				add notes
1:07	N2345B	Joe P/-	QC	NavLog	Exp.	-				add notes
4:32	TBRVGGM	Joe P/-	QC	NavLog	Exp. ICAO Equipment Mismatch - Error #2	-				add notes
1:04	N2345B	Joe P/-	QC	NavLog	Exp.	-				add notes
0:58	N2345B	Joe P/-	QC	NavLog	Exp.	-				add notes

ir PDCs Here!  
pilots of Jet & Turbo Props  
equipped with a datalink box.

LEARN MORE

6 Weeks  
7 Weeks  
3 Months  
4 Months  
5 Months  
6 Months  
1 Year

Create/Update a Web Page with your Schedule  
2 weeks 4 weeks 7 weeks 3 Months 4 Months 5 Months  
6 Months 1 Year

Calendar Title:  
Flight Schedule

Display Flight Schedule in Calendar Format

Touch to  
Hide/View  
Main Menu

Touch to Use  
Stylus/Pen


FitPlan Go - FitPlan.com Page

## HOME MENU

The Home Menu, positioned along the left-hand side of the screen, is the primary means of accessing many of the features of FltPlan Go. The Home Menu provides quick access to the various pages within

### HOME MENU ICONS

	FltPlan.com	Displays FltPlan.com information for flight plans after linking and syncing your FltPlan.com credentials.
	Airports	Displays the Airport Information Page, which includes basic airport info, frequencies, runways, procedures, weather, NOTAM's, FBO's, fuel prices/fees, FAA remarks, & Nav Aids.
	Maps	Displays the aircraft on a georeferenced map with various overlays and layers of information.
	NavLogs	Displays NavLog Options, Split Screen Options, Share/Save Options, Connectivity, My NavLogs/WX, and different NavLog format options, e.g. Web or PDF.
	External	Displays the External Devices Page, which allows the wireless sharing of data between devices via Bluetooth®, or, if properly equipped, Wi-Fi.
	Checklist	Displays the Checklist Page where specific aircraft electronic checklists can be viewed to ensure proper flight procedures.
	Binders	Displays flight specific binders with customized information related to many items, including documents, procedures, airports, NavLogs, and weather.
	Weather	Displays the Weather Imagery Page, providing various meteorological data for both real-time and forecast weather events.
	Tracking	Displays the available aircraft ID's the active User set-up for flight tracking.
	Tools	Displays two groups of icons, Tools & Calculators. Tools listed include eLogbook, PDC Service, Cloud Tops, Weight & Balance, Contacts. Calculators listed include Numeric, Celcius to Fahrenheit, Temperature, Density Altitude, Conversions, Equal Time, Winds, and Airport Winds.
	Scratch Pad	Displays the Scratch Pad Page, which allows the pilot to quickly draw or write down information on the device screen.
	Downloads	Displays the Downloads Page, where the User can download and update various charts for offline use. Available charts include Maps, Procedures, Documents, A/FD and Miscellaneous.
	Settings	Displays the Settings Page, where the User can adjust how the device interacts with the FltPlan Go program, such as Tutorial, Support, Current User, Allow Sleep Mode, Screen Brightness, Super Dim, Allow GPS in Background, Minimum Runway Length (ft), Show Notification Alert, Messages From FltPlan, Privacy Policy, App Version, Refresh Database, Lock Screen, Clear Cache, Turn Off Map Layers, and Unregister From Notifications.
<b>Home Menu Icons</b>		



Selecting the Airports icon from the Home Menu will display various details related to the desired airport, which include FBO's, Airport Information, Frequencies, Runways, Procedures, Weather, Model Output Statistics (MOS), NOTAMs, Fuel Services/Information, and Remarks (Traffic Pattern, After Hours Phone Number(s), etc.).

**TETERBORO**  
TETERBORO, NJ  
N40°51.0' W074°03.7'

**FBOs** (Current Selection)

- Information
- Frequencies
- Runways
- Procedures
- Weather
- MOS
- NOTAMs
- Remarks

**MERIDIAN TEB**

Phone: 201-288-5040  
Freq: 131.52

Services About

PRIOR ARRIVAL NOTICE IS RECOMMENDED. Jet A & Avgas Quick Turns, Complimentary GPU, Lav & Water Services, Vacuum, Hangar and ramp parking, Pilot Lounge, Sleep Room, Locker Room & Showers, Crew Cars, Home Theater, Executive Passenger Lounge, Conference Rooms, Gym, Rental car/Limo service on premises, Pilot Lunch Room & Vending Machines, Complimentary Coffee, Ice & Newspapers.  
**Address:** 485 INDUSTRIAL AVE TETERBORO, NJ 07608

Service	Jet	100LL	SAF	MoGas
Full	9.31	7.40		
Self				

Fuel avail: 24/7 Jet A w/prist + \$0.07

Misc info: All props receive first night free with fuel. All jets receive first 2 nights free with fuel.

VIEW IN WEB BROWSER

Touch to Hide/View Main Menu


Touch to View Info

Touch to View Info in Browser via FltPlan.com

- FitPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

## HEADER MENU

The Header Menu is customized for each section (e.g. Airports, Maps, NavLogs, etc.) and contains various buttons to help the User navigate the FltPlan Go program quickly. In the Airports section, the available buttons include History, Favorites, View on Map, Share and/or Save Airports, Runway Wind Calculator, Airports Near Current Location, Add and/or View Binder(s), Airport Diagram, Airports Near Current Selection, and the Airport/Facility Directory (A/FD).



FltPlan Go - Airports Page - Header Menu

## HISTORY

### Viewing Airport History:

- 1) Touch  within the Airports section to display a menu listing the recent airports searched/used.
- 2) Select the desired airport to view information.



FltPlan Go - Airports Page - History Menu

### Deleting Airport History:

- 1) Touch  within the Airports section to display a menu listing the recent airports searched/used.
- 2) Long press on the desired airport to display a confirmation window asking to remove the airport from History.
- 3) Touch **Yes** to delete the airport.



**NOTE:** The History drop-down menu holds a maximum of 15 airports. When adding more than 15 airports to the list, the old airport(s) will be deleted to allow room for the new airport(s).


### FAVORITES

#### Viewing Favorite Airports:

- 1) Touch  within the Airports section to display a drop-down menu listing User defined favorites.
- 2) Select the desired airport.

#### Adding Favorite Airport:

- 1) Touch  within the Airports section to display a drop-down menu listing User defined favorites.
- 2) Touch '+' to add the current airport to Favorites.



### VIEW ON MAP

Touch  within the Airports section to view the airport on the Map.




**NOTE:** Online Maps are available for preflight planning when properly connected to Wi-Fi. To ensure the desired Maps will be available during flight, please download Maps to the device prior to departure.

### SEARCH AIRPORTS

The next button located in the center of the Header Menu is Search Airports, where the current four letter airport identifier will be displayed (KXXX). Touch  to display a drop-down menu with a search bar that sorts the data into three main groups, United States (U.S.), Canada, and Other. The U.S. group lists the airports in alphabetical order by State (e.g. Alabama, California, Delaware, Washington, etc.). The Canada group lists the airports in alphabetical order by Province (e.g. Alberta, Ontario, Quebec, Yukon, etc.). The Other group lists the airports in alphabetical order by Country (e.g. Bahamas, Guatemala, Mexico, Venezuela, etc.).

Touch within the Search Bar to manually enter text for an airport I.D. (e.g. TJIG, CYQA, KTEB), then select the desired airport to view the corresponding airport information.

- FitPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index



FltPlan Go - Airports Page - Search Airports - U.S.


## RUNWAY WIND CALCULATOR

The next button located in the Header Menu of the Airports Page is the Runway Wind Calculator. Touch **WIND CALC.** to display the Runway Wind Calculator page, where the appropriate runway, ref speed, target speed, and wind data can be entered and calculated. To set specific User Preferences related to Tailwind Caution, Tailwind Limit, X-Wind Caution, X-Wind Limit, Target Speed, Steady State Wind calculation, and Headwind calculation. Once the Preferences are set, the Wind Calculator will display the applicable annunciators when/if these limitations are exceeded.

On the top of the page, the Headwind (Knots) and X-Wind (Knots) component will auto-fill as data is entered/adjusted. If wind gusts are entered, the Headwind and X-Wind numbers will 'flash' between the steady/constant wind component and the wind gust component. On the runway picture below the calculator, a blue arrow depicts the direction of the wind in relation to the selected runway and will change as data is entered/adjusted.

### Entering/Adjusting Wind Calculator Preferences:

- 1) Touch **WIND CALC.** within the Airports section > **Preferences.**
- 2) Touch the desired text box and enter wind velocity (knots) and Target Speed preferences/limitations.
- 3) Touch **Steady State Wind** or **Head Wind Comp** to enter calculation(s).
- 4) Touch '-' or '+' to adjust percentage calculation(s) for Steady State Wind or Head Wind Comp, as desired.
- 5) Touch anywhere outside the Preferences dialogue box to exit, or touch the **Close** button to exit.



FltPlan Go - Airports Page - Runway Wind Calculator - Preferences Menu

**Entering/Adjusting Wind Information:**

- 1) Touch **WIND CALC.** within the Airports section.
- 2) Select the Desired Runway.
- 3) Adjust the Slider to the desired number for **Wind From** (Radial Measure in Degrees, e.g. 090 = From the East, 180 = From the South, etc.). Touch '-' or '+' to make small adjustments.
- 4) Adjust the Slider to the desired number for **Wind Speed** (Knots). Touch '-' or '+' to make small adjustments.
- 5) If necessary, adjust the Slider to the desired number for **Wind Gusts** (Knots). Touch '-' or '+' to make small adjustments.
- 6) If necessary, touch within the 'Ref Speed' box to enter the desired number (Knots). Touch '-' or '+' to make small adjustments. The **Target Speed** will autocalculate as data is entered/adjusted.
- 7) Touch the **Back** button to exit and return to the previous page.

The screenshot shows the Runway Wind Calculator interface for airport KTEB. The interface includes several key components:

- Change airport:** A button at the top left to switch airports.
- Preferences:** A button at the top right to access settings.
- HEAD WIND:** A section showing a headwind component of G25.1 and a crosswind component of G14.5. A vertical orange bar labeled 'X W I N D' indicates the crosswind level.
- Runway Number:** A list of runways (01, 19, 06, 24) with status indicators (X, !, X, X). Runway 19 is selected and highlighted in green.
- Wind From:** A slider set to 160 degrees, with a scale from 010 to 360.
- Wind Speed (knots):** A slider set to 21 knots, with a scale from 0 to 50.
- Gusting to (knots):** A slider set to 29 knots, with a scale from 0 to 50. Below the slider is the text 'Adjust wind speed to turn off gusting wind'.
- Ref Speed:** A box showing a reference speed of 106 knots.
- Target Speed:** A box showing a target speed of 134 knots.
- Relative Wind & Runway:** A circular gauge at the bottom left showing the relative wind direction and runway alignment.

Annotations on the left side of the image include: 'Touch to Change Airport', 'Headwind Component', 'Unfavorable Runway(s)', 'Selected Runway Used for Calculation', 'Slide to Adjust', and 'Relative Wind & Runway'. Annotations on the right side include: 'Touch to View/Edit Preferences', 'Crosswind Component', 'Touch -/+ to Adjust', 'Caution & Limit Exceeded Annunciator(s)', and 'Touch -/+ to Adjust'.

FltPlan Go - Airports Page - Runway Wind Calculator

## AIRPORTS NEAR ME

The next button located in the Header Menu of the Airports Page is Airports Near Me. Touch  to view a menu of airports near the current location of the device, listed from nearest to furthest. Touch the desired airport from the list to view the applicable airport information.



**NOTE:** Location Services must be enabled on the device in order to accurately display Airports Near Me. Most devices list Location Services under Settings > Privacy.

### Viewing Airports Near Me:

- 1) Touch  within the Airports section.
- 2) Touch desired airport from the list to view additional Airport Information.

Nearby Me	
KOJC, JOHNSON COUNTY EXECUTIVE OLATHE, KS (RWY: 4097 ft) Dist. 3 NM	Distance From Airport
KIXD, NEW CENTURY AIRCENTER OLATHE, KS (RWY: 7339 ft) Dist. 4 NM	Longest Runway
K51K, CEDAR AIR PARK OLATHE, KS (RWY: 2440 ft) Dist. 6 NM	City, State
KK34, GARDNER MUNI GARDNER, KS (RWY: 3224 ft) Dist. 8 NM	
69KS, CHILES AIRPARK (PRIVATE) CHILES, KS (RWY: 2600 ft) Dist. 12 NM	
52KS, BLAND (PRIVATE) EUDORA, KS (RWY: 1800 ft) Dist. 16 NM	
75MO, CHILDRENS MERCY HOSPITAL HLPRT KANSAS CITY, MO (RWY: 0 ft) Dist. 17 NM	
3MO1, POLICE DEPT HELIPORT (PVT) KANSAS CITY, MO (RWY: 0 ft) Dist. 18 NM	
KMKC, CHARLES B. WHEELER DOWNTOWN KANSAS CITY, MO (RWY: 6827 ft) Dist. 19 NM	
KK81, MIAMI COUNTY PAOLA, KS (RWY: 3398 ft) Dist. 20 NM	

Touch to View Airport Info

FltPlan Go - Airports Page - Airports Near Me

## ADD TO BINDERS


The last button located in the Header Menu of the Airports Page is Add to Binders. Touch  to view a menu of Binders. Touch **Add** in the lower right corner to add the current airport to a Binder, which can be found quickly by pressing the Binders icon on the Main Menu.

### Adding Airport to Binder:

- 1) Touch  within the Airports section.
- 2) Touch the desired binder location where the current airport information will be saved.

### Creating New Binder:

- 1) Touch  within the Airports section > 'Add'.
- 2) Enter the Binder name in the text box > **Done** to save or **Cancel** to close without saving.



FltPlan Go - Airports Page - Binders Menu

## AIRPORT DIAGRAM

In the Airports section, directly below the top line of the Header Menu, the next group of buttons listed allow the User quick access to important information. One of the buttons is Airport Diagram, which will display a full-screen airport diagram if there is an FAA approved chart.

Touch the **Airport Diagram** button within the Airports section to view.



FltPlan Go - Airports Page - Info Buttons



When the Airport Diagram page is displayed, there will be a customized Banner Menu with quick access buttons that allow the User to efficiently navigate the FltPlan Go program.



FltPlan Go - Airports Page - Airport Diagram - Banner Menu

## ENABLE SHIP

Touch the **Enable Ship** button to view your aircraft on the Chart.



**NOTE:** A GPS signal is required to view Aircraft position on the Chart.

## BREADCRUMBS

Touch the **Breadcrumbs** button to display a green line that represents the actual GPS route taken by the aircraft.


## ZULU TIME

Touch the **Zulu Time** button to display the Timestamp in Local (L) or Zulu (Z) format, then longpress on the Airport Diagram in the desired location to create a timestamp.

## TIMER



Touch  to view the Timer. Touch **Start** to begin the Timer, **Stop** when desired, and then **Reset** to begin from zero. Touch the 'X' to close the Timer.




FltPlan Go - Airports Page - Airport Diagram - Timer

## ANNOTATE




Touch  to view the Annotate options. Touch **Color** to select the color of the penstroke, e.g. Black, Red, Blue, Green, Yellow, etc. Touch **Width** to select the size of the penstroke. Touch the **Undo** arrow to remove the most recent annotation. Touch the **Paintbrush** to annotate, as desired. Touch the **Pencil** to draw freehand. Touch the 'Square' icon to create a square shaped annotation. Touch the 'Circle' icon to create a circular annotation. Touch the 'Save' icon to save the most recent annotation(s). Touch **Done** to exit the annotate process.



FltPlan Go - Airports Page - Airport Diagram - Annotate Icons

Touch to Adjust Penstroke Touch to Exit



Save Undo Select Shape Paint Draw

FitPlan Go - Airports Page - Airport Diagram - Annotate

- FitPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index


## LOCK SCREEN

Touch  to lock the screen orientation on the device. When the screen orientation is locked, the padlock icon will change to red.

Touch  to unlock the screen orientation. The ability to Zoom In/Out and Annotate are not available when the screen orientation is locked.

## PRINT


Touch  to Print and/or view Printer Options. Touch **Select Printer** to view previous and/or available printer options. Once a Printer has been selected, enter the desired number of **Copies**, select the **Paper Size**, **Color**, **Orientation**, **Double-sided**, and **Pages**, then touch **Print**. Touch 'PDF' to download the file as a pdf which will be saved to the device and should be available for offline viewing. Touch the back button to exit.



FltPlan Go - Airports Page - Print Options

## EMAIL/SHARE

Touch  within the Airports section to display a menu listing available sharing and/or storage options (e.g. Chrome, Nearby Share, Drive, Quick Share, Gmail, etc.).



FltPlan Go - NavLogs - Share/Save Menu

## ROTATE IMAGE

Touch  to rotate the image 90° clockwise.

### FBOs

Located on the left side of the Airports section is a list of tabs that sort features/information associated with the selected airport. The first tab on the list is FBOs. Touch the **FBO** Tab to view all available FBOs. If there are multiple FBOs on the field, scroll right/left to view additional FBOs. Select the **Services** button to view car services, fuel prices, contact info, etc. Select the **About** button to view various details about the FBO, such as ammenities, mailing address, pilot/fuel rewards, etc.

**TETERBORO**  
TETERBORO, NJ  
N40°51.0' W074°03.7'

**FBOs** | MERIDIAN TEB | JET AVIATION

**MERIDIAN TEB**  
Phone: 201-288-5040  
Freq: 131.52

Services | **About**

PRIOR ARRIVAL NOTICE IS RECOMMENDED. Jet A & Avgas Quick Turns, Complimentary GPU, Lav & Water Services, Vacuum, Hangar and ramp parking, Pilot Lounge, Sleep Room, Locker Room & Showers, Crew Cars, Home Theater, Executive Passenger Lounge, Conference Rooms, Gym, Rental car/Limo service on premises, Pilot Lunch Room & Vending Machines, Complimentary Coffee, Ice & Newspapers.  
**Address:** 485 INDUSTRIAL AVE TETERBORO, NJ 07608

Service	Jet	100LL	SAF	MoGas
Full	9.31	7.40		
Self				

Fuel avail: 24/7 Jet A w/prist + \$0.07  
Misc info: All props receive first night free with fuel. All jets receive first 2 nights free with fuel.

FltPlan Go - Airports Page - FBOs

## INFORMATION

Located on the left side of the Airports section is a list of tabs that sort features/information associated with the selected airport. The second tab on the list is Information. Touch the **Information** Tab to view whether or not the airport is an Airport of Entry (AOE), Airport Elevation (also known as Field Elevation, Runway Elevation, Aerodrome Elevation, Airport Height), Fuel Available (Jet and/or AVGAS), Latitude and Longitude coordinates, Time Zone, and Magnetic Variation.

KTEB

WIND CALC.

### TETERBORO

TETERBORO, NJ  
N40°51.0' W074°03.7'

AIRPORT DIAGRAM

NEARBY AIRPORTS

OPEN A/FD

FBOs >

Information >

Frequencies >

Runways >

Procedures >

Weather >

MOS >

NOTAMs >

Remarks >

AOE	Yes
Elevation	8.0
Fuel Available	JET/AVGAS
Latitude	40.85
Longitude	-74.06
Timezone	EASTERN / UTC -5 (-4)
Variation	12.0

Touch to View

FltPlan Go - Airports Page - Information

190-02961-00 Rev A

FltPlan Go for Android User's Guide

20

### FREQUENCIES

Located on the left side of the Airports section is a list of tabs that sort features/information associated with the selected airport. The third tab on the list is Frequencies. Touch the **Frequencies** Tab to view all available frequencies, such as Clearance, ATIS, ASOS/AWOS, Ground, Tower, and CTAF.

🕒
★
📍

KTEB

WIND CALC.
📍
📁

### TETERBORO

TETERBORO, NJ  
N40°51.0' W074°03.7'

AIRPORT DIAGRAM

NEARBY AIRPORTS

OPEN A/FD

FBOs >

Information >

Frequencies >

Runways >

Procedures >

Weather >

MOS >

NOTAMs >

Remarks >

Clearance	128.05
Arrival ATIS	114.2/132.85
Departure ATIS	114.2
Ground	121.9
Tower	119.5/125.1

Touch to View

FltPlan Go - Airports Page - Frequencies

- FitPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

190-02961-00 Rev A

FltPlan Go for Android User's Guide

21

## RUNWAYS

Located on the left side of the Airports section is a list of tabs that sort features/information associated with the selected airport. The fourth tab on the list is Runways. Touch the **Runways** Tab to view the runway I.D., length, and width, e.g. 01/19 is 7000' (length) x 150' (width).

The screenshot shows the FltPlan Go app interface for Teterboro Airport (KTEB). The top bar includes navigation icons (back, star, location), the airport code 'KTEB', and a 'WIND CALC.' button. Below the top bar is a map of the airport and its name 'TETERBORO' with coordinates 'TETERBORO, NJ N40°51.0' W074°03.7'. To the right of the map are three buttons: 'AIRPORT DIAGRAM', 'NEARBY AIRPORTS', and 'OPEN A/FD'. A left sidebar contains various menu items, with 'Runways' highlighted. A line points from the text 'Touch to View' to the 'Runways' tab. The main content area shows a table of runways:

FBOs	06/24	6013 x 150
Information	01/19	7000 x 150
Frequencies		
<b>Runways</b>		
Procedures		
Weather		
MOS		
NOTAMs		
Remarks		

FltPlan Go - Airports Page - Runways

## PROCEDURES

Located on the left side of the Airports section is a list of tabs that sort features/information associated with the selected airport. The fifth tab on the list is Procedures. Touch the **Procedures** Tab to view filtered information in four categories, Airport, Instrument Approaches, STARS (Arrivals), and DP/SID Departures. Touch the **Download All** button to download all available procedrues for the selected airport. Touch the desired procedure to view, then the Back button to return.

The first section lists information such as Airport Diagram, Hot Spot(s), Takeoff Minimums, Diverse Vector Area, Alternate Minimums, etc. Instrument Approaches lists all precision and non-precision approaches. Standard Arrival Procedures (STARS) lists all available Arrivals. DP/SID Departures lists all available Standard Instrument Departures (SIDs) / Departure Procedures (DP). If a document is geo-referenced, a purple arrow will be displayed. If a document is downloaded, a green check mark will be displayed.

🔄
★
📍

KTEB

WIND CALC.

📍
📁



### TETERBORO

TETERBORO, NJ  
N40°51.0' W074°03.7'

AIRPORT DIAGRAM

NEARBY AIRPORTS

OPEN A/FD

FBOs >

DOWNLOAD ALL

Touch to Download All Procedures

Information >	AIRPORT DIAGRAM <span style="float: right; color: green;">✔</span>	Successfully Downloaded	
Frequencies >	TAKEOFF MINIMUMS <span style="float: right; color: green;">✔</span>		
Runways >	ALTERNATE MINIMUMS <span style="float: right; color: green;">✔</span>		
Procedures >	LAHSO <span style="float: right; color: green;">✔</span>		
Weather >	HOT SPOT <span style="float: right; color: green;">✔</span>		
MOS >			
NOTAMs >	<b>Instrument Approaches (13)</b>	Geo-referenced Chart Available	
Remarks >	ILS OR LOC RWY 06 <span style="float: right; color: green;">✔</span>		
	ILS OR LOC RWY 19 <span style="float: right; color: green;">✔</span>		
	RNAV (RNP) Z RWY 06 <span style="float: right; color: green;">✔</span>		
	RNAV (RNP) Z RWY 19 <span style="float: right; color: green;">✔</span>		
	RNAV (GPS) RWY 24 <span style="float: right; color: green;">✔</span>		
	RNAV (GPS) X RWY 06 <span style="float: right; color: green;">✔</span>		Touch to View
	RNAV (GPS) X RWY 19 <span style="float: right; color: green;">✔</span>		
	RNAV (GPS) Y RWY 06 <span style="float: right; color: green;">✔</span>		
	RNAV (GPS) Y RWY 19 <span style="float: right; color: green;">✔</span>		
	VOR/DME RWY 06 <span style="float: right; color: green;">✔</span>		
	VOR/DME-B <span style="float: right; color: green;">✔</span>		Scroll to View Additional Info

VIEW IN WEB BROWSER

Touch to View

Touch to View Info in Browser via FltPlan.com

FltPlan Go - Airports Page - Procedures

- FitPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

## WEATHER

Located on the left side of the Airports section is a list of tabs that sort features/information associated with the selected airport. The sixth tab on the list is Weather. Touch the **Weather** Tab to view METARs, Nearby Departure Airport METARs, Terminal Forecasts, and PIREPs. Touch the Refresh button update weather information. A timestamp will appear on the top of the screen indicating the date and time of the most recent refresh.

- FltPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

KTEB

WIND CALC.

### TETERBORO

TETERBORO, NJ  
N40°51.0' W074°03.7'

AIRPORT DIAGRAM

NEARBY AIRPORTS

OPEN A/FD

Data Refresh Info

18:21 05/02/2022 UTC

REFRESH

- FBOs >
- Information >
- Frequencies >
- Runways >
- Procedures >
- Weather >
- MOS >
- NOTAMs >
- Remarks >

#### METAR REPORTS

KTEB 021751Z 07006KT 3SM BR OVC007 12/11 A3001 RMK AO2 DZE47 CIG 005V010 SLP162 P0000 60001 T01220111 10128 20106 58009

KTEB 021728Z 06006KT 2SM -DZ(light drizzle) BR OVC005 12/11 A3002 RMK AO2 P0000 T01220106

KTEB 021651Z 07007KT 2SM -DZ(light drizzle) BR OVC004 12/11 A3003 RMK AO2 RAB1552E47DZB48 SLP167 P0001 T01220106

KTEB 021556Z VRB04KT 1 1/2sm R06/3500VP6000FT -RA BR OVC004 12/11 A3004 RMK AO2 RAB52 P0000 T01220106

KTEB 021551Z 07004KT 2SM R06/3500VP6000FT BR OVC008 12/11 A3004 RMK AO2 SLP172 T01220106

KTEB 021549Z 07005KT 2SM R06/4500VP6000FT BR OVC008 12/11 A3004 RMK AO2

#### TERMINAL FORECASTS

KTEB 021740Z 0218/0324 05007KT 2SM -DZ(light drizzle) BR OVC004

FM022100 02007KT 2SM -DZ(light drizzle) BR OVC004

FM030000 01004KT 3SM BR OVC006

FM031300 05006KT P6SM SCT008 BKN015

TEMPO 0316/0319 SCT020 BKN035

FM032000 10009KT P6SM SCT015 BKN025

#### NEARBY DEPARTURE AIRPORT METARS

KCDW 021753Z 06006KT 4SM BR OVC007 13/11 A3003 RMK AO2 CIG 005V011 SLP172 60001 T01330111

Touch to View Info in Browser via FltPlan.com  
VIEW IN WEB BROWSER

Touch to Refresh Data

Touch to View Additional Info

FltPlan Go - Airports Page - Weather

FltPlan Go for Android User's Guide

190-02961-00 Rev A

24



**NOTE:** A connection to Wi-Fi or ADS-B unit must be established to ensure current weather information.

## MOS

Located on the left side of the Airports section is a list of tabs that sort features/information associated with the selected airport. The seventh tab on the list is MOS. Touch the **MOS** Tab to view outlook weather forecasts which include details such as Ceilings (ft), Visibility (miles), Wind (compass direction and velocity in knots), Chance of Precipitation, and Temperature (°F). MOS forecasts provide weather data up to four (4) days out, presented in 3-hour windows, and refreshed hourly. To manually refresh the weather, touch the **Reload Data** button.

KTEB

WIND CALC.

### TETERBORO

TETERBORO, NJ  
N40°51.0' W074°03.7'

AIRPORT DIAGRAM

NEARBY AIRPORTS

OPEN A/FD

FBOs >

MOS Weather Forecast

RELOAD DATA

**Mon 05/02/2022 12:00Z**

Ceil: ● Vis: ● Wind: ● Temp: ●

Clouds: OVC 3000 - 6500 ft Vis: > 6 mi Wind: 08003kt Temp: 52° --- See METARs/TAF ---

---

**Mon 05/02/2022 15:00Z**

Ceil: ● Vis: ● Wind: ● Temp: ●

Clouds: OVC 1000 - 2000 ft Vis: 6 mi Haze Wind: 06004kt Temp: 54° --- See METARs/TAF ---

---

**Mon 05/02/2022 18:00Z**

Ceil: ● Vis: ● Wind: ● Temp: ●

Clouds: OVC 500 - 1000 ft Vis: 3 to 5 mi Mist Wind: 05004kt Temp: 57° Prob. Rain: 46%

---

**Mon 05/02/2022 21:00Z**

Ceil: ● Vis: ● Wind: ● Temp: ●

Clouds: OVC 500 - 1000 ft Vis: 2 to 3 mi Mist Wind: 01004kt Temp: 58° Prob. Rain: 46%

---

**Tue 05/03/2022 00:00Z**

Ceil: ● Vis: ● Wind: ● Temp: ●

Clouds: OVC 500 - 1000 ft Vis: 2 to 3 mi Mist Wind: 36006kt Temp: 57° Prob. Rain: 40%

---

**Tue 05/03/2022 03:00Z**

Ceil: ● Vis: ● Wind: ● Temp: ●

Clouds: OVC 500 - 1000 ft Vis: 3 to 5 mi Mist Wind: 36004kt Temp: 55° Prob. Rain: 40%

---

**Tue 05/03/2022 06:00Z**

Ceil: ● Vis: ● Wind: ● Temp: ●

Clouds: OVC 500 - 1000 ft Vis: 3 to 5 mi Mist Wind: 36003kt Temp: 53° Prob. Rain: 22%

Touch to Re-  
fresh Data

Touch to View

Scroll to View  
Additional Info

FltPlan Go - Airports Page - MOS

- Account
- FitPlan
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

## NOTAMS

Located on the left side of the Airports section is a list of tabs that sort features/information associated with the selected airport. The eighth tab on the list is NOTAMS. Touch the **NOTAMS** Tab to view NOTAMS, and FDC. To Refresh NOTAMS information, tap the Refresh button. A timestamp will appear on the top of the screen indicating the most recent refresh.



**NOTE:** A connection to Wi-Fi or ADS-B unit must be established to ensure current NOTAMS information.

KTEB

WIND CALC.

### TETERBORO

TETERBORO, NJ  
N40°51.0' W074°03.7'

AIRPORT DIAGRAM

NEARBY AIRPORTS

OPEN A/FD

Data Refresh Info
19:20 05/02/2022 UTC
REFRESH
Touch to Refresh Data

- FBOs >
- Information >
- Frequencies >
- Runways >
- Procedures >
- Weather >
- MOS >
- NOTAMS >
- Remarks >

### NOTAMS

KTEB 1/9454 TEB IAP TETERBORO, TETERBORO, NJ. ILS OR LOC RWY 6, AMDT 29I... NOTE: FOR INOPERATIVE ALS INCREASE S-LOC 6 CAT C/D VISIBILITY TO 1 3/8 SM. 2110061843-2310061842

KTEB 06/007 TEB OBST CRANE (ASN UNKNOWN) 405306N0740222W (2.32NM NE TEB) 210FT (202FT AGL) FLAGGED AND LGTD 2106011518-2206011900

KTEB 1/9433 TEB IAP TETERBORO, TETERBORO, NJ. ILS OR LOC RWY 6, AMDT 29I... S-ILS 6, DA 276/HAT 270 ALL CATS. VISIBILITY ALL CATS RVR 2000. TEMPORARY CRANE 309FT MSL 4327FT NORTHEAST OF RWY 6 (2021-AEA-182, 83, 84, 85-NRA-OE). 2108041000-2207241000

KTEB 1/9436 TEB IAP TETERBORO, TETERBORO, NJ. RNAV (GPS) Y RWY 19, AMDT 1... LPV DA 337/HAT 331 ALL CATS. VISIBILITY ALL CATS 1. TEMPORARY CRANE 309FT MSL 2197FT SOUTHEAST OF RWY 19 (2021-AEA-182, 83, 84, 85-NRA). 2108041000-2207241000

KTEB 08/030 TEB OBST CRANE (ASN 2021-AEA-182-NRA) 405101N0740319W (0.2NM E TEB) 309FT (300FT AGL) FLAGGED AND LGTD 2108061753-2206301559

KTEB 1/1680 TEB IAP TETERBORO, TETERBORO, NJ. ILS OR LOC RWY 19, AMDT 1... S-ILS 19, DA 337/HAT 331 ALL CATS. VISIBILITY ALL CATS 1. TEMPORARY CRANE 309FT MSL 2197FT SOUTHEAST OF RWY 19 (2021-AEA-182, 83, 84, 85-NRA). 2111272251-2207241000

KTEB 2/3456 TEB STAR TETERBORO AIRPORT, TETERBORO, NJ. WILKES-BARRE FOUR ARRIVAL... DISREGARD FJC VORTAC RADIALS AT HARTY AND MUGZY. CHART NOTE:DME REQUIRED 2201121845-2301122359

KTEB 01/100 TEB AD AP RDO ALTIMETER UNREL. AUTOLAND, HUD TO TOUCHDOWN, ENHANCED FLT VISION SYSTEMS TO TOUCHDOWN, HEL OPS REQUIRING RDO ALTIMETER DATA TO INCLUDE HOVER AUTOPILOT MODES AND CAT A/B/PERFORMANCE CLASS TKOF AND LDG NOT AUTHORIZED EXC FOR ACFT USING APPROVED ALTERNATIVE METHODS OF COMPLIANCE DUE TO 5G C-BAND INTERFERENCE PLUS SEE AIRWORTHINESS DIRECTIVES 2021-23-12, 2021-23-13 2201190501-2401190501

Touch to View

Scroll to View Additional Info

FltPlan Go - Airports Page - NOTAMS

190-02961-00 Rev A

FltPlan Go for Android User's Guide

26

### REMARKS

Located on the left side of the Airports section is a list of tabs that sort features/information associated with the selected airport. The ninth and final tab on the list is Remarks. Touch the **Remarks** Tab to view a list of FAA remarks, e.g. Traffic Pattern (Left or Right), After Hours Contact Info, Customs Data, Migratory Bird Activity, Engineered Materials Arresting System (EMAS) Info, Approach Lighting, etc.

**TETERBORO**  
TETERBORO, NJ  
N40°51.0' W074°03.7'

**Remarks**

- Customs Data - Phone: 201-288-8799 - Fax: 201-288-4699 - Info: Main Customs Office: We are located at hangar 1 and Jet Aviation. All landing rights/outbound request needs to be submitted for approval via this email ktebgaops@cbp.dhs.gov We are open 7 days a week and our normal operation hours are 0700-2400. Arrival flights are required to be scheduled between the hours of 0730-2315 (wheels down).
- Traffic Pattern: 01 - Left Traffic / 19 - Left Traffic
- Traffic Pattern: 06 - Left Traffic / 24 - Left Traffic
- CLSD TO MOTORLESS ACFT - UNCTLD ACFT & ULTRALIGHT ACTIVITY EXCEP BY PRIOR PERMISSION.
- DLY CONS CONST ACT ALL QUADRANTS.
- ACFT CAPABLE OF OPERATING ABV 100,000 POUNDS MUST SUBMIT CERTIFICATION TO AMGR VERIFYING AIRCRAFT OPERATING WEIGHT IS LESS THAN 100,000 LBS. CONTACT AIRPORT OPERATIONS AT 201-288-1775 FOR FORMS.

FltPlan Go - Airports Page - Remarks

### VIEW IN BROWSER

Throughout the FltPlan Go program, there will be the option to view the information in a web browser. Touching the **View in Web Browser** button will display a window confirming the desire to exit FltPlan Go and view the information via FltPlan.com.

Touch **No** to stay within the FltPlan Go program.

Touch **Yes** to exit FltPlan Go and launch FltPlan.com in a web browser.

**Leaving the App**  
Clicking 'Yes' will result in leaving the app and going to your web browser.

Touch to Stay in FltPlan Go **NO** **YES** Touch to View Info in Web Browser

FltPlan Go - Airports Page - View In Browser Confirmation

# MAPS



Selecting the Maps page allows the user to view the aircraft on a geo-referenced map with various layers of information.

- FitPlan Account
- Airports
- Maps**
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

Touch to View

FitPlan Go - Maps Page

## HEADER MENU

The Header Menu is customized for each section (e.g. Airports, Maps, NavLogs, etc.) and contains various buttons to help the User navigate the FltPlan Go program quickly. In the Maps section, the available buttons include Airports Near Me, Map Settings/Options, Split Screen, Zoom, Connectivity, Current Route, Measure Distance, Timer, Account, Layers, Route, Edit, METARs, MOS, Winds, Weather (Wx), XM, and ADS-B.



## AIRPORTS NEAR ME

The first button located in the Header Menu of the Maps Page is Airports Near Me. Touch  to view a list of airports near the current location of the device, listed from nearest to furthest. Touch the desired airport from the list to view the applicable airport information.

### Viewing Airports Near Me:

- 1) Touch  within the Airports section.
- 2) Touch desired airport from the list to view additional Airport Information.

Nearby Me	
KOJC, JOHNSON COUNTY EXECUTIVE OLATHE, KS (RWY: 4097 ft) Dist. 3 NM	Distance From Airport
KIXD, NEW CENTURY AIRCENTER OLATHE, KS (RWY: 7339 ft) Dist. 4 NM	Longest Runway
K51K, CEDAR AIR PARK OLATHE, KS (RWY: 2440 ft) Dist. 6 NM	City, State
KK34, GARDNER MUNI GARDNER, KS (RWY: 3224 ft) Dist. 8 NM	
69KS, CHILES AIRPARK (PRIVATE) CHILES, KS (RWY: 2600 ft) Dist. 12 NM	
52KS, BLAND (PRIVATE) EUDORA, KS (RWY: 1800 ft) Dist. 16 NM	
75MO, CHILDRENS MERCY HOSPITAL HLPRT KANSAS CITY, MO (RWY: 0 ft) Dist. 17 NM	
3MO1, POLICE DEPT HELIPORT (PVT) KANSAS CITY, MO (RWY: 0 ft) Dist. 18 NM	
KMKC, CHARLES B. WHEELER DOWNTOWN KANSAS CITY, MO (RWY: 6827 ft) Dist. 19 NM	
KK81, MIAMI COUNTY PAOLA, KS (RWY: 3398 ft) Dist. 20 NM	

Touch to View Airport Info

FltPlan Go - Airports Page - Airports Near Me



**NOTE:** Location Services must be enabled on the device in order to accurately display Airports Near Me. Most devices list Location Services under Settings > Privacy.

## MAP OPTIONS



Touch to view a list with several options that include: North-up, Track-up, Track-forward, Downloaded Maps Only, Auto-center Position, Display Ship Position, Toggle Range Circle Rings, Display Route Fix Labels, Customize Route & Ship Icon, Runway/Airport Options, Toggle Breadcrumbs, Save Breadcrumbs, Clear Breadcrumbs, Breadcrumbs List, Go to Departure Airport, and Go to Arrival Airport.

ORIENTATION	
North-up	<input checked="" type="radio"/>
Track-up	<input type="radio"/>
Track-forward	<input type="radio"/>
MAP & SHIP OPTIONS	
Downloaded Maps Only	<input checked="" type="checkbox"/>
Auto-center Position	<input checked="" type="checkbox"/>
Display Ship Position	<input checked="" type="checkbox"/>
Toggle Range Circle Rings	<input checked="" type="checkbox"/>
ROUTE & ICON OPTIONS	
Display Route Fix Labels	<input checked="" type="checkbox"/>
Customize Route & Ship Icon	
Runway / Airport Options	
BREADCRUMBS	
Toggle Breadcrumbs	<input checked="" type="checkbox"/>
Save Breadcrumbs	
Clear Breadcrumbs	
Breadcrumbs List	
GO TO AIRPORT	
Go to Departure Airport	
Go to Arrival Airport	
<a href="#">CLOSE</a>	

*Touch to View/Adjust* (points to the gear icon)

*Touch to Exit* (points to the CLOSE button)

FltPlan Go - Maps Page - Options

- FltPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

## TRACK UP

Touch to point the Map in the direction of flight.

## NORTH UP

Touch to change the Map orientation where North is always 'Up', no matter the direction of flight.

## TRACK FORWARD

Touch to display only the area in front of the aircraft position, moving the aircraft to the 'bottom' of the Map.

## DOWNLOADED MAPS ONLY

Touch to view maps that have been previously downloaded and are not being supplied via an active internet connection.



**NOTE:** Use **Downloaded Maps Only** after the applicable charts are downloaded via the Downloads section to ensure Maps will be displayed when the device is no longer connected to the internet.

## AUTO-CENTER POSITION

Touch to automatically center the display on the aircraft.

## DISPLAY SHIP POSITION

Touch to display an aircraft icon on the map representing the current position.

## TOGGLE RANGE CIRCLE RINGS

Touch to display range circles that center around the aircraft position at a defined distance, which can be helpful when visualizing distance and/or time out from a certain point.


## DISPLAY ROUTE FIX LABELS

Touch to display all route fixes and labels.

## CUSTOMIZE ROUTE & SHIP ICON

Touch **Customize Route & Ship Icon** to display a menu with options to edit the Aircraft Icon, Route Color and Opacity, and GPS Position.

- Touch **Jet, Prop, or Helicopter** to adjust the Aircraft Icon shape.
- Touch **Small, Medium, or Large** to adjust the Aircraft Icon size.
- Touch the desired Aircraft Icon color. Aircraft Icon adjustments are made in real time to help the User identify the preferred display settings.
- Below the Aircraft Icon settings are the Route settings. Touch the desired Route color.
- Slide the **Route Line Opacity** switch to the desired level.



FltPlan Go - Maps Page - Aircraft Icon Options


## RUNWAY/AIRPORT OPTIONS

Touch to display a menu with settings for **Show Runways on Map**, **Runway Color**, **Runway Icons**, **Standard Icons**, and **Airport Color**.

- Touch **Show Runways on Map** as desired, to adjust display on Map.
- Touch the desired Runway Color.
- Touch **Runway Icons** or **Standard Icons**, as desired. Standard Icons displays a 'ring' to depict the location of an airport. If Runway Icons is selected, the display includes the runway orientation within the depiction of the airport location, which can be enabled by touching **Maps > Layers > Airports**.



**NOTE:** An additional download may be required if 'Runway Icons' is selected..



FltPlan Go - Maps Page - Runway & Airport Icon Options

## TOGGLE BREADCRUMBS

Touch to enable the flight path tracking option for future playback and review. When enabled, a green checkmark will be displayed. Touch to toggle 'On/Off' as desired.

## SAVE BREADCRUMBS

Touch to display a pop-up window prompting the User to manually enter the name of the current breadcrumbs. Once the name has been entered, touch **Save**.

## CLEAR BREADCRUMBS

Touch to clear the current breadcrumbs displayed on the Map.

## BREADCRUMBS LIST

Touch to view Saved Breadcrumbs and Online Breadcrumbs.

- Touch **Saved Breadcrumbs** to view a pop-up window with the options to **Open, Email, Rename, Upload to FltPlan.com,** and **Delete**.
- Touch **Open Breadcrumbs** to view the track on the Map, along with a pop-up window in the top right corner with playback options.
- Touch **Breadcrumbs Playback** to view a pop-up window with several options, including **Play, Pause,** and **Stop**. **Flight Duration** is presented in hours, minutes, and seconds. **Speed Option(s),** and **Flight Percentage** are displayed via progress bar. Touch **Play** and the breadcrumbs from your flight will populate the map. Touch **Pause** to pause the playback and keep the breadcrumbs on the Map. Touch **Stop** to exit breadcrumbs playback.
- Slide the **Speed Bar,** which has two icons indicating an increased playback rate (rabbit) or a slower playback rate (turtle) as desired.
- The **Flight Percentage Bar** is located on the right side, and indicates the percentage of the flight that has been completed.
- Touch **Online Breadcrumbs** to display a pop-up window with the options to Delete or Download. Touch **Delete** to remove breadcrumbs. Touch **Download** to download a set of breadcrumbs and store offline.
- Touch **Google Earth** and a prompt will appear with the options to email and create a KML file of the selected breadcrumbs. Touch the downloaded KML file to view via Google Earth.
- Touch **Email Breadcrumbs** to display a pop-up window with a User generated list of saved breadcrumbs as the body of the email. Enter desired text to compose the email and send. The recipient will be able to open the breadcrumbs from the email via FltPlan Go.
- Touch **Upload to FltPlan.com** to save your breadcrumbs to FltPlan.com, allowing the User to access the breadcrumbs from both FltPlan.com and the FltPlan Go program.

## GO TO DEPARTURE AIRPORT

Touch to redirect the Airports section to the Departure Airport listed in the route.


## GO TO ARRIVAL AIRPORT

Touch to redirect the Airports section to the Arrival Airport listed in the route.

## SPLIT SCREEN



Touch  to display a menu with various Split Screen options that can be displayed simultaneously, such as; Airports, Departure Airport Procedures, Arrival Airport Procedures, NavLogs, Howgozit, Weather, ScratchPad, and Tools. Touch the desired display option to view one of the Split Screen Options in conjunction with with Maps or NavLogs simultaneously, in either vertical or horizontal orientation.



FltPlan Go - Maps - Split Screen Options Menu

- FltPlan
- Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

- FitPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

Touch to View Split Screen Options

KTEB TO KLWC

GARMIN

Layers
Route
Edit
METARs
MOS
Winds
Wx
XM
ADS-B

Reverse Route **REVERSE**

Add Present Position to Route **P/P**

Save Route **SAVE**

Save & File Route **SAVE / FILE**

Touch When Finished **DONE**

KTEB ZIMMZ SPOTZ MIKYG HOTEV BEETS VINSE LEJOY AIR CORVS  
ZANDR BOWRR EMPTY CREEP FYLLS VHP JAAVE GORDO SPI BAYLI  
TWAIN SAAGS MCI KLWC

**WAYPOINTS** Add/Delete User Waypoints

**PROCEDURES** View Available Procedures

**S/R GRID** Add Search & Rescue Grid

**CLEAR** Clear Route

Accuracy: 54 m

Speed kts: 0 kts

Lat/Long: N38°51.3' W094°48.0'

Altitude: 972 ft

True Course: 360°

ZULU TIME

**(TEB4.TEB) 21280 AL-890 (FAA) TETERBORO FOUR DEPARTURE TETERBORO (TEB) TETERBORO, NEW JERSEY**

**TOP ALTITUDE: 2000**

**NON-DME AIRCRAFT: 1500**

**TEB 2.3**

**TEB 4.5**

**TEB 2.1**

**TEB 2.2**

**TEB 2.3**

**TEB 2.4**

**TEB 2.5**

**TEB 2.6**

**TEB 2.7**

**TEB 2.8**

**TEB 2.9**

**TEB 3.0**

**TEB 3.1**

**TEB 3.2**

**TEB 3.3**

**TEB 3.4**

**TEB 3.5**

**TEB 3.6**

**TEB 3.7**

**TEB 3.8**

**TEB 3.9**

**TEB 4.0**

**TEB 4.1**

**TEB 4.2**

**TEB 4.3**

**TEB 4.4**

**TEB 4.5**

**TEB 4.6**

**TEB 4.7**

**TEB 4.8**

**TEB 4.9**

**TEB 5.0**

**TEB 5.1**

**TEB 5.2**

**TEB 5.3**

**TEB 5.4**

**TEB 5.5**

**TEB 5.6**

**TEB 5.7**

**TEB 5.8**

**TEB 5.9**

**TEB 6.0**

**TEB 6.1**

**TEB 6.2**

**TEB 6.3**

**TEB 6.4**

**TEB 6.5**

**TEB 6.6**

**TEB 6.7**

**TEB 6.8**

**TEB 6.9**

**TEB 7.0**

**TEB 7.1**

**TEB 7.2**

**TEB 7.3**

**TEB 7.4**

**TEB 7.5**

**TEB 7.6**

**TEB 7.7**

**TEB 7.8**

**TEB 7.9**

**TEB 8.0**

**TEB 8.1**

**TEB 8.2**

**TEB 8.3**

**TEB 8.4**

**TEB 8.5**

**TEB 8.6**

**TEB 8.7**

**TEB 8.8**

**TEB 8.9**

**TEB 9.0**

**TEB 9.1**

**TEB 9.2**

**TEB 9.3**

**TEB 9.4**

**TEB 9.5**

**TEB 9.6**

**TEB 9.7**

**TEB 9.8**

**TEB 9.9**

**TEB 10.0**

**TEB 10.1**

**TEB 10.2**

**TEB 10.3**

**TEB 10.4**

**TEB 10.5**

**TEB 10.6**

**TEB 10.7**

**TEB 10.8**

**TEB 10.9**

**TEB 11.0**

**TEB 11.1**

**TEB 11.2**

**TEB 11.3**

**TEB 11.4**

**TEB 11.5**

**TEB 11.6**

**TEB 11.7**

**TEB 11.8**

**TEB 11.9**

**TEB 12.0**

**TEB 12.1**

**TEB 12.2**

**TEB 12.3**

**TEB 12.4**

**TEB 12.5**

**TEB 12.6**

**TEB 12.7**

**TEB 12.8**

**TEB 12.9**

**TEB 13.0**

**TEB 13.1**

**TEB 13.2**

**TEB 13.3**

**TEB 13.4**

**TEB 13.5**

**TEB 13.6**

**TEB 13.7**

**TEB 13.8**

**TEB 13.9**

**TEB 14.0**

**TEB 14.1**

**TEB 14.2**

**TEB 14.3**

**TEB 14.4**

**TEB 14.5**

**TEB 14.6**

**TEB 14.7**

**TEB 14.8**

**TEB 14.9**

**TEB 15.0**

**TEB 15.1**

**TEB 15.2**

**TEB 15.3**

**TEB 15.4**

**TEB 15.5**

**TEB 15.6**

**TEB 15.7**

**TEB 15.8**

**TEB 15.9**

**TEB 16.0**

**TEB 16.1**

**TEB 16.2**

**TEB 16.3**

**TEB 16.4**

**TEB 16.5**

**TEB 16.6**

**TEB 16.7**

**TEB 16.8**

**TEB 16.9**

**TEB 17.0**

**TEB 17.1**

**TEB 17.2**

**TEB 17.3**

**TEB 17.4**

**TEB 17.5**

**TEB 17.6**

**TEB 17.7**

**TEB 17.8**

**TEB 17.9**

**TEB 18.0**

**TEB 18.1**

**TEB 18.2**

**TEB 18.3**

**TEB 18.4**

**TEB 18.5**

**TEB 18.6**

**TEB 18.7**

**TEB 18.8**

**TEB 18.9**

**TEB 19.0**

**TEB 19.1**

**TEB 19.2**

**TEB 19.3**

**TEB 19.4**

**TEB 19.5**

**TEB 19.6**

**TEB 19.7**

**TEB 19.8**

**TEB 19.9**

**TEB 20.0**

**TEB 20.1**

**TEB 20.2**

**TEB 20.3**

**TEB 20.4**

**TEB 20.5**

**TEB 20.6**

**TEB 20.7**

**TEB 20.8**

**TEB 20.9**

**TEB 21.0**

**TEB 21.1**

**TEB 21.2**

**TEB 21.3**

**TEB 21.4**

**TEB 21.5**

**TEB 21.6**

**TEB 21.7**

**TEB 21.8**

**TEB 21.9**

**TEB 22.0**

**TEB 22.1**

**TEB 22.2**

**TEB 22.3**

**TEB 22.4**

**TEB 22.5**

**TEB 22.6**

**TEB 22.7**

**TEB 22.8**

**TEB 22.9**

**TEB 23.0**

**TEB 23.1**

**TEB 23.2**

**TEB 23.3**

**TEB 23.4**

**TEB 23.5**

**TEB 23.6**

**TEB 23.7**

**TEB 23.8**

**TEB 23.9**

**TEB 24.0**

**TEB 24.1**

**TEB 24.2**

**TEB 24.3**

**TEB 24.4**

**TEB 24.5**

**TEB 24.6**

**TEB 24.7**

**TEB 24.8**

**TEB 24.9**

**TEB 25.0**

**TEB 25.1**

**TEB 25.2**

**TEB 25.3**

**TEB 25.4**

**TEB 25.5**

**TEB 25.6**

**TEB 25.7**

**TEB 25.8**

**TEB 25.9**

**TEB 26.0**

**TEB 26.1**

**TEB 26.2**

**TEB 26.3**

**TEB 26.4**

**TEB 26.5**

**TEB 26.6**

**TEB 26.7**

**TEB 26.8**

**TEB 26.9**

**TEB 27.0**

**TEB 27.1**

**TEB 27.2**

**TEB 27.3**

**TEB 27.4**

**TEB 27.5**

**TEB 27.6**

**TEB 27.7**

**TEB 27.8**

**TEB 27.9**

**TEB 28.0**

**TEB 28.1**

**TEB 28.2**

**TEB 28.3**

**TEB 28.4**

**TEB 28.5**

**TEB 28.6**

**TEB 28.7**

**TEB 28.8**

**TEB 28.9**

**TEB 29.0**

**TEB 29.1**

**TEB 29.2**

**TEB 29.3**

**TEB 29.4**

**TEB 29.5**

**TEB 29.6**

**TEB 29.7**

**TEB 29.8**

**TEB 29.9**

**TEB 30.0**

**TEB 30.1**

**TEB 30.2**

**TEB 30.3**

**TEB 30.4**

**TEB 30.5**

**TEB 30.6**

**TEB 30.7**

**TEB 30.8**

**TEB 30.9**

**TEB 31.0**

**TEB 31.1**

**TEB 31.2**

**TEB 31.3**

**TEB 31.4**

**TEB 31.5**

**TEB 31.6**

**TEB 31.7**

**TEB 31.8**

**TEB 31.9**

**TEB 32.0**

**TEB 32.1**

**TEB 32.2**

**TEB 32.3**

**TEB 32.4**

**TEB 32.5**

**TEB 32.6**

**TEB 32.7**

**TEB 32.8**

**TEB 32.9**

**TEB 33.0**

**TEB 33.1**

**TEB 33.2**

**TEB 33.3**

**TEB 33.4**

**TEB 33.5**

**TEB 33.6**

**TEB 33.7**

**TEB 33.8**

**TEB 33.9**

**TEB 34.0**

**TEB 34.1**

**TEB 34.2**

**TEB 34.3**

**TEB 34.4**

**TEB 34.5**

**TEB 34.6**

**TEB 34.7**

**TEB 34.8**

**TEB 34.9**

**TEB 35.0**

**TEB 35.1**

**TEB 35.2**

**TEB 35.3**

**TEB 35.4**

**TEB 35.5**

**TEB 35.6**

**TEB 35.7**

**TEB 35.8**

**TEB 35.9**

**TEB 36.0**

**TEB 36.1**

**TEB 36.2**

**TEB 36.3**

**TEB 36.4**

**TEB 36.5**

**TEB 36.6**

**TEB 36.7**

**TEB 36.8**

**TEB 36.9**

**TEB 37.0**

**TEB 37.1**

**TEB 37.2**

**TEB 37.3**

**TEB 37.4**

**TEB 37.5**

**TEB 37.6**

**TEB 37.7**

**TEB 37.8**

**TEB 37.9**

**TEB 38.0**

**TEB 38.1**

**TEB 38.2**

**TEB 38.3**

**TEB 38.4**

**TEB 38.5**

**TEB 38.6**

**TEB 38.7**

**TEB 38.8**

**TEB 38.9**

**TEB 39.0**

**TEB 39.1**

**TEB 39.2**

**TEB 39.3**

**TEB 39.4**

**TEB 39.5**

**TEB 39.6**

**TEB 39.7**

**TEB 39.8**

**TEB 39.9**

**TEB 40.0**

**TEB 40.1**

**TEB 40.2**

**TEB 40.3**

**TEB 40.4**

**TEB 40.5**

**TEB 40.6**

**TEB 40.7**

**TEB 40.8**

**TEB 40.9**

**TEB 41.0**

**TEB 41.1**

**TEB 41.2**

**TEB 41.3**

**TEB 41.4**

**TEB 41.5**

**TEB 41.6**

**TEB 41.7**

**TEB 41.8**

**TEB 41.9**

**TEB 42.0**

**TEB 42.1**

**TEB 42.2**

**TEB 42.3**

**TEB 42.4**

**TEB 42.5**

**TEB 42.6**

**TEB 42.7**

**TEB 42.8**

**TEB 42.9**

**TEB 43.0**

**TEB 43.1**

**TEB 43.2**

**TEB 43.3**

**TEB 43.4**

**TEB 43.5**

**TEB 43.6**

**TEB 43.7**

**TEB 43.8**

**TEB 43.9**

**TEB 44.0**

**TEB 44.1**

**TEB 44.2**

**TEB 44.3**

**TEB 44.4**

**TEB 44.5**

**TEB 44.6**

**TEB 44.7**

**TEB 44.8**

**TEB 44.9**

**TEB 45.0**

**TEB 45.1**

**TEB 45.2**

**TEB 45.3**

**TEB 45.4**

**TEB 45.5**

**TEB 45.6**

**TEB 45.7**

**TEB 45.8**

**TEB 45.9**

**TEB 46.0**

**TEB 46.1**

**TEB 46.2**

**TEB 46.3**

**TEB 46.4**

**TEB 46.5**

**TEB 46.6**

**TEB 46.7**

**TEB 46.8**

**TEB 46.9**

**TEB 47.0**

**TEB 47.1**

**TEB 47.2**

**TEB 47.3**

**TEB 47.4**

**TEB 47.5**

**TEB 47.6**

**TEB 47.7**

**TEB 47.8**

**TEB 47.9**

**TEB 48.0**

**TEB 48.1**

**TEB 48.2**

**TEB 48.3**

**TEB 48.4**

**TEB 48.5**

**TEB 48.6**

**TEB 48.7**

**TEB 48.8**

**TEB 48.9**

**TEB 49.0**

**TEB 49.1**

**TEB 49.2**

**TEB 49.3**

**TEB 49.4**

**TEB 49.5**

**TEB 49.6**

**TEB 49.7**

**TEB 49.8**

**TEB 49.9**

**TEB 50.0**

**TEB 50.1**

**TEB 50.2**

**TEB 50.3**

**TEB 50.4**

**TEB 50.5**

**TEB 50.6**

**TEB 50.7**

**TEB 50.8**

**TEB 50.9**

**TEB 51.0**

**TEB 51.1**

**TEB 51.2**

**TEB 51.3**

**TEB 51.4**

**TEB 51.5**

**TEB 51.6**

**TEB 51.7**

**TEB 51.8**

**TEB 51.9**

**TEB 52.0**

**TEB 52.1**

**TEB 52.2**

**TEB 52.3**

**TEB 52.4**

**TEB 52.5**

**TEB 52.6**

**TEB 52.7**

**TEB 52.8**

**TEB 52.9**

**TEB 53.0**

**TEB 53.1**

**TEB 53.2**

**TEB 53.3**

**TEB 53.4**

**TEB 53.5**

**TEB 53.6**

**TEB 53.7**

**TEB 53.8**

**TEB 53.9**

**TEB 54.0**

**TEB 54.1**

**TEB 54.2**

**TEB 54.3**

**TEB 54.4**

**TEB 54.5**

**TEB 54.6**

**TEB 54.7**

**TEB 54.8**

**TEB 54.9**

**TEB 55.0**

**TEB 55.1**

**TEB 55.2**

**TEB 55.3**

**TEB 55.4**

**TEB 55.5**

**TEB 55.6**

**TEB 55.7**

**TEB 55.8**

**TEB 55.9**

**TEB 56.0**

**TEB 56.1**

**TEB 56.2**

**TEB 56.3**

**TEB 56.4**

**TEB 56.5**

**TEB 56.6**

**TEB 56.7**

**TEB 56.8**

**TEB 56.9**

**TEB 57.0**

**TEB 57.1**

**TEB 57.2**

**TEB 57.3**

**TEB 57.4**

**TEB 57.5**

**TEB 57.6**

**TEB 57.7**

**TEB 57.8**

**TEB 57.9**

**TEB 58.0**

**TEB 58.1**

**TEB 58.2**

**TEB 58.3**

**TEB 58.4**

**TEB 58.5**

**TEB 58.6**

**TEB 58.7**

**TEB 58.8**

**TEB 58.9**

**TEB 59.0**

**TEB 59.1**

**TEB 59.2**

**TEB 59.3**

**TEB 59.4**

**TEB 59.5**

**TEB 59.6**

**TEB 59.7**

**TEB 59.8**

**TEB 59.9**

**TEB 60.0**

**TEB 60.1**

**TEB 60.2**

**TEB 60.3**

**TEB 60.4**

**TEB 60.5**

**TEB 60.6**

**TEB 60.7**

**TEB 60.8**

**TEB 60.9**

**TEB 61.0**

**TEB 61.1**

**TEB 61.2**

**TEB 61.3**

**TEB 61.4**

**TEB 61.5**

**TEB 61.6**

**TEB 61.7**

**TEB 61.8**

**TEB 61.9**

**TEB 62.0**

**TEB 62.1**

**TEB 62.2**

**TEB 62.3**

**TEB 62.4**

**TEB 62.5**

**TEB 62.6**

**TEB 62.7**

**TEB 62.8**

**TEB 62.9**

**TEB 63.0**

**TEB 63.1**

**TEB 63.2**

**TEB 63.3**

**TEB 63.4**

**TEB 63.5**

**TEB 63.6**

**TEB 63.7**

**TEB 63.8**

**TEB 63.9**

**TEB 64.0**

**TEB 64.1**

**TEB 64.2**

**TEB 64.3**

**TEB 64.4**

**TEB 64.5**

**TEB 64.6**

**TEB 64.7**

**TEB 64.8**

**TEB 64.9**

**TEB 65.0**

**TEB 65.1**

**TEB 65.2**

**TEB 65.3**

**TEB 65.4**

**TEB 65.5**

**TEB 65.6**

**TEB 65.7**

**TEB 65.8**

**TEB 65.9**

**TEB 66.0**

**TEB 66.1**

**TEB 66.2**

**TEB 66.3**

**TEB 66.4**

**TEB 66.5**

**TEB 66.6**

**TEB 66.7**

**TEB 66.8**


**TEB 66.9**

**TEB 67.0**

**TEB 67.1</**

## ZOOM

Touch  to display a menu with the following options; Zoom to Present Position, Zoom to Departure Airport, Zoom to Arrival Airport, Zoom to Full Route, and Zoom to Breadcrumbs. Touch the desired Zoom option to view the area on the Map.




FltPlan Go - Maps Page - Zoom Options

## CONNECTIVITY

Touch  to display a menu with options to Export Flight Plan and Share Flight Plan.

### GARMIN PILOT

Touch the Upload Route button to transfer the route of flight to Garmin Pilot. When connected to a compatible Garmin avionics suite that supports flight plan transfers, the avionics will be displayed as an option to export the route of flight.



FltPlan Go - Maps Page - Connectivity Options



**NOTE:** To aid in Flight Plan transfer, please ensure the desired external piece of equipment is connected via the External Page prior to attempting the flight plan transfer.

### JEPPESEN FLITEDECK

Touch to send the current route of flight to a properly configured and connected piece of Jeppesen equipment.

### DYNON

Touch to send the current route of flight to a properly configured and connected piece of Dynon equipment.

### AVIDYNE


Touch to send the current route of flight to a properly configured and connected piece of Avidyne equipment.

## MY ROUTES

Touch the button at the top, center, with the Departure and Arrival airport ID's, e.g. KTEB TO KLWC to display a menu listing Local Routes and Account Routes.

To Delete a Saved Route, long press the desired route and touch **Yes**, when prompted, to delete the route.

To Refresh My Routes, touch **Refresh Routes** at the bottom of the My Routes menu.



FltPlan Go - Maps Page - Routes

## AUTO SYNCING ROUTES

When a flight plan is created in FltPlan.com, the flight information, including NavLogs, Routes, Weight & Balance Calculations, and Checklists, are synced to the FltPlan Go program.

- FltPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

Touch to View

From	To	Course	Distance
KTEB	ZIMMZ	279° M	48nm 945nm
ZIMMZ	SPOTZ	271° M	12nm 933nm
SPOTZ	MIKYG	255° M	22nm 911nm
MIKYG	HOTEE	255° M	34nm 877nm
HOTEE	BEETS	253° M	49nm 827nm

Distance Between Waypoints

Distance to Destination

Scroll to View Additional Info

- FitPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

FltPlan Go - Maps Page - Route With Waypoints

# DISTANCE MEASURING TOOL

Touch  to display the Measure Tool window, then touch anywhere on the Map to drop the first 'pin'. Touch anywhere on the Map to drop another 'pin' which will display the Total distance in the Measure Tool window. Multiple 'pins' can be created on the Map with the distance between the points listed in Nautical Miles (nm) on the Map.



Touch to View Distance Measuring Tool

Distance Between Two Points

Touch to Close


Touch to Reset

FltPlan Go - Maps - Distance Measuring Tool

## TIMER

Touch  to view the Timer.

Touch **Start** to begin the Timer, **Stop** when desired, and then **Reset** to begin from zero. Touch the 'X' to close the Timer.



FltPlan Go - Maps - Timer

## ACCOUNT

Touch the button in the top right corner, e.g.  to Add Account or Logout.

## LAYERS

Touch **Layers** to view the available **Online** base maps, **Offline** maps/charts, and **Overlay** options.

### ONLINE

Touch any of the options listed in the Online section, which include: North America, World, Satellite, Street, Topographic, and Shaded Relief.




FltPlan Go - Maps - Layers - Online Menu



**NOTE:** When the Downloaded Maps Only options is toggled 'On', a pop-up window will appear stating the User cannot view Online Maps. At the bottom of the pop-up window, touch **Turn off Downloaded Maps Only** to view both downloaded and online maps. To turn Downloaded Maps Only back on, touch **Map Options > Maps > Downloaded Maps Only**.

## OFFLINE

Touch any of the options listed in the Offline section, which include: Sectionals, Jet High, Victor Low, TACs, Helicopter, IFR Terminal, United States, Canada, and Caribbean.




FltPlan Go - Maps - Layers - Offline Menu


## OVERLAY

Touch any of the options listed in the Overlay section, which include: Customs, Temporary Flight Restrictions (TFRs), Stadiums, Airports, Fuel Prices (AvGas or Jet Fuel), Stadiums, State Outline, and Civil Air Patrol (CAP) Search Grid. Touch **Refresh** to update overlay data.

The User can adjust TFR, Stadium, and State Outline opacity by touching **Options** and moving the slider as desired.



FltPlan Go - Maps - Layers - Overlay Menu



FltPlan Go - Maps - Layers - Overlay - Options

## CUSTOMS

Touch **Customs** to display United States and Canadian customs locations on the Map. Touch the flag icon to view additional information.

Touch to Toggle Overlay 'On/Off'

The screenshot shows the Garmin flight planning application interface. At the top, there are navigation icons and a route identifier 'KTEB TO KLWC'. Below this is a menu bar with options: Layers, Route, Edit, METARs, MOS, Winds, Wx, XM, and ADS-B. Underneath the menu bar are buttons for 'Online', 'Offline', and 'Overlay'. The 'Layers' panel is open, showing a list of map overlays with checkboxes. 'Customs' is checked and highlighted. Other overlays include TFRs 19:42:16Z, Airports, Fuel Prices, AvGas, Jet Fuel, Stadiums, State Outline, and CAP Search Grid. Below the list are 'OPTIONS' and 'REFRESH' buttons. The main map area displays a detailed view of the Buffalo, NY region, including Niagara Falls and Buffalo Niagara International Airport (KBUF). A popup window for 'KBUF Customs' is overlaid on the map, providing contact information and operating hours. The popup includes a flag icon, the airport name 'KBUF Customs', location 'BUFFALO, NY', phone number '716-632-4727', and fax number. It also lists operating hours: '2 hrs advance notice required. Business hrs 0700-2359 Monday-Friday and 0700-2300 on Saturday & Sunday. \*Weekend arrivals call prior to 1600 on preceeding Friday Email buffaloairportcargo@cbp.dhs.gov'. At the bottom of the popup are 'AIRPORT INFO' and 'CLOSE' buttons.

Touch to View

Touch to Close

Touch to View Customs Info

FltPlan Go - Maps - Layers - Overlay - Customs

- FltPlan
- Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

## TEMPORARY FLIGHT RESTRICTIONS (TFRs)

Touch **TFRs** to display on the Map, which will be depicted by a Red circle. When online, the TFRs will automatically update everytime the Layers tab is selected, and present a time stamp (HH:MM) in Zulu time. Touch the TFR for additional information.

Touch **Refresh** to manually update Overlay data.

The screenshot shows the FltPlan Go app interface. At the top, there's a header with navigation icons and the text 'KTEB TO KLWC'. Below that is a 'Layers' tab selected among 'Route', 'Edit', 'METARs', 'MOS', 'Winds', 'Wx', 'XM', and 'ADS-B'. Under the 'Layers' tab, there are sub-tabs for 'Online', 'Offline', and 'Overlay'. A list of layers is shown with checkboxes: Customs, TFRs 20:02:17Z (checked), Airports, Fuel Prices, AvGas, Jet Fuel, Stadiums, State Outline (checked), and CAP Search Grid. At the bottom of the layers list are 'OPTIONS' and 'REFRESH' buttons. Below the layers list is a map showing a red circle representing a TFR. A popup window titled 'TFRs 1 of 2' is open over the map, displaying the following information:

<b>Notam Id</b>	2/2904
<b>Object Id</b>	35
<b>TFR Type</b>	Section_91_141
<b>TFR Area</b>	A28
<b>Lower Alt</b>	0
<b>L Alt Type</b>	MSL
<b>Upper Alt</b>	17999
<b>U Alt Type</b>	MSL
<b>Effective</b>	FROM:2022.05.12 22:15:00 UTC TO:2022.05.15

Annotations on the screenshot include: 'Touch to Toggle Overlay 'On/Off'' pointing to the TFRs layer checkbox; 'Touch to View Info' pointing to the TFR popup; 'Touch to View Additional TFR(s)' pointing to the 'NEXT' button in the popup; and 'Scroll to View Info' pointing to the bottom of the popup.

FltPlan Go - Maps - Layers - Overlay - TFRs

## STATE OUTLINE



**NOTE:** The State Outline layer has to be downloaded prior to viewing via **Downloads > Maps > Layers > STB.**

Touch State Outline to display a red outline defining each state's border. The User can adjust TFR, Stadium, and State Outline opacity by touching **Options** and moving the slider as desired.

Touch to Toggle Overlay 'On/Off' (pointing to the State Outline checkbox)

Touch to View/Adjust State Outline Opacity (pointing to the OPTIONS button)

FltPlan Go - Maps - Layers - Overlay - State Outline

### Overlay Options

TFRs & Stadiums Opacity

State Outline Opacity

Slide to Adjust

FltPlan Go - Maps - Layers - Overlay - Options


### AIRPORTS

Touch **Airports** to display all airports on the Map. Touch an airport icon to display additional information, such as Latitude, Longitude, City, and Fuel.

Touch **View Runways** to display the runway I.D., length and width.

Touch **View Airport** to view the selected airport in the Airports tab within Garmin Pilot.

Touch **View Procedures** to display the available charts and procedures.



FitPlan Go - Maps - Layers - Overlay - Airports

## FUEL PRICES

Touch **Fuel Prices** to display the price per gallon on the Map, then touch the desired octane, **AvGas** or **Jet Fuel**. A circle will be displayed with the airport ID, whether or not the fuel is Self Serve 'S', or Full Service 'F', and the price per gallon. Touch the circle to view additional information, e.g. Name of the FBO that provides the Fuel Service, Hours of Availability, After Hours Contact Info, Fuel Programs, etc.

The screenshot shows the 'Layers' menu in the FltPlan Go app. The 'Fuel Prices' option is checked and highlighted in green. Below it, 'AvGas' and 'Jet Fuel' are also visible. The map overlay shows several airports with fuel price callouts:

- KLWC**: F: 7.30
- KK64**: S: 4.99
- K34**: F: 6.05, S: 5.90, F: 6.25
- KMD**: F: 6.65, S: 6.25, F: 6.61
- KOJC**: F: 6.75
- KMCC**: F: 7.70, S: 5.26

Annotations on the image include:

- 'Touch to Toggle On/Off' pointing to the Fuel Prices checkbox.
- 'Touch to Display' pointing to the AvGas and Jet Fuel radio buttons.
- 'Touch to View Info' pointing to a callout circle for KMCC.
- 'Self Service Price Per Gallon' pointing to the 'S' price for KK64.
- 'Full Service Price Per Gallon' pointing to the 'F' price for KOJC.


FltPlan Go - Maps - Layers - Overlay - Fuel Prices - AvGas

- Account
- FitPlan
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index


### STADIUMS

Touch **Stadiums** to display Temporary Flight Restrictions (TFRs) related to a Stadium. Touch the Stadium icon to view additional information. If there are multiple stadiums within the same area, touch **Next** to view additional info.

The User can adjust TFR, Stadium, and State Outline opacity by touching **Options** and moving the slider as desired.



FltPlan Go - Maps - Layers - Overlay - Stadiums




FltPlan Go - Maps - Layers - Overlay - Options

## CIVIL AIR PATROL (CAP) SEARCH GRID



**NOTE:** The CAP Search Grid layer has to be downloaded prior to viewing via **Downloads > Maps > Layers > CAP.**

Touch **CAP Search Grid** to create a grid pattern, labeled and separated into quadrants, to aid in a Search and Rescue event.



Touch to Toggle On/Off

FitPlan Go - Maps - Layers - Overlay - CAP Search Grid

- FitPlan
- Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

## ROUTE

Touch **Route** to display informatoin regarding the planned route of flight, which includes: From, To, Distance (nm), Course, Time To (hhmm), Leg (nm), Arrival.

**NOTE:** The Route feature provides information that is intended for in-flight use. Once airborne, the various data points, e.g. Time To, Arrival, etc., will be calculated and displayed in real-time.

📍
⚙️
+
🔍
↕️

KTEB TO KLWC

🗨️
🕒
GARMIN

Layers	Route	Edit	METARs	MOS	Winds	Wx	XM	ADS-B
From	To	Course	Distance					
KTEB	ZIMMZ	279° M	48nm 945nm					
ZIMMZ	SPOTZ	271° M	12nm 933nm					
SPOTZ	MIKYG	255° M	22nm 911nm					
MIKYG	HOTEE	255° M	34nm 877nm					
HOTEE	BEETS	253° M	49nm 827nm					

Scroll to View Additional Waypoints


FltPlan Go - Maps Page - Route With Waypoints - U.S.

## GRAPHICALLY EDIT ROUTE

Long press on the Route to activate the 'rubber band', which allows the User to manually edit the Route to include an Airport, Navaid, or Waypoint.

Touch the arrow to expand or collapse the options bar, then select **Direct To**, **Add to Route**, or **Info**, as desired.

Touch **Close** to exit without saving.



FltPlan Go - Maps Page - Manually Adjust Route

## EDIT

Touch **Edit** to adjust flight plans that have been synced from the associated FltPlan.com account. Touch within the Edit box to manually enter text via the keyboard.



FltPlan Go - Maps Page - Edit

On the left side of the Edit menu, there are buttons to help the User complete standard tasks quickly: Reverse, P/P, Save, and Save/File.

### REVERSE

Touch the **Reverse** button to keep all the same fixes, but reverse the route.

### P/P

Touch the **P/P** button to load the Latitude and Longitude (Lat/Long) of the User's Present Position as a fix within the route

### SAVE

Touch the **Save** button to save the route(s) locally to the FltPlan Go program.

### SAVE/FILE

Touch the **Save/File** button to display a pop-up window with the following options: Web, which allows the User to create a flight plan on the Web via Fltplan.com, or App, which allows the User to file the flight plan via the FltPlan Go program.

**Create Flight Plan**

REFRESH PILOT & AIRCRAFT DATA

Date: 05/13/2022

IFR or VFR: IFR

Departure: KTEB

Arrival: KLWC

PIC / Captain: TEST PILOT

SIC / Co-Pilot: TEST PILOT

Aircraft: N2345B

Call Sign (optional):

Depart Time: 15:04

Souls on Board:

Alternate:

Suggested Altn:

Remarks:

P/u Clearance Fix (optional):

Route:  
ZIMMZ SPOTZ MIKYG HOTEET BEETS VINSE LEJOY AIR CORVS ZANDR BOWRR  
EMPTY CREEP FYLLS VHP JAAVE GORDO SPI BAYLI TWAIN SAAGS MCI

CLOSE SAVE SAVE & FILE

FltPlan Go - Maps - Edit - Save/File - App Options

On the right side of the Edit menu, there are buttons to help the User complete standard tasks quickly: Waypoints, Procedures, and S/R Grid.

## WAYPOINTS

Touch the **Waypoints** button to view and/or add User Waypoints. To create a Waypoint, touch the **Add** button to enter the Name, Description, and Location (Lat/Long), then touch **Add**. Touch **Show All** to view Waypoints on the Map.

Touch **Export** and select the desired program to share/save the Waypoint.

To delete a Waypoint, longpress the Waypoint to display a pop-up window confirming the desire to Delete, then touch **Yes**.

**Custom Waypoint**

Name: WORKIN'

Description: GARMIN HQ

Latitude: 38.85585

Longitude: -94.79965

Valid coordinate inputs:  
 41.12345 / -73.12345  
 41 25N / 073 58W  
 41 25.78N / 073 58.12W  
 41 25 45N / 073 58 57W

MANAGE CANCEL ADD

Touch to Enter Info

Touch to View/Edit Waypoints

Touch to Cancel

Touch to Save

FltPlan Go - Maps Page - Edit - Waypoints - Create

**User Waypoints**

WORKIN'  
38.85585 / -94.79965

EXPORT SHOW ALL

DELETE ALL CLOSE ADD

Longpress to Delete

Touch to Export

Touch to Delete All

Touch to Display All on Map

Touch to Exit

Touch to Create Waypoint

FltPlan Go - Maps Page - Edit - Waypoints Menu

- FitPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

FltPlan Go - Maps Page - Edit - User Waypoint Displayed

## PROCEDURES

Touch the **Procedures** button to view available Standard Instrument Departures (SIDs), Standard Arrival Routes (STARs) or Approaches on the Map.



**NOTE:** Not all airports have approved government approved Procedures. If this is the case, a textual note will be displayed stating such, e.g. 'No Sid/Stars Available For Airport'.



FltPlan Go - Maps Page - Edit - Procedures - Arrivals

### Adding a Procedure:

- 1) Touch  in the bottom right corner of the Map to view the Procedures Options menu listing Opacity, Departures, Arrivals, and Approaches.
- 2) Touch **Departures** to view a list of available SIDs for the Departure Airport.
- 3) Touch **Arrivals** to view a list of available STARs for the Destination Airport.
- 4) Touch **Approaches** to view a list of available Instrument Approaches for the Destination Airport.
- 5) Touch the **Add To** button to incorporate the procedure into the Route.
- 6) Touch the **Procedure** button to view the Procedure in Split Screen mode.

- FltPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

**SID / STAR Options**

Slide to Adjust Chart Overlay Opacity

Touch to Load Available Departures — **DEPARTURES (KLWC)** — **ARRIVALS (KIAD)** — Touch to Load Available Arrivals

**APPROACHES (KIAD)** — Touch to View Available Approaches

Select between 'Departures' or 'Arrivals' to load Sids or Stars.

Touch to Exit — **CLOSE** — **REMOVE** — Touch to Remove Current Procedure

FltPlan Go - Maps Page - Edit - Procedures - Options

**SID / STAR Options**

Slide to Adjust Chart Overlay Opacity

**DEPARTURES (KLWC)** — **ARRIVALS (KIAD)** — Current Selection

**APPROACHES (KIAD)**

- CAVLR4 >
- COATT5 >
- DELRO5 >
- DOCCS3 >
- Touch to Select — GIBBZ4 >

Touch to Exit — **CLOSE** — **REMOVE** — Touch to Remove Current Procedure

— Scroll to View Additional Info

FltPlan Go - Maps Page - Edit - Procedures - Arrivals

- 7) Once a Procedure is loaded, touch  in the bottom right corner of the Map to view a secondary Procedures Options menu, listing Opacity, Airport, Procedures, and Approaches.

### SID / STAR Options

BACK
SID/STAR Options
SHOW ALL —Touch to Show All on Map

	BKW.GIBBZ4 Star	
	GIBBZ.GIBBZ4 Star	
	HVQ.GIBBZ4 Star	
	MGW.GIBBZ4 Star	 <small>—Touch to Expand/Collapse</small>


ADD TO ROUTE
PROCEDURE

—Touch to Add Procedure to Route
—Touch to View Chart in Split Screen


—Touch to Exit
CLOSE
REMOVE
—Touch to Remove Current Procedure

FltPlan Go - Maps Page - Edit - Procedures - SID / STAR Options

- 8) Touch the desired fix along the SID/STAR, then press the **Procedure** button to view the chart in Split Screen mode.



Current Route



Touch to Rotate Image 90°

FltPlan Go - Maps Page - Edit - Procedures - STAR - Split Screen

- FitPlan Account
- Airports
- Maps**
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

KIAD Procedures	
	<a href="#">DOWNLOAD ALL</a>
Airport	
AIRPORT DIAGRAM	
Instrument Approaches (25)	
ILS OR LOC RWY 01R	
ILS OR LOC RWY 19L	
ILS OR LOC/DME RWY 01C	
ILS OR LOC/DME RWY 01L	
ILS OR LOC/DME RWY 12	
ILS OR LOC/DME RWY 19C	
ILS OR LOC/DME RWY 19R	

Touch to Download All Procedures

Successfully Downloaded

Touch to Select

Scroll to View Additional Info

FitPlan Go - Maps Page - Edit - Procedures - Approaches

KLWC TO KIAD

REVERSE

P/P

SAVE

SAVE / FILE

DONE

KLWC MGW MGW BRNDN HIROY JIMVE TABBE KIKKR IGGY MOSLE  
MONNK BMICH THZMN GIBBZ KIAD

WAYPOINTS

**PROCEDURES** ← Current Selection

S/R GRID

Current Route

ENABLE SHIP

BREADCRUMBS

ZULU TIME

16 JUN 2022

CASANOVA  
116.3 CSN  
Chan 110

Chan 58

289° R-109

109°

ELEV 313	D	TDZE 286	
TDZ/CL Rwys 1C, 1L, 1R, 12, 19C and 19R			
REIL Rwy 30			
HIRL all Rwys			

CATEGORY	A	B	C	D
S-ILS 1C	** 486/24 200 (200-½)			
S-LOC 1C	620/24 334 (400-½)		620/40 334 (400-¾)	
CIRCLING	940-1 627 (700-1)		1060-2½ 747 (800-2½)	

WASHINGTON, DC  
Amdt 2D 15JUL21

38°57'N-77°28'W

WASHINGTON DULLES INTL (TAD)

**ILS or LOC/DME RWY**

Accuracy 51 m

FltPlan Go - Maps Page - Edit - Procedures - Approach - Split Screen

- Account
- FitPlan
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

- FltPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

### SID / STAR Options

Slide to Adjust Chart Overlay Opacity

Current Selection — DEPARTURES (KAPA)    ARRIVALS (KLWC)

APPROACHES (KLWC)

- ECH001 >
- MRSHH2 >
- PIKES2 >
- Touch to Select — PLAIN1 >
- ROCKI5 >

Touch to Exit — CLOSE REMOVE — Touch to Remove Current Procedure

Scroll to View Additional Info

FltPlan Go - Maps Page - Edit - Procedures - Departures



FltPlan Go - Maps Page - Edit - Procedures - SID Selection on Map

- FitPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

- FitPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

Procedure Added to Route

KAPA TO KLWC

REVERSE

P/P

SAVE

SAVE / FILE

DONE

KAPA DEN EXTAN TXC GLD KLWC

WAYPOINTS

PROCEDURES

S/R GRID

ZULU TIME

Accuracy

51 m

Current Selection

Current Route

Touch to View Options

FitPlan Go - Maps Page - Edit - Procedures - SID on Map - Split Screen

## SR GRID

Touch the SR Grid button to input the desired grid details, which include the Waypoint, Pattern (Parallel, Sector, Expanding Square, Creeping Line, Route, or Grid Aligned), Initial Degrees, Initial Turn, Leg Length (nm), Space Length, (nm), and Leg Count.

Touch **Add** to display the SR Grid on the map.

Touch **Cancel** to close without saving. Each leg of the SR Grid will be displayed in the 'Edit' window along with a Map overlay.

Touch **Clear** to remove the SR Grid.

Add to Route

Waypoint:	KLWC		
Pattern:	Parallel		
Initial Degrees:	360		
Initial Turn:	<div style="background-color: #0070C0; color: white; padding: 5px 10px; border-radius: 5px;">Left</div> <div style="background-color: #D9E1F2; padding: 5px 10px; border-radius: 5px;">Right</div>	Touch to Enter / Adjust Info	
Leg Length (nm):	5		
Space Length (nm):	0.5		
Leg Count:	10		
Touch to Close Without Saving	<div style="background-color: #0070C0; color: white; padding: 10px 20px; border-radius: 5px; display: inline-block;">Cancel</div>	<div style="background-color: #0070C0; color: white; padding: 10px 20px; border-radius: 5px; display: inline-block;">Add</div>	Touch to Save & View SAR Grid on Map

FltPlan Go - Maps Page - Edit - SR Grid Options

- FitPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index



Touch to Clear Grid Pattern

FltPlan Go - Maps Page - Edit - SAR Grid

## IMPORTING KMZ, KML, CSV, CUSTOM WAYPOINTS

The FltPlan Go program allows the User to send various file types from a device. The first step is getting the file on the device to allow for an upload to FltPlan Go. One way to accomplish this task would be emailing the file to yourself, then opening the file from your device running FltPlan Go, then touch the emailed attachment to allow FltPlan Go to open the file automatically, or prompt the User with other program options that can open the file.

Another option would be to Airdrop the files onto the device running FltPlan Go.



**NOTE:** To import a CSV file, the formatting must follow the exact format template to be rendered transferable: WAYPOINT, LAT, LONG, DESCRIPTION.

## METARS

Touch the **METARS** tab to display a drop-down menu with settings for Ceiling, Visibility, Wind Speed, and Temperature. Touch the text box with a numeric value to adjust the color coded circles (magenta, red, blue, or green) as desired to align with personal and/or equipment limitations. These circles will then be displayed based on the Map, allowing the User to view airport METARs across the country at a glance. Toggle the checkmark On/Off next to Show METARs Layer, Ceiling, Visibility, Wind Speed, and Temperature. The parameters of a route will be automatically tabulated with the default METARs data settings. After inputing and adjusting the parameters, the User can return to the default settings by touching the **Reset Defaults** button.

Touch the **Refresh** button to update the weather data.

Touch a METAR circle on the map to display information for the selected airport.

**Touch to Adjust**

**Touch to Refresh**

**Touch to Reset**

**Touch to Toggle Display On/Off**


**Data Refresh Info** - Last Updated: 15:44:22Z - 2022-May-20

FltPlan Go - Maps Page - METARs Overlay

- FitPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

Touch the dot at an airport on the Map to view the METAR details via pop-up window displaying the Airport ID, e.g. KLWC, Ceiling (ft), Visibility (sm), Wind Speed (kts), and Temperature. The color of the dot will be represented by the most severe of the selected weather conditions.

At the bottom of the pop-up window, there are two buttons, **View Procedures** and **View Airport**. Touch the **View Procedures** button to view instrument procedures for selected airport. Touch the **View Airports** button to open the Airports Tab for the selected airport.



FltPlan Go - Maps Page - METARs - Individual Airport

## MOS

Model Output Statistics (MOS) forecasts include important and practical details necessary for pre-flight planning. Potentially significant, location-specific factors such as terrain characteristics and weather anomalies not accounted for in traditional forecasts are factored into the MOS forecast. MOS forecasts provide weather data for up to 4 days out, presented in 3-hour windows, and refreshed hourly. FltPlan.com's MOS weather on FltPlan Go is unique, as the extra layer of information along the route of flight is easy to read quickly for more than 2,000 airports. Should the destination airport not have a MOS forecast, Flight Plan Go will provide information for the nearest MOS reporting airport.

Touch the **MOS** tab to display a menu which lists options for the MOS layer: Ceiling (ft), Wind Speed (knots), Visibility (miles), Temperature (°F), Date (Day of the Week, MM/DD/YYYY), and a Zulu Time (HH:MM).

### Enabling MOS:

- 1) Toggle the checkmark On/Off next to **Ceiling, Visibility, Wind Speed, and Temperature.**
- 2) Touch the desired **Date** and **Time.**
- 3) Touch the **Legend** button to view the parameters for color designation.
- 4) Touch the **Refresh** button to update the weather data.
- 5) Touch the **Display** button to enable the MOS overlay.
- 6) Touch the **Remove** button to disable the MOS overlay.
- 7) Touch a MOS circle on the map to display information for the selected airport.

FltPlan Go - Maps Page - MOS Overlay

MOS Legend			
Ceiling (100s Feet)			
LIFR	IFR	MVFR	VFR
< 5 ≤	< 10 ≤	< 30 ≤	
Visibility (Miles)			
LIFR	IFR	MVFR	VFR
< 1 ≤	< 3 ≤	< 5 ≤	
Wind Speed (Knots)			
Real Windy	Windy	Breezy	Light
> 30 ≥	> 20 ≥	> 10 ≥	
Temperature (°C / °F)			
Cold	Mild	Hot	
≤ 0 / 32 <	< 30 / 86 ≤		

Touch to Refresh Weather Data

KSGF	
MOS Weather Forecast	
RELOAD DATA	
<b>Sun 05/22/2022 00:00Z</b>	
Ceil:	Vis:  Wind:  Temp:
Clouds: OVC 500 - 1000 ft Vis: 2 to 3 mi Mist Wind: 34022kt Temp: 55° Prob. Rain: 65%	
<b>Sun 05/22/2022 03:00Z</b>	
Ceil:	Vis:  Wind:  Temp:
Clouds: OVC 500 - 1000 ft Vis: 3 to 5 mi Mist Wind: 36015kt Temp: 51° Prob. Rain: 65%	
<b>Sun 05/22/2022 06:00Z</b>	
Ceil:	Vis:  Wind:  Temp:

FltPlan Go - Maps - MOS Legend & MOS Forecast Individual Airport

# WINDS



**NOTE:** An internet connection must be established to view Wind information.

Touch the **Winds** tab to display a menu listing the following overlay options; Wind Speed (knots) and Altitude (ft), United States / CONUS, Canada / Alaska. Winds can be displayed as either Color Coded Arrows or Wind Barbs.

## Enabling Winds:

- 1) Toggle the checkmark On/Off next to **Wind Speed**.
- 2) Touch the altitude box and select desired altitude.
- 3) Toggle the checkmark next to **United States/CONUS** (Continental United States), **Canada/Alaska, Northern Hemisphere**.
- 4) If necessary, toggle the checkmark next to **Use Low/Slow Scale**, for details related to lower altitudes.
- 5) Adjust the overlay display by selecting **Color Coded Arrows** or **Wind Barbs**.

The screenshot shows the 'Winds' settings menu in the FltPlan Go application. The menu is titled 'Winds' and includes the following options:

- Wind Speed (kts) at
- United States / CONUS
- Canada / Alaska
- Display Winds as**
  - Color coded arrows
  - Wind barbs
- Use Low / Slow Scale

Additional UI elements and annotations include:

- Touch to Select Altitude:** Points to the 'FL410' input field.
- Touch to Toggle Display On/Off:** Points to the checkmarks for 'Wind Speed', 'United States / CONUS', and 'Canada / Alaska'.
- Touch to View:** Points to the 'Winds' tab in the top menu.
- Touch to Toggle On/Off:** Points to the 'Use Low / Slow Scale' checkbox.
- Data Refresh Info:** Points to the 'Last Updated: 14:22:52Z - 2022-May-23' text.
- Touch to Refresh Weather Data:** Points to the 'REFRESH' button.
- Touch to Close:** Points to the close icon (X) in the 'Winds' info popup.
- Touch to View Info:** Points to the 'Winds' info popup.

The map below the menu shows a grid of color-coded wind arrows. A blue airplane icon is positioned on the map, and a 'Winds' info popup is displayed above it, showing the following data:

Winds	
Altitude:	FL410
Direction:	237°
Wind Speed:	70 kts
ISA Temp:	-4

FltPlan Go - Maps Page - Winds - Color Coded Arrows Overlay - High Altitude

When Color Coded Arrows are initially selected, the default wind velocity scale ranges from 30 knots to 150 knots, but there will be an additional option to view the winds on a different scale entitled 'Use Low/Slow Scale'. Enabling this option will adjust the wind velocity scale range to 10 knots to 45 knots.

Toggle the checkmark On/Off next to **Use Low/Slow Scale**, as desired.

**Winds**

- Wind Speed (kts) at 11,000
- United States / CONUS
- Canada / Alaska

**Display Winds as**

- Color coded arrows
- Wind bars

Use Low / Slow Scale

Last Updated: 14:22:52Z - 2022-May-23

**REFRESH**


**Winds**

- Altitude: 11,000
- Direction: 175°
- Wind Speed: 21 kts
- ISA Temp: +1

FltPlan Go - Maps Page - Winds - Color Coded Arrows Overlay - Low/Slow

Touch the wind indicator (arrow or barb) on the Map to view specific information detailing the Altitude (ft), Direction (radial degrees), Wind speed (kts) and Temperature (°C).

Touch the **Refresh** button to update the weather data.



FltPlan Go - Maps Page - Winds - Wind Barbs

## WEATHER (WX)



**NOTE:** An internet connection must be established to view information within the Weather tab.




**NOTE:** Radar animation is not available when multiple Radar layers are selected.

Touch the Weather tab to display a menu listing Baron Weather options, such as; U.S. Radar, Canadian Radar, Alaskan Radar, Surface Analysis, IR Satellite, Visible Satellite, Echo Tops, and Lightning.

### Enabling Weather:

- 1) Toggle the desired layers On/Off by touching the checkmark.
- 2) Slide the Weather Opacity tool, as desired.
- 3) When a Radar option is enabled  will be displayed in the bottom right corner of the Map.
- 4) Touch  to animate the weather in 10 minute intervals, then  to stop animation.



FltPlan Go - Maps - Weather - U.S. Radar & Lightning

## XM (OPTIONAL)

Touch the XM button to view connection options. Touch either **Connect via WiFi**, or **Connect via GDC64**.

### Connecting to Baron Mobile Link System

- 1) From the device, e.g. Samsung Galaxy S7 Tab, go to **Settings** and connect the WiFi to Mobile Link.
- 2) Once the Mobile Link is connected, there will be a slight delay to allow the XM Receiver to fully initialize (this can take several minutes).
- 3) Open FltPlan Go.
- 4) Touch the **Maps** tab > **XM**.



**NOTE:** If an error is received when navigating to the XM weather menu, the most common cause is due to the lengthy initializing stage required for the XM Radio.

- 5) From the XM menu, touch the desired weather to display.

## ADS-B

Once an ADS-B device has been connected via the External tab, touch **Maps > ADS-B** to display a menu listing available data overlays, graphics, and information. The first column contains the options, CONUS (Continental United States) Radar, Regional Radar, PIREPs, NOTAMS, METARs, TAFs, Traffic, and Traffic Breadcrumbs. Once enabled, the PIREPs, NOTAMS, METARs and TAFs will be overlaid on the Map. NOTAMS appear as purple squares, METARs as green squares, and TAFs as blue squares. PIREPs will be displayed via the appropriate symbol. Touch the weather and traffic icons on the Map to view additional information.

Touch  next to Traffic to display the legend and options, which include Minimize Distant Traffic, Hide Distant Traffic, and Display Relative Altitude.

- Enable **Minimize Distant Traffic** to hide the gray ring around the traffic.
- Enable **Hide Distant Traffic** to hide the distant traffic.
- Enable **Display Relative Altitude** to display the relative altitude of the traffic.

The second column within the ADS-B menu contains information detailing the number of weather stations used to collect data. Touch **Refresh** to refresh the connection. Touch **Disconnect** to remove the device connection.

### Traffic Settings

Callsign:  Touch to Enter Info

-  Within 2,000 ft & 5 miles
-  Within 3,000 ft & 8 miles
-  Greater than 3,000 ft & 8 miles
- Minimize distant traffic
- Hide distant traffic
- Display relative altitude

Touch to Toggle 'On/Off'

FltPlan Go - Maps - ADS-B - Traffic Legend & Settings

Touch to View

Touch to Refresh ADS-B Connection

Touch to Remove ADS-B Connection

Touch to Toggle On/Off

Touch to View/Adjust Settings

Slide to Adjust Opacity

Selected Traffic Info

Current Location

Touch to View Info

CONUS blocks:	0   N/A
Regional blocks:	0   N/A
PIREPs:	0   N/A
NOTAMs:	0   N/A
METARs:	0   N/A
TAFs:	0   N/A
Traffic:	3

FltPlan Go - Maps - ADS-B




**NOTE:** The User must be connected to an ADS-B device in order to receive current Weather, NOTAMs, TAFs, METARs, AIRMETS, and SIGMETs.

- Account
- FltPlan
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

## HEAD-UP DISPLAY (HUD)

Located on the bottom of the screen, the HUD displays flight information, which includes; GPS Accuracy, Ground Speed, Lat/Long, Altitude, and True Course. This information is updated in real time based upon the tablet's GPS or a properly configured and connected external GPS / ADS-B device. If the HUD is hidden, touch in the bottom right corner and then slide Left, across the screen, to display the HUD. To hide the HUD information banner, slide the information banner to the Right.



Slide Right to Hide HUD Info

FltPlan Go - Maps - GPS Signal Acquired

## AUTO CENTER

The Auto Center button is located in the bottom right corner, just above the HUD information banner. Touch to center the Map to the current location of the aircraft. When activated, the Auto Center button appears green and will automatically recenter the Map back to the aircraft after the User is done scrolling. To disable the Auto Center feature, touch again, turning the button grey.



Selecting the NavLogs icon from the Home Menu will guide the User to NavLog section, highlighting NavLog Options, Split Screen Options, Connectivity, My NavLogs/WX, Share/Save Options, Print Options, and Account Options.

Touch to View/  
Download NavLog

KIXD TO KSTP

GARMIN

FitPlan.com
Navigation Log
Tuesday 05-24-22

Dept: 1030L (GMT-5) - Arr: 1143L (GMT-5)

N2345B	IFR	GenAv	C525/L	Equip: SGRW/PU1	ASOS Ph: 913-780-6987/135.32
Dep: KIXD	1530Z	352kts	FL370	Route (see below)	Cinc: 888-766-8267 (57)
Dest: KSTP	ETE: 1:13		Altn: KMSP		FSS: 800-992-7433 (1-57)
Item 18: PBN/C2D2 DOF/220524 REG/N2345B SUR/282B CODE/ABCDEF					ATC Cinc issues? FitPlan:1-203-262-8383
Item 19: FOB: 0349 SOB: 4 PIC:TEST PILOT (sic:test pilot)					Elev:1087 Gnd:124.3 Twr:133.0

Filed: ROYAL9.TONCE TWOLF.TWOLF3

KIXD TO KSTP : TC=13° : (FMS winds: 193° / 46) : MC= 9° : ST. LINE=375nm : AIRWAY=377nm : Extra=1%

Winds Aloft	FL410 ISA(-57) Comp	FL370 ISA(-57) Comp	FL350 ISA(-54) Comp	FL330 ISA(-50) Comp
TONCE	242/068 -05 +032	234/076 -03 +045	228/073 -00 +050	224/070 +02 +052
TWOLF	257/086 -04 +032	249/107 -03 +054	243/105 +00 +062	243/101 +01 +061
KGEEE	258/088 -04 +011	253/112 -03 +022	248/110 +00 +032	246/106 +02 +036
Avg. Trip Winds=>	+ 30 Tailwind	+ 46 Tailwind	+ 53 Tailwind	+ 54 Tailwind
FLT TIME==>	1:17(+04) 332TAS	1:13(+00) 352TAS	1:11(-02) 366TAS	1:11(-02) 369TAS
Fuel Burn==>	1,225 Lbs	1,186 Lbs	1,186 Lbs	1,200 Lbs

FIX	ST	LAT/LON	InB/Out	Mag	Crs	Leg	Rem	Fuel Burn	Leg	Rem	ETE	ATA	WX
KIXD OLATHE	KS	N3849.9W09453.4	--/011	0	377	100	100.0	0:00	1:13	0:00			
SEE DP FOR ROUTE PRIOR TO MCI VOR													
MCI 113.25KANSAS CITY	MO	N3917.1W09444.2	010/000	28	349	196	295.8	0:08	1:05	0:08			N/A
JDOGG 113.25/40	MO	N3957.0W09439.7	000/004	40	309	132	427.8	0:08	0:57	0:16			N/A
TONCE	MO	N4016.9W09437.4	004/014	20	289	46	473.7	0:03	0:54	0:19			N/A
TWOLF	IA	N4317.0W09333.1	015/003	186	103	371	844.3	0:29	0:25	0:48			N/A
KGEEE	MN	N4344.9W09330.5	003/004	28	75	63	907.6	0:05	0:20	0:53			N/A
LYNKS	MN	N4406.9W09328.4	004/004	22	53	54	961.3	0:04	0:16	0:57			N/A
TRGET	MN	N4413.9W09327.7	004/022	7	46	18	979.2	0:01	0:15	0:58			N/A
SEE STAR FOR ROUTE AFTER TRGET INTERSECTION													
KSTP ST. PAUL	MN	N4456.1W09303.6	022/--	46	0	207	1186	0:15	0:00	1:13			

**EL:705 Atis: 118.35 Twr: 119.1 Gnd: 121.67** Fuel hourly method: 1,373

**ALTN:** KMSP MINNEAPOLIS MINNEAPOLIS-ST. PAUL INTL\_MN | Alt: **FL030** Brg **245°** 8nm Time: **0:04** Fuel **139**

Fuel (lbs.) | Taxi: 100 | Trip: 1,086 | Altn: 139. | 45 min: 555 | Extra: 1,227 | **PFOB: 3,107** | **Min Fuel Required: 1,880**

Extra Fuel Reduced to Meet Maximum Takeoff Weight Requirements

Fuel Order: 1,607 lbs./240 gal.

Weights(lbs.)	OEW: 6,593	Payload: 800	ZFW: 7,393
---------------	------------	--------------	------------

TOLD	PTXW:	10,500	MTXW:	10,500/	Performance	Runway	Wind/QNH/OAT
KIXD	PTOW:	10,400	MTOW:	10,400/TS	MRTW:	10,400/A	36 T08010KT/29.99/+12
KSTP	PLDW:	9,314	MLDW:	9,700/S	MRLW:	9,700/C	14 T13008KT/30.22/+18
KMSP	PLDW:	9,175	MLDW:	9,700/S	MRLW:	9,700/C	22 T15007KT/30.23/+13

Scroll to View  
Additional Info

FitPlan Go - NavLogs

NavLog Options

Connectivity Options

Touch to View Saved/Online NavLogs

KIXD TO KSTP

Print Options

Touch to Logout or Add Account

GARMIN


Split Screen Options

Email/Share Options

FitPlan Go - NavLogs - Banner Menu

## NAVLOG OPTIONS

The first button in the NavLogs banner menu is Options. Touch  to view a menu with the following options: Refresh Current NavLog, Download all NavLogs for Today, Departure Airport, and Arrival Airport.



FltPlan Go - NavLogs - Options

### REFRESH CURRENT NAVLOG

Touch **Refresh Current NavLog** to refresh/update the NavLog following any route changes or weather updates.


Touch **Download All NavLogs for Today** to download NavLogs dated for today. Once all NavLogs have been downloaded a green message will appear stating 'NavLogs Downloaded'.

Touch **Departure Airport** to be redirected to the Airports Page, highlighting the departure airport's information.

Touch **Arrival Airport** to be redirected to the Airports Page, highlighting the arrival airport's information.

## SPLIT SCREEN OPTIONS

Touch  to display a drop-down menu with various Split Screen options that can be displayed simultaneously, such as; Airports, Flight Instruments (AHRS), Departure Airport Procedures, Arrival Airport Procedures, Howgozit, Checklsit, and Weather. Touch the desired display option to view one of the Split Screen Options in conjunction with with NavLogs simultaneously, in either vertical or horizontal orientation.



FltPlan Go - NavLogs - Split Screen Options

KIXD TO KSTP
Garmin

Navigation Log
Tuesday 05-24-22  
Dept: 1030L (GMT-5) - Arr: 1143L (GMT-5)

N2345B	IFR	GenAv	C525/L	Equip: SGRW/PU1	ASOS Ph: 913-780-6987/135.32
Dep: KIXD	1530Z	352kts	FL370	Route (see below)	Clnc: 888-766-8267 (57)
Dest: KSTP	ETE: 1:13		Altn: KMSP		FSS: 800-992-7433 (1-57)
Item 18: PBN/C2D2 DOF/220524 REG/N2345B SUR/282B CODE/ABCDEF				ATC Clnc issues? FltPlan:1-203-262-8383	
Item 19: FOB: 0349 SOB: 4 PIC:TEST PILOT (sic:test pilot)				Elev:1087 Gnd:124.3 Twr:133.0	

Filed: ROYAL9.TONCE TWOLF.TWOLF3

KIXD to KSTP : TC=13° : (FMS winds: 193°/ 46) : MC= 9° : ST. LINE=375nm : AIRWAY=377nm : Extra=1%

Winds Aloft	FL410 ISA(-57) Comp	FL370 ISA(-57) Comp	FL350 ISA(-54) Comp	FL330 ISA(-50) Comp
TONCE	242/068 -05 +032	234/076 -03 +045	228/073 -00 +050	224/070 +02 +052
TWOLF	257/086 -04 +032	249/107 -03 +054	243/105 +00 +062	243/101 +01 +061
KGEE	258/088 -04 +011	253/112 -03 +022	248/110 +00 +032	246/106 +02 +036
Avg. Trip Winds=>	+ 30 Tailwind	+ 46 Tailwind	+ 53 Tailwind	+ 54 Tailwind
<b>FLT TIME==&gt;</b>	<b>1:17(+04) 332TAS</b>	<b>1:13(+00) 352TAS</b>	<b>1:11(-02) 366TAS</b>	<b>1:11(-02) 369TAS</b>
<b>Fuel Burn==&gt;</b>	<b>1,225 Lbs</b>	<b>1,186 Lbs</b>	<b>1,186 Lbs</b>	<b>1,200 Lbs</b>

FIX	ST	LAT/LON	InB/Out Mag Crs	Leg	Rem	Fuel Burn Leg Tot.	Leg	Rem	ETE	ATA	WX
KIXD OLATHE	KS	N3849.9W09453.4	---/011	0	377	100 100.0	0:00	1:13	0:00		
SEE DP FOR ROUTE PRIOR TO MCI VOR											
MCI 113.25KANSAS CITY	MO	N3917.1W09444.2	010/000	28	349	196 295.8	0:08	1:05	0:08		N/A
JDOG 113.25//40	MO	N3957.0W09439.7	000/004	40	309	132 427.8	0:08	0:57	0:16		N/A
TONCE	MO	N4016.9W09437.4	004/014	20	289	46 473.7	0:03	0:54	0:19		N/A
TWOLF	IA	N4317.0W09333.1	015/003	186	103	371 844.3	0:29	0:25	0:48		N/A

Touch to Refresh Weather Data
KIXD
Touch to Change Airport

### Forecast

**KIXD**

This Afternoon	Tonight	Wednesday	Wednesday	Thursday	Thursday	Friday	Friday	Saturday	Saturday	Sunday	Sunday	Memorial Day
Showers	Showers	Chance	Chance	Chance	Partly Cloudy	Sunny	Mostly Clear	Sunny	Partly Cloudy	Mostly Sunny	Partly Cloudy	Mostly Sunny
High: 62°F	Low: 59°F	High: 66°F	Low: 53°F	High: 65°F	Low: 51°F	High: 77°F	Low: 60°F	High: 83°F	Low: 67°F	High: 86°F	Low: 69°F	High: 87°F

### Metar Report

05/24/2022 18:18 UTC

KIXD 241811Z 07013G22KT 4SM RA BR BKN008 BKN023 OVC095 13/12 A2991 RMK A02 CIG 006V015 P0002 T01280117

KIXD 241808Z 08014G22KT 5SM -RA BR SCT008 BKN070 OVC095 13/12 A2992 RMK A02 P0001 T01280117

KIXD 241753Z 07012G20KT 4SM -RA BR SCT012 BKN075 OVC095 13/12 A2991 RMK A02 SLP124 P0014 60043 T01280117 10128 20117 58021

KIXD 241737Z 07013G19KT 3SM RA BR FEW007 BKN012 OVC085 13/12 A2994 RMK A02 P0012 T01280117

Touch to Refresh Weather Data

Touch to Change Airport

Scroll to View Additional Info

FltPlan Go - NavLogs - Split Screen - Weather

- Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

190-02961-00 Rev A

FltPlan Go for Android User's Guide


77

## HOWGOZIT

**NOTE:** Prior to selecting Howgozit, please ensure the the correct route is selected by touching the route from the drop-down menu or creating the route by touching **Maps > Edit**.

**NOTE:** Please ensure the latest NavLog is downloaded to ensure the best data is available for calculations.

Within the Split Screen Options menu, touch **Howgozit** to log flight times, legs, and fuel burn in real time. This data is then compared with projections/expectations and generates a score based upon actual flight/leg time vs. expected fuel burn.




FltPlan Go - NavLogs - Split Screen Options

To enter data points along the route, the User, upon passing a waypoint, will enter the time over the waypoint and the fuel on board. Howgozit then displays a new accurate ETA and fuel on board upon landing. If the User's device has GPS signal, Howgozit will automatically display the time over the fix without User intervention.

**NOTE:** The autogenerated Howgozit times over a fix are based upon the NavLog ground speed, not the current ground speed.


Touch to display a pop-up window with the Departure Date (MM/DD/YYYY), Time (HH:MMZ), and Now buttons at the top. Touch the **Departure Date** button to display the date currently imported from the NavLog. To change the Date, touch the date listed in the secondary pop-up window, then set the date by 'spinning' the Month, Date, and Year.

Touch **OK** to save, or **Cancel** to exit without saving.



FltPlan Go - NavLogs - Split Screen - Howgozit - Settings - Date Selection

Touch the **Departure Time** button to display the time currently imported from the NavLog. To change the Departure Time, touch the time listed in the secondary pop-up window, then set the time by 'spinning' the hours and minutes accordingly.



FltPlan Go - NavLogs - Split Screen - Howgozit - Settings - Time Selection

Touch the **Now** button to set the departure date and time to the present date and time.

Enter Fuel On Board manually (lbs) and touch **Ok** to save the data, or **Close** to exit without saving.

Touch **Howgozit** to display the following data that was pulled from the NavLog: Departure (Zulu), Estimated Arrival (Zulu), Updated Arrival (Zulu), Updated Landing Fuel, and various fixes along the route. Touch the checkmark next to Auto Update to allow the GPS to automatically calculate the Estimated Time of Arrival (ETA), Actual Time of Arrival (ATA), and Score during the flight.

Departure: **17:00 Z**      Updated Arrival: **18:13 Z** ⚙️ *Touch to View/Adjust*  
 Est. Arrival: **18:13 Z**      Updated Fuel: **1,914**

Location	Time		Fuel		Score	
	Fix	ETA	ATA	Fuel	Actual	Score
KIXD	17:00 Z	17:00 Z	0	3,100	3,100	0
MCI	17:08 Z	--	--	2,804	--	--
JDOGG	17:16 Z	--	--	2,672	--	--
TONCE	17:19 Z	--	--	2,626	--	--
TWOLF	17:48 Z	--	--	2,256	--	--
KGEEE	17:53 Z	--	--	2,192	--	--
LYNKS	17:57 Z	--	--	2,139	--	--
TRGET	17:58 Z	--	--	2,121	--	--
KSTP	18:13 Z	--	--	1,914	--	--

▶       **Auto Update** *Touch to Toggle On/Off*

*Touch to Adjust Time/Fuel on Board Upon Arrival to Fix*

FltPlan Go - NavLogs - Split Screen - Howgozit

Once the fixes along the route have been imported, the User can adjust the Arrival Data by touching the desired fix/waypoint which displays a window for Arrival data. Enter the Time (Zulu) or press the **Now** button to load the current time. Touch within the Fuel on Board text box to manually enter information.

Touch **OK** to save any adjustments.

Touch **Delete** to remove the fix/waypoint from the route.

Touch **Close** to exit without saving.

Once the data has been entered, the Howgozit section will calculate a Score for each leg and present the data as green text if there was an improvement from the NavLog expectations, black text if the data was the same as the NavLog expectations, or red text if the data was a downgrade from the NavLog expectations.

KIXD TO KSTP
Print
Email
GARMIN

FitPlan.com
Navigation Log
Tuesday 05-24-22  
Dept: 1030L (GMT-5) - Arr: 1143L (GMT-5)

N2345B	IFR	GenAv	C525/L	Equip: SGRW/PU1	ASOS Ph: 913-780-6987/135.32
Dep: KIXD	1530Z	352kts	FL370	Route (see below)	Clnc: 888-766-8267 (57)
Dest: KSTP	ETE: 1:13		Altn: KMSP		FSS: 800-992-7433 (1-57)
Item 18: PBN/C2D2 DOF/220524 REG/N2345B SUR/282B CODE/ABCDEF				ATC Clnc issues? FitPlan: 1-203-262-8383	
Item 19: FOB: 0349 SOB: 4 PIC:TEST PILOT (sic:test pilot)				Elev:1087 Gnd:124.3 Twr:133.0	

Filed: ROYAL9.TONCE TWOLF.TWOLF3

KIXD to KSTP : TC=13° : (FMS winds: 193° / 46) : MC= 9° : ST. LINE=375nm : AIRWAY=377nm : Extra=1%

Winds Aloft	FL410 ISA(-57) Comp	FL370 ISA(-57) Comp	FL350 ISA(-54) Comp	FL330 ISA(-50) Comp
TONCE	242/068 -05 +032	234/076 -03 +045	228/073 -00 +050	224/070 +02 +052
TWOLF	257/086 -04 +032	249/107 -03 +054	243/105 +00 +062	243/101 +01 +061
KGEEE	258/088 -04 +011	253/112 -03 +022	248/110 +00 +032	246/106 +02 +036
Avg. Trip Winds=>	+ 30 Tailwind	+ 46 Tailwind	+ 53 Tailwind	+ 54 Tailwind
FLT TIME==>	1:17(+04) 332TAS	1:13(+00) 352TAS	1:11(-02) 366TAS	1:11(-02) 369TAS
Fuel Burn==>	1,225 Lbs	1,186 Lbs	1,186 Lbs	1,200 Lbs

FIX	ST	LAT/LON	InB/Out Mag Crs	Leg	Rem	Fuel Burn Leg Tot.	Leg	Rem	ETE	ATA	WX
KIXD OLATHE	KS	N3849.9W09453.4	---/011	0	377	100 100.0	0:00	1:13	0:00		
SEE DP FOR ROUTE PRIOR TO MCI VOR											
MCI 113.25KANSAS CITY	MO	N3917.1W09444.2	010/000	28	349	196 295.8	0:08	1:05	0:08		N/A
JDOGG 113.25//40	MO	N3957.0W09439.7	000/004	40	309	132 427.8	0:08	0:57	0:16		N/A
TONCE	MO	N4016.9W09437.4	004/014	20	289	46 473.7	0:03	0:54	0:19		N/A
TWOLF	IA	N4317.0W09333.1	015/003	186	103	371 844.3	0:29	0:25	0:48		N/A

Departure: 17:00 Z

Est. Arrival: 18:13 Z

Updated Arrival: 18:12 Z

Updated Fuel: 1,918

*Touch to View Howgozit Settings*

Location	Time			Fuel			
	Fix	ETA	ATA	Score	Fuel	Actual	Score
KIXD	17:00 Z	17:00 Z		0	3,100	3,100	0
MCI	17:08 Z	17:09 Z		+1	2,804	2,704	-100
JDOGG	17:16 Z	17:17 Z		+1	2,672	2,602	-70
TONCE	17:19 Z	17:18 Z		-1	2,626	2,630	+4
TWOLF	17:48 Z	--	--	--	2,256	--	--
KGEEE	17:53 Z	--	--	--	2,192	--	--
LYNKS	17:57 Z	--	--	--	2,139	--	--
TRGET	17:58 Z	--	--	--	2,121	--	--
KSTP	18:13 Z	--	--	--	1,914	--	--

*Touch to Adjust Time/Fuel on Board* →

→ *'Score' for Leg of Route*

FitPlan Go - NavLogs - Split Screen - Howgozit Scores

### MY NAVLOGS/WX

Touch the button at the top, center, with the Departure and Arrival airport ID's, e.g. **KTEB TO KLWC** to display a menu listing My NavLogs/Wx.

Touch the desired NavLog to download to the device.

Touch the refresh arrow to refresh the downloaded NavLogs.

**My NavLogs / Wx**

RELOAD DATA — Touch to Refresh All NavLogs

<b>KIXD to KSTP</b> Tue. 5/24, 10:30 N2345B - GARMIN	0 minutes old	Touch to Refresh NavLog
<b>KSTP to KMDW</b> Wed. 5/25, 08:00 N2345B - GARMIN	0 minutes old	Touch to Refresh NavLog
<b>KMDW to KIAD</b> Thu. 5/26, 08:00 N2345B - GARMIN	Not Downloaded	Touch to Download NavLog to Device
<b>KIAD to KFXE</b> Fri. 5/27, 09:00 N2345B - GARMIN	Not Downloaded	
<b>KFXE to KRY Y</b> Sat. 5/28, 10:00 N2345B - GARMIN	Not Downloaded	
<b>KRY Y to KIXD</b> Sun. 5/29, 18:00 N2345B - GARMIN	Not Downloaded	

NavLogs Saved to Device for Offline Use

NavLogs Available Only While Online

FltPlan Go - NavLogs Page - My NavLogs / WX

### SYNCING NAVLOGS

When a flight plan is created in FltPlan.com, the flight information, including NavLogs, Routes, Weight & Balance Calculations, and Checklists, are synced to the FltPlan Go program.



**NOTE:** After creating a flight plan on FltPlan.com and generating a NavLog, the User needs to touch the Save button, which will allow the FltPlan Go program to import the NavLog and save for offline viewing.

## NAVLOG INFORMATION

Once a route has been crated in the FlPlan.com page, touch **Press Here for NavLog** to view a long list of pertinent information for the flight, such as Navigation Log, Trip Notes, Winds Matrix, Weather Info, and Airport Diagrams for the Departure and Arrival Airports.

### NAVIGATION LOG DETAILS

The Navigation Log includes the following information:

①	N2345B	⑮ IFR	⑭ GenAv	⑬ C525/L	Equip: SGRW/PU1	⑫
②	Dep: KIXD	2000Z	352kts	FL370	Route (see below)	⑪
③	Dest: KFFC	ETE: 1:57	Altn: KFTY			⑩
④	Item 18: PBN/C2D2 DOF/220222 REG/N2345B SUR/282B CODE/ABCDEF					⑨
⑤	Item 19: FOB: 0350 SOB: 4 PIC:JOE PILOT (sic:test pilot)					⑧
⑥	Filed: RACER7.SGF TIROE					⑦

①	Aircraft registration (N#).
②	Departure Airport International Civil Aviation Organization (ICAO) Identifier.
③	Departure Time (Zulu).
④	Destination Airport International Civil Aviation Organization (ICAO) Identifier.
⑤	ICAO Aircraft Equipment Information.
⑥	Fuel On Board (HHMM), Souls On Board, Pilot In Command, and Second In Command (if necessary).
⑦	Fixes / Waypoints Filed for the Route.
⑧	Estimated Time Enroute (HH:MM).
⑨	Alternate Airport International Civil Aviation Organization (ICAO) Identifier.
⑩	Planned Flight Level / Altitude.
⑪	Planned maximum runway takeoff weight (10,400 lbs.).
⑫	ICAO Aircraft Equipment Information.
⑬	Aircraft Type Identifier and Equipment Suffix.
⑭	Type of Operation (General Aviation).
⑮	Flight Plan Rules for Route (IFR / VFR).

## WINDS ALOFT MATRIX

The Winds Aloft Matrix is the next section and includes the following information:

		15		14		13		12		11	
1	KIXD to KFFC : TC=124° : (FMS winds: 304°/ 51) : MC= 120° : ST. LINE=598nm : AIRWAY=664nm : Extra=11%										
2	<b>Winds Aloft</b>	FL410 ISA(-57) Comp		FL370 ISA(-57) Comp		FL350 ISA(-54) Comp		FL330 ISA(-50) Comp			
3	BUM	245/129	+03 -067	244/137	+04 -074	242/137	+04 -076	241/127	+02 -070		
4	SGF	245/132	+03 +030	246/145	+04 +034	245/149	+05 +032	245/140	+03 +031		
	TIROE0300	250/119	-01 +065	250/116	+01 +064	249/109	+03 +059	247/102	+05 +053		
	TIROE0200	255/112	-02 +069	257/106	+01 +068	256/098	+03 +063	254/092	+05 +057	10	
	TIROE0100	259/104	-01 +068	262/095	+02 +068	264/086	+03 +064	263/082	+05 +060		9
5	<b>Avg. Trip Winds=&gt;</b>	+ 52 Tailwind		+ 51 Tailwind		+ 46 Tailwind		+ 42 Tailwind			
	<b>FLT TIME==&gt;</b>	2:00(+03) 332TAS		1:57(+00) 352TAS		1:56(-01) 366TAS		1:55(-02) 369TAS			
	<b>Fuel Burn==&gt;</b>	1,654 Lbs		1,715 Lbs		1,777 Lbs		1,827 Lbs			
		6	7	8							

1	Departure and Arrival Airport International Civil Aviation Organization (ICAO) Identifier.
2	Flight Level / Altitude, i.e. FL410 = 41,000' MSL.
3	Fix / Waypoint Along Route.
4	Bearing To / From the Fix / Waypoint.
5	Average Tailwind Component (Knots) for Trip.
6	Flight Time (HH:MM) and Time Difference Between the Next Altitude Data Set.
7	Amount of Fuel Used (lbs or gals).
8	Average True Airspeed (Knots) for Trip.
9	Temperature (°C).
10	Wind Velocity (Knots).
11	The Difference (%) Between the Route via Airways vs. Direct.
12	Distance of the Planned Route via Airways (Nautical Miles).
13	Distance of the Direct Route (Nautical Miles).
14	Magnetic Course.
15	True Course.

- FitPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

## FIX INFO


The Fix Info is the next section and includes the following information:

FIX	ST	LAT/LON	InB/Out Mag Crs	Leg Rem		Fuel Burn		Leg	Rem	ETE	ATA	WX	
						Leg	Tot.						
① KIXD OLATHE	KS	N3849.9W09453.4	---/011	0	664	100	100.0	0:00	1:57	0:00			
	MCI 113.25	KANSAS CITY	MO	N3917.1W09444.2	010/164	28	636	196	296.1	0:08	1:49	0:08	N/A
	GRILD 113.25/164/36	MO	N3841.7W09435.5	164/168	36	600	132	428.4	0:08	1:41	0:16	N/A	
② BUM 115.9 BUTLER	MO	N3816.3W09429.3	168/128	26	574	93	521.8	0:06	1:35	0:22		N/A	
	SGF 116.9	SPRINGFIELD	MO	N3721.4W09320.0	128/115	78	496	171	692.7	0:14	1:21	0:36	N/A
	TIROE0300			N3554.5W09004.2	118/119	180	316	322	1015	0:27	0:54	1:03	122.0
	TIROE0200			N3504.1W08818.2	122/123	100	216	170	1184	0:14	0:40	1:17	122.0
TIROE0100			N3412.1W08634.5	126/127	100	116	177	1361	0:14	0:26	1:31	122.0	
TIROE	GA	N3318.4W08452.0	127/083	101	15	233	1594	0:18	0:08	1:49		N/A	
③ KFFC ATLANTA	GA	N3321.5W08434.4	083/---	15	0	121	1715	0:08	0:00	1:57			

①	Departure Airport International Civil Aviation Organization (ICAO) Identifier.
②	Frequency for Navigational Aid.
③	Destination Airport International Civil Aviation Organization (ICAO) Identifier.
④	State Abbreviation.
⑤	Latitude (°N/°S) and Longitude (°W/°E).
⑥	Magnetic Course Approaching Fix and Magnetic Course Leaving Fix.
⑦	Length of Leg (Nautical Miles).
⑧	Distance Remaining to Primary Destination (Nautical Miles).
⑨	Fuel Consumption for the Leg (lbs or gals).
⑩	Total Fuel Consumption for the Trip (lbs or gals).
⑪	Estimated Time for the Leg (HH:MM).
⑫	Estimated Time Remaining Until Primary Destination (HH:MM).
⑬	Estimated Time Enroute Until Primary Destination (HH:MM).
⑭	Frequency for Weather Information.

## FUEL BURN & ALTERNATE AIRPORT INFO

The Fuel Burn & Alternate Destination Airport is the next section and includes the following information:



1	Alternate Airport International Civil Aviation Organization (ICAO) Identifier, Name, and Location (City, State).
2	Primary Destination Airport Name and CTAF/UNICOM Frequency.
3	Primary Destination Airport Phone Number.
4	Fuel Burn for Taxi (lbs or gals).
5	Total Fuel Burn for Trip (lbs or gals).
6	Fuel Burn to Fly to Alternate Airport (lbs or gals).
7	Fuel Needed to Fly for 45 Minutes Upon Reaching Alternate Airport (lbs or gals).
8	Phone Number for Flight Service Station.
9	Minimum Amount of Fuel Needed for Trip (lbs or gals).
10	Fuel Burn to Fly to Alternate Airport (lbs or gals).
11	Hourly Fuel Calculation (lbs or gals).
12	Time Needed to Fly From Primary Destination Airport to the Alternate Airport (HH:MM).
13	Distance Needed to Fly From Primary Destination Airport to the Alternate Airport (Nautical Miles).
14	Bearing From the Primary Destination Airport to the Alternate Airport.
15	Altitude Used to Calculate Flight Data From The Primary Destination Airport to the Alternate Airport.
16	Common Traffic Advisory Frequency (CTAF) for the Primary Destination Airport.
17	Automated Weather Observing Station (AWOS) for the Primary Destination Airport.
18	Elevation for the Primary Destination Airport (ft).


- FitPlan
- Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

## AIRPORT DIAGRAMS

The next section in the Navigation Log is Airport Diagrams, which displays the Departure and Arrival Airport Diagrams, and, if available, FBO location.



**NOTE:** Airport Diagrams could be out of date, please verify with the appropriate source for any changes/updates.



FltPlan Go - NavLogs Page - Airport Diagrams

## WINDS MATRIX - EXPANDED

The next section in the Navigation Log is the Winds Matrix, but with greater detail than previously listed in the Navigation Log. The vast majority of information is the same, but more details are listed for fuel burn and time per Fix. Additional Cruise Altitude information is also detailed, allowing the User to view more data pertinent to the Trip. The filed altitude for the Trip will be highlighted with a green background.



**NOTE:** When a Cruise Altitude exceeds the aircraft limitations, ABOVE MAX ALT will be displayed and the various data points will remain blank.

Altitude Exceeds Aircraft Limitations

### Winds Matrix KIXD to KFFC

**N2345B** *FitPlan.com* Tuesday 02-22-22 — Dept: 1400L (GMT-6) — Arr: 1657L (GMT-5)

Filed Altitude

Fix Name	FL450 ISA(-57) Comp	FL410 ISA(-57) Comp	FL390 ISA(-57) Comp	FL370 ISA(-57) Comp	FL350 ISA(-54) Comp
Rem. (Miles)	Rem. (Time - Fuel)	Rem. (Time - Fuel)	Rem. (Time - Fuel)	Rem. (Time - Fuel)	Rem. (Time - Fuel)
<b>SGF</b> (496nm)	244/118 -02 +026 (--- ---)	245/132 +03 +030 (1:23 - 957 Lbs)	246/139 +05 +032 (1:22 - 982 Lbs)	246/145 +04 +034 (1:21 - 1023 Lbs)	245/149 +05 +032 (1:19 - 1084 Lbs)
<b>TIROE0300</b> (316nm)	248/116 -06 +060 (--- ---)	250/119 -01 +065 (:55 - 670 Lbs)	250/121 +01 +067 (:54 - 680 Lbs)	250/116 +01 +064 (:54 - 701 Lbs)	249/109 +03 +059 (:54 - 733 Lbs)
<b>TIROE0200</b> (216nm)	254/108 -06 +065 (--- ---)	255/112 -02 +069 (:40 - 521 Lbs)	256/114 +00 +072 (:39 - 523 Lbs)	257/106 +01 +068 (:40 - 531 Lbs)	256/098 +03 +063 (:40 - 546 Lbs)
<b>TIROE0100</b> (116nm)	256/100 -06 +062 (--- ---)	259/104 -01 +068 (-)	261/105 +01 +072 (-)	262/095 +02 +068 (-)	264/086 +03 +064 (-)
<b>Avg. Winds=&gt;</b>	+ 48 Tailwind	+ 52 Tailwind	+ 54 Tailwind	+ 51 Tailwind	+ 46 Tailwind
<b>FLT TIME==&gt;</b>	ABOVE MAX ALT.	2:00(+03) 332TAS	1:59(+02) 338TAS	1:57(+00) 352TAS	1:55(-02) 366TAS
<b>Fuel Burn==&gt;</b>	---	1,654 Lbs	1,679 Lbs	1,712 Lbs	1,776 Lbs

Fix Name	FL330 ISA(-50) Comp	FL310 ISA(-46) Comp	FL290 ISA(-43) Comp	FL270 ISA(-39) Comp	FL250 ISA(-35) Comp
Rem. (Miles)	Rem. (Time - Fuel)				
<b>SGF</b> (496nm)	245/140 +03 +031 (1:19 - 1131 Lbs)	244/124 +02 +028 (1:21 - 1183 Lbs)	241/106 +02 +021 (1:22 - 1235 Lbs)	238/087 +03 +014 (1:23 - 1317 Lbs)	236/084 +03 +011 (1:23 - 1359 Lbs)
<b>TIROE0300</b> (316nm)	247/102 +05 +053 (:54 - 757 Lbs)	246/097 +05 +050 (:54 - 785 Lbs)	242/087 +06 +040 (:55 - 809 Lbs)	236/073 +08 +027 (:56 - 850 Lbs)	237/071 +09 +028 (:56 - 875 Lbs)
<b>TIROE0200</b> (216nm)	254/092 +05 +057 (:40 - 557 Lbs)	252/084 +05 +050 (:40 - 572 Lbs)	251/077 +07 +045 (:41 - 581 Lbs)	250/072 +08 +041 (:41 - 603 Lbs)	247/069 +09 +037 (:41 - 618 Lbs)
<b>TIROE0100</b> (116nm)	263/082 +05 +060 (-)	260/078 +06 +055 (-)	258/072 +07 +049 (-)	255/066 +09 +042 (:27 - 362 Lbs)	252/066 +10 +040 (:26 - 366 Lbs)
<b>Avg. Winds=&gt;</b>	+ 42 Tailwind	+ 40 Tailwind	+ 34 Tailwind	+ 28 Tailwind	+ 26 Tailwind
<b>FLT TIME==&gt;</b>	1:55(-02) 369TAS	1:56(-01) 369TAS	1:57(+00) 370TAS	1:58(+01) 369TAS	1:57(+00) 368TAS
<b>Fuel Burn==&gt;</b>	1,829 Lbs	1,899 Lbs	1,957 Lbs	2,051 Lbs	2,098 Lbs

FitPlan Go - NavLogs Page - Winds Matrix - Expanded

- FitPlan
- Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

## RUNWAY & APPROACH INFO

The next section in the Navigation Log is the Runway and Approach info, where both the Departure Airport and Arrival Airport will have runway (length, width, usable, etc.) and approach info (equipment, inbound course, frequency, etc.) displayed.

KIXD (Elev: 1087') - Departure Airport Runway Info						KSTP (Elev: 705') - Arrival Airport Runway Info							
Rwy	Length	Appr.*	Rwy	Length	Appr.*	Rwy	Length	Usable	Appr.*	Rwy	Length	Usable	Appr.*
04	5132x100		22	5132x100		09	3642x100	3642'		27	3642x100	3642'	
18	7339x150		36	7339x150	ILS/DME	13	4004x150	4004'		31	4004x150	4004'	
* only ILS, LOC, LDA, & SDF approaches shown						14	6491x150	6148'	ILS/DME 111.50 - 146°	32	6491x150	6109'	ILS/DME 111.50 - 326°
* only ILS, LOC, LDA, and SDF approaches to a specific runway shown													

①	Departure Airport International Civil Aviation Organization (ICAO) Identifier.
②	Runway Length (ft) x Width (ft).
③	Runway I.D.
④	Type of Approach/Equipment.
⑤	Total Usable Runway (ft).
⑥	ILS Navigation Frequency.
⑦	Inbound Course.
⑧	Arrival Airport Elevation (ft).
⑨	Arrival Airport International Civil Aviation Organization (ICAO) Identifier.
⑩	Departure Airport Elevation (ft).

The remaining sections within the Navigation Log contain the following raw data/text sets:

- Departure Airport METARs
- Departure Airport Forecast
- Recent NOTAMs - Departure Airport (New or Modified)
- Departure Airport NOTAMs
- Nearby Departure Airport METARs
- Arrival Airport METARs
- Arrival Airport Forecast
- Recent NOTAMs - Arrival Airport (New or Modified)
- Arrival Airport NOTAMs
- Alternate Airport METAR/TAF
- Recent NOTAMs - Alternate Airport (New or Modified)
- Alternate Airport NOTAMs
- Nearby Arrival Airport Weather
- Enroute METARs and TAFs
- Enroute Navigation NOTAMs
- Enroute PIREPs

### AUTO SYNCING NAVLOGS

When the User creates a flight plan on FltPlan.com, flight information including NavLogs, Routes, Weight & Balance Calculations, and Checklists are auto-synced to the FltPlan Go program. When auto-sync is enabled, push notifications will be received (pop-up) directly to the device anytime a new NavLog is available. When a flight is approaching, FltPlan Go will automatically send a push notification with the latest NavLog information one hour prior to departure.




FltPlan Go - NavLogs Push Notification

- Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

## EMAIL/SHARE

Touch  within the Airports section to display a menu listing available sharing and/or storage options (e.g. Chrome, Nearby Share, Drive, Quick Share, Gmail, etc.).



FltPlan Go - NavLogs - Share/Save Menu

## ACCOUNT

Touch the button in the top right corner, e.g.  to Add Account or Logout.

- FitPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

EXTERNAL



The External icon is fifth on the Home Menu. On the External Devices section, the User can view several device categories, such as Internal, External, and Simulators.

**External Connections**

FitPlan.com	<b>Internal</b>	
Current Selection	Android GPS	✓
Touch to Select	<b>External</b>	
Touch to View	Garmin	
	Stratus 3	
	Avidyne	
NavLogs	Dual XGPS170/190	
	Dynon	
	FreeFlight	
	Pathfinder	
Checklists	iLevil SW	
	L-3 Lynx (4000)	
Binders	L-3 Lynx (43211)	
	SkyGuard	
Weather	Stratux	
	Ping Buddy	
Tracking	Custom Unit	
	<b>Simulators</b>	
Tools	X-Plane	
	FSX & Prepar3D	
ScratchPad		

GPS Status:	Enabled
Accuracy:	67 m
Latitude:	38.8557
Longitude:	-94.7998
Altitude:	966 ft
Course:	360.00
Speed:	0 kts
Last Update:	15:34:37

FltPlan Go - External Page

- FitPlan Account
- Airports
- Maps
- NavLogs
- External**
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

## INTERNAL DEVICES

Touch the device under the Internal heading, e.g. Android GPS, to view information gathered by the Android's internal GPS, such as:

- Status
- Accuracy (meters)
- Latitude
- Longitude
- Altitude (ft)
- Course
- Speed (knots)
- Last Update

The Android's internal GPS is automatically enabled by default. To disable, touch the **Disable GPS** button.

## EXTERNAL DEVICES

The next section is External, which lists devices compatible with the FltPlan Go program.

 **NOTE:** The desired External device must be connected to the Android via Settings. Once the connection has been established, the device will be visible for the User to select within the list of External devices. For an updated list of compatible devices, please click on the following link: <https://www.fltplan.com/FltPlanConnectivityOptions.pdf>

 **NOTE:** When a connection is made with a Stratus 3, it will automatically switch to GDL90 Mode to work with FltPlan Go.

 **NOTE:** To connect an ADS-B device, ensure the Android is connected to the unit via Bluetooth or Wi-Fi. Once connected, touch the External tab and select the unit within the list of External devices.

 **NOTE:** If the Android disconnects from the ADS-B unit, FltPlan Go will automatically reconnect to the last unit used.

### Connecting to External GPS Unit:

- 1) Ensure the most recent version of FltPlan Go is downloaded.
- 2) Connect the External GPS to the device via Wi-Fi or Bluetooth.
- 3) Ensure **Location Services** is enabled for FltPlan Go in the Android's Settings.
- 4) Open FltPlan Go.
- 5) Touch the **External** Tab and verify the Internal GPS is enabled. Please wait for the Latitude and Longitude to populate.
- 6) Touch **Maps > Options > Display Ship Position**.

## Connecting to ADS-B Unit:

- 1) Ensure the most recent version of FltPlan Go is downloaded.
- 2) Connect the ADS-B unit to the device via Wi-Fi or Bluetooth.
- 3) Open FltPlan Go.
- 4) Touch the **External** Tab.
- 5) Select the desired ADS-B unit and wait for the 'Connected' message to appear in the top right corner.
- 6) Once connected, touch the **Maps** Tab.
- 7) Touch **ADS-B** in the top right corner, then select the desired information to display on the Map.



**NOTE:** When located in a high traffic area, disabling the 'yellow' aircraft (the furthest away) may help declutter the Map by displaying only the 'orange' and 'red' aircraft, which are closer.

## SIMULATORS

The next section is Simulators, which lists the devices compatible with the FltPlan Go program.



**NOTE:** To connect a Simulator, ensure the system is turned on, touch the External tab, and select the unit within the list of Simulators.



**NOTE:** Only one (1) X-Plane user is allowed per network.

## Connecting to X-Plane:

- 1) Ensure the most recent version of FltPlan Go is downloaded.
- 2) Ensure the latest version of X-Plane is installed.
- 3) Ensure the device running FltPlan Go and the computer running X-Plane are on the same wireless network.
- 4) Open X-Plane on the computer.
- 5) Load a flight.
- 6) Touch **Settings > Net Connections > Android/Device**. Verify all options are toggled 'On'.
- 7) Use the default port and leave the IP field empty.
- 8) **Close** the Settings Menu.
- 9) Open FltPlan Go app on the device.
- 10) Touch **External Tab > X-Plane** (under Simulators). Wait until status reads 'Connected'.
- 11) Touch **Maps Tab > Options > Display Ship Position > Toggle Breadcrumbs**.

The connections should now be set, allowing the User to start the flight on X-Plane while viewing the position in the FltPlan Go program.

## Connecting to Flight Simulator X or Prepar3D:



**NOTE:** A connection will be evident when messages are being sent.


- 1) Ensure the most recent version of FltPlan Go is downloaded.
- 2) Ensure the latest Service Pack is installed.
- 3) Go to [www.fltplan.com/fsx.htm](http://www.fltplan.com/fsx.htm) to download the **FltPlan Go GPS** file on the computer that will be used with FSX or Prepar3D.
- 4) Once the FltPlan Go GPS file downloads, extract **FSX.zip**, then run '**setup.exe**' and follow the on-screen instructions.
- 5) For Steam users, locate the extracted FSX.zip file and click on **Steam SDK > SimConnect.msi**, then run SimConnect.msi and follow the on-screen instructions.
- 6) Open FSX or Prepar3D and enter the flight information.
- 7) Prior to starting the flight in FSX or Prepar3D, open the **FltPlan Go GPS file > Connect to FSX**, then wait for a connection.
- 8) Open FltPlan Go app on the device.
- 9) Touch **External Tab > FSX & Prepar3D** (under Simulators). Wait until status reads 'Connected'.
- 10) Touch **Maps Tab > Options > Display Ship Position > Toggle Breadcrumbs**.

The connections should now be set, allowing the User to start the flight on FSX or Prepar3D while viewing the position in the FltPlan Go program.

### CHECKLISTS



The Checklist icon is sixth on the Home Menu. Any checklists associated with the account, e.g. Garmin, will be listed with  above the aircraft. Touch  to view all applicable checklists for that aircraft.



## CHECKLIST FOR AIRCRAFT

After selecting the desired aircraft, all applicable checklists will be listed. Touch the desired aircraft checklist, e.g. 'Exterior - Cockpit - Cabin Checks'. At the top of the screen, touch **<** to navigate to a previously viewed checklist or touch **>** to navigate to the next checklist in sequence.

### CHECKING OFF ITEMS

The first checklist item to complete will be listed at the top, with the action listed below, e.g. 'Aircraft Documents (Item) Aboard (Action)'.

Touch **Done** beneath the action when the item has been completed. A  will be displayed to indicate the checklist item has been successfully completed.

### SKIPPING ITEMS

Touch  to skip a checklist item. A  will be displayed to indicate the checklist item has been skipped. Continue through the remainder of the checklist as necessary, then, when reaching the end, any skipped items will prompt a pop-up window stating "Checklist has a skipped item. Move to skipped item?". Touch **Cancel** to continue without completing the skipped checklist item, or touch **Yes** to move to the missed checklist item. Once all checklist items are completed, a pop-up window will appear stating "Checklist completed. Proceed to next checklist?". Touch **Cancel** to close the pop-up window and remain on the current checklist. Touch **Continue** to proceed to the next checklist in sequence.

- FitPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

## TEXT TO SPEECH

Touch the button next to 'Text 2 Speech' to toggle On/Off, as desired. When enabled, the green circle will be visible, which allows the feature to audibly read the two lables (Item and Action) for any checklist item.



**NOTE:** Please ensure the volume is at an adequate level on the device to properly use the Text 2 Speech feature.

## RESET LIST

Touch the **Reset List** button to restore all the checklist items to the default 'unselected' status.


FltPlan Go - Checklists - Skipped Item

## CREATING CHECKLIST ON FLTPLAN.COM



**NOTE:** The User can only create or edit a checklist from either the FltPlan.com Tab in FltPlan Go, or on the FltPlan.com website.

**Log Into FltPlan.com:** When connected to the internet, log into FltPlan.com with a username and password.




FltPlan.com - Home - Tools

- FltPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

### Viewing Checklist Tutorial:

- 1) From the Main Menu, click **Tools > Checklist**.
- 2) Click **Tutorial** to view a Checklist Tutorial pdf. in a separate browser window.



FltPlan.com - Tools - Checklist Selection

### Adding Checklist:

- 1) From the Main Menu, click **Tools > Checklist**.
- 2) Click **Add** next to the desired Checklist, e.g. N2345B.
- 3) Select the Aircraft Category, **Single Engine Piston, Multi Engine Piston, Turbo Prop, Jet, or Helicopter**.
- 4) Select the Manufacturer's Checklist or User Created Checklist, as desired.
- 5) The User will be redirected to the Checklist Selction page. Click **View** next to the desired Checklist.



FltPlan.com - Tools - Add Checklist Category

Click to Create Checklist

Create Custom Checklist

### Manufacturer's Checklist

Select BOMBARDIER – BD 700 GLOBAL EXPRESS

Select BOMBARDIER – CHALLENGER 604

Select BOMBARDIER – CL30 CHALLENGER 300

Select CESSNA – 525C CJ4

Select GULFSTREAM – G200

Select GULFSTREAM – G280

Select GULFSTREAM – G450

Select LEARJET – 45

### User Created Checklist

Select BOMBARDIER – GLOBAL 6000

Select CESSNA – 650 CITATION III

Select CESSNA – S550 CITATION S II

Select CHALLENGER – 601-3A

Select FALCON – 50 M 80

Select LEARJET – 40XR

Select  
Manufacturer's  
Checklist

Select User  
Checklist

FltPlan.com - Tools - Jet Checklists

FitPlan  
Account

Airports

Maps

NavLogs

External

Checklists

Binders

Weather

Flight  
Tracking

Tools

Scratch  
Pad


Downloads

Settings

Index


**Adding Custom Checklist:**

- 1) From the Main Menu, click **Tools > Checklist**.
- 2) Click **Add** next to the desired Checklist, e.g. N2345B.
- 3) Select the Aircraft Category, **Single Engine Piston, Multi Engine Piston, Turbo Prop, Jet, or Helicopter**.
- 4) Click **Create Custom Checklist**.
- 5) Click **Add New Category** in the Standard Checklist window, or the Emergency Checklist window.




FltPlan.com - Checklists - Custom - Standard

- 6) Enter a Category Name, then click **Save Category**. The Category Name will now be listed, e.g. 'Checklist TEST'.



FltPlan.com - Checklists - Custom - Standard - Add New Category

- 7) Click **Add New Item**.



FltPlan.com - Checklists - Custom - Standard - Add New Item

- 8) Enter a title for the checklist **Item**, e.g. 'Cabin Preparation'.
- 9) Enter a description for the checklist **Action**, e.g. 'Vacuum and clean cabn'.

10) Click **Add Item/Action**.

FltPlan.com - Checklists - Custom - Standard - Add New Item - Details

11) The User will be redirected to the Custom Checklist with the new Item/Action displayed. To add a new Item/Action, click **Add New Item**.

12) Click **Edit** next to the Item/Action and/or the Checklist Title to adjust, as desired.

FltPlan.com - Checklists - Custom - Standard - New Item Added

13) Click **Sort Checklist**, then adjust the order by clicking  or .

14) Once the Checklist has been sorted, click **Checklist Display** to save.

FltPlan.com - Checklists - Custom - Standard - Sort Checklist

15) When the Custom Checklist is complete, click **Print Checklist** to display the checklist in 'Printer Friendly' format in another browser window.

16) Click **Checklist Menu** to return to the Main Checklist Page. The Custom Checklist is now able to sync with FltPlan Go.

17) To view the new Checklist in FltPlan Go, launch the FltPlan Go app, then touch **Checklist > Refresh**.

**Edit Checklist:**

- 1) From the Main Menu, click **Tools > Checklist**.
- 2) Click **Edit** next to the desired checklist, e.g. N2345B.
- 3) Click  to display Edit Options.



- 4) Click **Add New Category** in the Standard Checklist window, or the Emergency Checklist window.
- 5) Enter a Category Name, then click **Save Category**.
- 6) Click **Sort Categories**, then adjust the order by clicking  or .
- 7) Click **Select** next to the desired checklist item and edit/adjust information, e.g. 'Before Start'.

Standard Checklist	
<input type="text" value="Sort Categories"/>	
EXTERIOR - COCKPIT - CABIN CHECKS	Select
DELAY BEFORE FLIGHT WITHOUT APU - GPU	Select
BEFORE START	Select
STARTING ENGINES	Select
BEFORE TAXI	Select
TAXI	Select
BEFORE TAKEOFF	Select
CLEARED FOR TAKEOFF	Select
CLIMB	Select
FLIGHT LEVEL 1 8 0 CHECK - CRUISE	Select
DESCENT - FLIGHT LEVEL 1 8 0 CHECK	Select
APPROACH	Select
BEFORE LANDING	Select
TWO ENGINE GO AROUND	Select
AFTER LANDING	Select
CLEAR OF RUNWAY	Select
SHUTDOWN	Select
QUICK TURN	Select
<input type="button" value="Add New Category"/>	

Click to Edit

FltPlan.com - Checklists - Edit

- FitPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists**
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

8) Click **Edit** next to the desired checklist item and edit/adjust informatoin, e.g. 'I Pads / Hot Spot'.

Checklist - BEFORE START - Edit		
Item	Action	
1 PARKING BRAKE / CHOCKS	HYDRAULIC PRESSURE REQUIRED / SET / REMOVED	<a href="#">Edit</a>
2 I PADS / HOT SPOT	ON BOARD	<a href="#">Edit</a>
3 CABIN DOOR	CLOSED / LOCKED / VERIFIED	<a href="#">Edit</a>
4 TEXT OPERATIONAL CONTROL BLOCK OUT	SENT	<a href="#">Edit</a>
5 CELL PHONES	AIRPLANE MODE	<a href="#">Edit</a>
6 PASSENGER BRIEFING	COMPLETED	<a href="#">Edit</a>
7 SEATS / SEATBELTS / HARNESS	ADJUSTED / SECURE	<a href="#">Edit</a>
8 STANDBY ATTITUDE INDICATOR	ON / CAGED	<a href="#">Edit</a>
9 EMERGENCY LIGHT SWITCH	ARM	<a href="#">Edit</a>
10 BATTERY SWITCH	BATT	<a href="#">Edit</a>
11 GENERATORS	OFF FOR G P U START / GEN	<a href="#">Edit</a>
12 FUEL COMPUTERS	NORM AFTER 10 SECONDS BATTERY ON	<a href="#">Edit</a>
13 PASSENGER ADVISORY LIGHTS	PASS SAFE	<a href="#">Edit</a>
14 NAV AND REC LIGHTS	ON	<a href="#">Edit</a>
15 AVIONICS POWER	AS REQUIRED	<a href="#">Edit</a>

Click to Edit

FltPlan.com - Checklists - Edit - Before Start

9) Click **Save Item/Action**, or **Delete Item/Action**, as desired. The updated Item/Action will now be included in the checklist.

Click to Edit Info

**Edit Category - BEFORE START - 2**

**Item**

**Action**

Save Item/Action  
Delete Item/Action

Click to Save

Click to Delete

FltPlan.com - Checklists - Edit - Before Start - iPads

- 10) Click **Checklist Menu** to return to the Main Checklist Page. The edited Checklist is now able to sync with FltPlan Go.
- 11) To view the newly modified Checklist in FltPlan Go, launch the FltPlan Go app, then touch **Checklist > Refresh**.

Checklist - BEFORE START - <span>Edit</span>		
Item	Action	
1 PARKING BRAKE / CHOCKS	HYDRAULIC PRESSURE REQUIRED / SET / REMOVED	<span>Edit</span>
2 I PADS / HOT SPOT	ON BOARD / PROPER CHARGE	<span>Edit</span>
3 CABIN DOOR	CLOSED / LOCKED / VERIFIED	<span>Edit</span>

Sort Checklist

Updated Action

FltPlan.com - Checklists - Edit - Before Start - iPads - Edited

### Delete Checklist:

- 1) From the Main Menu, click **Tools > Checklist**.
- 2) Click **Edit** next to the desired checklist, e.g. N2345B.
- 3) Click  to Delete the checklist.
- 4) There will be a prompt to confirm, click **OK** to delete the checklist, or **Cancel** to exit without deleting.

- FltPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

- FitPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders**
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index


# BINDERS



The Binders icon is seventh on the Home Menu. Here the User can create flight specific binders with customized information related to many things, including documents, procedures, airports, NavLogs, and weather.


## ADDING NEW BINDER

In the top left corner of the Binders Header Menu, touch the **New Binder** button to manually Set Binder Name.



FltPlan GO - Binders

Touch **Done** to Save, or **Cancel** to exit without saving.




FltPlan GO - Binders - New Binder - Set Binder Name

## EDIT BINDERS

### RENAMING OR DELETING BINDERS

Longpress on the desired binder to display a pop-up window with two options, 'Delete' or Rename. Touch **Delete** to remove the binder or touch **Rename** to manually enter text and rename the binder. Touch **Cancel** to exit without saving.




FltPlan GO - Binders - Edit Binders - Delete or Rename

### ADDING TO BINDERS

Touch the desired binder to view available files, then touch  to 'Add New' and display a 'Choose an Item' menu, which lists:

- Add Procedure
- Add Airport
- Add A/FD
- Add Documents
- Add NavLog
- Add Weather Brief
- Add FltTrack Tail Number
- Add ScratchPad Sketch



FltPlan GO - Binders - Add New - Choose an Item Menu

- FitPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders**
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

**Add Procedure:**

- 1) From the Binders Page, touch the desired **Binder** >  > **Add Procedure**. The 'Search Airports' menu is now displayed.
- 2) Towards the bottom of the 'Search Airports' menu, select the desired region, either **U.S.**, **Canada**, or **Other**.
- 3) Enter the ICAO airport I.D., e.g. KFOE and select the desired airport from the list. The 'KFOE' Procedures menu is now displayed.
- 4) Select the desired procedure to add to the binder. Repeat as necessary to load additional procedures into the binder.

**Add Airport:**

- 1) From the Binders Page, touch the desired **Binder** >  > **Add Airport**. The 'Search Airports' menu is now displayed.
- 2) Towards the bottom of the 'Search Airports' menu, select the desired region, either **U.S.**, **Canada**, or **Other**.
- 3) Enter the ICAO airport I.D., e.g. KFOE and select the desired airport from the list to add all Airport Info into the binder. Repeat as necessary to load additional Airports into the binder.

**Add A/FD:**

- 1) From the Binders Page, touch the desired **Binder** >  > **Add A/FD**. The 'Search Airports' menu is now displayed.
- 2) Towards the bottom of the 'Search Airports' menu, select the desired region, either **U.S.**, **Canada**, or **Other**.
- 3) Enter the ICAO airport I.D., e.g. KFOE and select the desired airport from the list to add A/FD into the binder. Repeat as necessary to load additional A/FDs into the binder.

**Add Documents:**

- 1) From the Binders Page, touch the desired **Binder** >  > **Add Documents**. The 'Choose a Document' menu is now displayed.
- 2) Select the desired document from the list, e.g. 'FltPlan Go Android Users Manual', to add to the binder. Repeat as necessary to load additional documents into the binder.

**Add NavLogs:**

- 1) From the Binders Page, touch the desired **Binder** >  > **Add NavLog**. The 'NavLogs / WX' menu is now displayed.
- 2) Select the desired NavLog to add to the binder. Repeat as necessary to load additional NavLogs into the binder.

**Add Weather Brief:**

- 1) From the Binders Page, touch the desired **Binder** >  > **Add Weather Brief**. The 'Weather' menu is now displayed.
- 2) Enter the ICAO airport I.D., e.g. KFOE into the Location text box.
- 3) Touch **Get WX** to populate the most recent weather data and add to the binder. Repeat as necessary to load additional Weather Briefs into the binder.

**Or:**

- 4) Select the ICAO airport I.D. from the 'Saved Weather Briefs' section to add to the binder. Repeat as necessary to load additional Weather Briefs into the binder.

## Add FltTrack Tail Number:



**NOTE:** Some aircraft, such as military, are not available for tracking by the general public.

- 1) From the Binders Page, touch the desired **Binder** > > **Add FltTrack Tail Number**. The 'Tracking' menu is now displayed.
- 2) Enter the aircraft tailnumber, e.g. N2345B, into the Tail Number text box.
- 3) Touch **Get Tracking** to add the aircraft tracking file to the binder. Repeat as necessary to load additional aircraft tracking files into the binder.

Or:

- 4) Select the desired aircraft tail number from the 'Saved Tracking Files' section. Repeat as necessary to load additional aircraft tracking files into the binder.

## Add ScratchPad Sketch:

- 1) From the Binders Page, touch the desired **Binder** > > **Add ScratchPad Sketch**. The 'Select File' menu is now displayed.
- 2) Select the desired ScratchPad file to add to the binder. Repeat as necessary to load additional ScratchPad files into the binder.

## MY DOCUMENTS

Within the Binders Page, touch the **My Documents** binder to view saved documents associated with the account.



**NOTE:** To delete or download Documents, please go the the Downloads Tab. Once the files are successfully downloaded, they will appear in the Documents binder.

The screenshot displays the 'My Documents' binder interface. At the top left is an 'ADD FILE' button. The grid contains 12 PDF files, each with a green checkmark indicating successful download. The files are:

- AUSTRALIA\_HIGH\_LE GEND
- FLTPLANGO-IPAD-USE RS-MANUAL\_09-20
- FLTPLAN\_GO\_QUICK START-IPAD
- FLTPLANGO-ANDROID -USERS-MANUAL\_09-...
- Chart Legend IFR High US Mainland
- Chart Legend IFR High US Alaska
- Chart Legend IFR High Caribbean
- Chart Legend IFR High and Low Pacific
- IFR\_HIGH\_USMAINLA ND\_03-31-2016
- IFR\_HIGH\_USALASKA\_ 03-31-2016
- IFR\_HIGH\_CARIBBEAN \_03-31-2016
- IFR\_HIGHANDLOW\_PA CIFIC\_03-31-2016
- Chart Legend IFR Low US Mainland
- Chart Legend IFR Low US Alsaka
- Chart Legend IFR Low Caribbean
- Chart Legend VFR US Mainland
- IFR\_LOW\_USMAINLAN D\_03-31-2016
- IFR\_LOW\_USALASKA\_ 03-31-2016
- IFR\_LOW\_CARIBBEAN\_ 03-31-2016
- VFR\_USMAINLAND\_03- 31-2016


FltPlan GO - Binders - My Documents

## ADD FILE TO MY DOCUMENTS

Touch **Binders > My Documents > Add File** to display the 'Add File' menu. Select the desired file to add to the binder.




FltPlan GO - Binders - My Documents - Add File Menu



FltPlan GO - Binders - My Documents - Add File Menu - FltPlan Mobile

## FILTER MY DOCUMENTS

Touch **Binders > My Documents >**  to display the 'Filter Documents' menu listing the following display options: All, Downloaded, Not Downloaded, and Update Available. The default My Documents Filter setting is 'All'. Select the desired Filter display options to adjust the display.



FltPlan GO - Binders - My Documents - Filter Menu

## VIEWING BINDER FILES

After a binder has been selected, a list of applicable files will be visible in thumbnail format. Touch the desired thumbnail to view the file in full-screen mode.



**NOTE:** A connection to Wi-Fi or cellular network must be established to ensure current chart/procedure information.

## UPLOADING FILES TO FLTPLAN GO

Uploading files, such as a pdf, to FltPlan Go, can be accomplished only if the files were loaded to the same FltPlan.com account.

### Uploading PDF to FltPlan Go:

- 1) In the FltPlan Go program, touch **Downloads > Documents**.
- 2) Any documents uploaded via FltPlan.com will be visible. Touch the desired document to upload to the device.
- 3) Once the file is successfully uploaded, touch **Binders > My Binders**, then select the desired document to view.
- 4) Touch the **Add** button in the top right corner > **Add Documents**.
- 5) Select the PDFs uploaded from FltPlan.com, then touch the desired files to save to the Binder.



**NOTE:** Once downloaded, Procedures, Airports, A/FDs, Documents, NavLogs, and ScratchPad documents can be viewed offline.

# WEATHER



The Weather icon is eighth on the Home Menu, and displays the Weather Page, which includes the following items:

- Departure / Arrival Airport METARs, Forecast, and NOTAMS
- Nearby Airport Departure / Arrival NOTAMS
- Nearby Departure / Arrival Airport Weather
- Enroute PIREPs, METARs, and TAFs.

The Banner Menu within the Weather section contains two buttons, and **My Airports / Routes**.

*Touch to Refresh Data* (Refresh icon)

*Touch to View My Airports/Routes* (My Airports / Routes button)

*Weather Data Timestamp* (Certified Weather UTC request time:06/06/2022 18:58z)

*Touch to Print* (Print button)

*Touch to Expand/Collapse* (Current METAR Grid button)

*Touch to View* (Weather Abbreviation button)

Airport	Ceiling	Visibility	Wind Speed	Temp	Weather
KLWC → KTLH					
KLWC	●	●	●	●	KLWC 061852Z AUTO 26007KT 10SM CLR 28/19 A2970 RMK AO1 SLP048 T02830194
KOJC	●	●	●	●	KOJC 061853Z 19004KT 10SM CLR 27/18 A2972 RMK AO2 SLP052 T02670178
KCNU	●	●	●	●	KCNU 061852Z AUTO 24003KT 10SM FEW028 28/20 A2973 RMK AO2 SLP056 T02780
KJLN	●	●	●	●	KJLN 061853Z 28008KT 10SM BKN030 BKN043 27/21 A2974 RMK AO2 SLP058 T02670
KDMO	●	●	●	●	KDMO 061853Z AUTO 24005KT 10SM FEW033 27/19 A2973 RMK AO2 SLP059 T02670
KSGF	●	●	●	●	KSGF 061852Z 24005KT 10SM SCT031 BKN038 BKN055 24/19 A2974 RMK AO2 SLP05
KHRO	●	●	●	●	KHRO 061853Z AUTO 00000KT 10SM OVC055 26/18 A2975 RMK AO2 SLP062 T02560
KCOU	●	●	●	●	KCOU 061854Z VRB05KT 10SM BKN026 BKN031 OVC060 26/18 A2972 RMK AO2 SLP0
KTBN	●	●	●	●	KTBN 061831Z AUTO 17007KT 10SM FEW014 SCT022 BKN029 OVC034 20/19 A2972 I
KVIH	●	●	●	●	KVIH 061853Z AUTO 13006KT 10SM OVC037 21/18 A2974 RMK AO2 RAE21 SLP061 P
KPOF	●	●	●	●	KPOF 061853Z AUTO 16005KT 6SM RA BR FEW014 BKN070 OVC095 22/20 A2978 RM
KJBR	●	●	●	●	KJBR 061853Z AUTO 17005KT 9SM -RA FEW070 BKN095 OVC120 23/22 A2979 RMK A
KBYH	●	●	●	●	Current WX Not Found
KMEM	●	●	●	●	KMEM 061754Z 12011KT 10SM SCT110 OVC200 25/21 A2979 RMK AO2 RAE03 TSE05
KGWO	●	●	●	●	KGWO 061853Z AUTO 19008KT 10SM FEW034 30/23 A2979 RMK AO2 RAE1757 SLP06
KUOX	●	●	●	●	KUOX 061855Z AUTO 18009KT 150V230 10SM FEW033 28/21 A2982 RMK AO2 PWINC
KDYR	●	●	●	●	KDYR 061844Z AUTO 11004KT 10SM -RA SCT004 BKN026 OVC110 22/ RMK AO2 CIG C
KMEI	●	●	●	●	KMEI 061758Z 23009KT 180V250 10SM SCT046 BKN060 BKN075 32/21 A2988 RMK A
KTUP	●	●	●	●	KTUP 061853Z VRB05KT 10SM FEW040 31/21 A2983 RMK AO2 LTG DSNT E AND SE PI
KMKL	●	●	●	●	KMKL 061853Z 10007KT 10SM TS FEW033 SCT039 BKN110 23/21 A2981 RMK AO2 P
KGTR	●	●	●	●	KGTR 061756Z 23010KT 10SM FEW041 31/21 A2988 RMK AO2 SLP121 T03060211 10
KTCL	●	●	●	●	KTCL 061853Z 23009KT 10SM FEW045 32/21 A2987 RMK AO2 LTG DSNT NE AND W S
KMSL	●	●	●	●	KMSL 061853Z AUTO 22010G19KT 10SM SCT047 SCT065 31/20 A2985 RMK AO2 LTG
KHSV	●	●	●	●	KHSV 061853Z 18008KT 10SM SCT044 BKN250 30/19 A2987 RMK AO2 LTG DSNT NE .
KTOI	●	●	●	●	KTOI 061853Z AUTO 19004KT 10SM FEW065 32/19 A2990 RMK AO2 SLP119 T032201
KBHM	●	●	●	●	KBHM 061853Z 18010G15KT 10SM SCT045 SCT060 BKN250 31/19 A2990 RMK AO2 L
KEDN	●	●	●	●	KEDN 061855Z AUTO 00000KT 10SM CLR 30/19 A2990 RMK AO2 T03000191
KANB	●	●	●	●	KANB 061853Z AUTO VRB04KT 10SM SCT048 SCT070 BKN085 30/19 A2990 RMK AO2
KMGM	●	●	●	●	KMGM 061853Z 16006KT 10SM FEW045 32/21 A2989 RMK AO2 SLP117 T03170211
KCSG	●	●	●	●	KCSG 061851Z 18006KT 10SM FEW047 31/19 A2990 RMK AO2 SLP118 T03060194

Ceiling (100s Feet)			
LIFR	IFR	MVFR	VFR
 < 5 ≤	 < 10 ≤	 < 30 ≤	
Visibility (Miles)			
LIFR	IFR	MVFR	VFR
 < 1 ≤	 < 3 ≤	 < 5 ≤	
Wind Speed (Knots)			
Real Windy	Windy	Breezy	Light
 > 30 ≥	 > 20 ≥	 > 10 ≥	
Temperature (Celsius)			
Cold	Mild	Hot	
 ≤ 0 <	 < 30 ≤		

FltPlan GO - Weather - METAR Legend

## REFRESH DATA



**NOTE:** In order to view the latest Weather, update a document, or use FltTracking, a Wi-Fi or cellular network connection must be established.

Located in the upper left corner of the Weather Page,  allows the User to import data frequently to ensure accurate information prior to departure. Each time  is selected, a timestamp entitled Certified Weather towards the top of the page will update with the UTC request time (MM/DD/YYYY & Zulu Time).

## MY AIRPORTS / ROUTES

Located in the middle of the Banner Menu within the Weather section, the **My Airports / Routes** button allows the User to Edit or Add information.



FltPlan GO - Weather - Banner Menu


### Adding Location:

- 1) Touch the My Routes button, e.g.  > **Show Location Weather**.
  - 2) Enter the Airport ID (ICAO), e.g. KLWC in the Location text box.
  - 3) Touch **Get WX** to save and continue.
- Or Touch **Close** to exit without saving.

- FltPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

**Adding Route:**

- 1) Touch the My Routes button, e.g. **KLWC-KTLH** > **Show Route Weather**.
  - 2) Enter an Airport ID (ICAO), e.g. KLWC in the Dept (Departure) text box and the Arrv (Arrival) text box.
  - 3) Touch **Get WX** to save and continue.
- Or** Touch **Close** to exit without saving.



FltPlan GO - Binders - My Documents - Filter Menu

### FLIGHT TRACKING



The Tracking icon is ninth on the Home Menu, and displays the available aircraft ID's the User set-up for flight tracking via FltPlan.com. The Banner Menu within the Tracking section contains two buttons, , and **My Aircraft** (or the most recently viewed aircraft ID, (e.g.N861PP).

*Touch to Re-fresh Data* 

*Touch to View My Aircraft* **N861PP**

*Scroll to View Additional Info* Current or Last Flight: **Yesterday** Date: **06/16/22 Thu** Depart: **KJEF** Arrive: **KFOE** Depart Time: **20:21** Arrive: **21:07** Typ

*Touch to Re-fresh Data* Last Updated: **06/17/2022 14:42Z** 

Flight #	Departure Airport	Departure Time	Arrival Airport	Estimated Arrival Time	Time to Arrival
N861PP	KFOE	Jun 16 9:14 AM	KBIS	Jun 16 11:54 AM	-

*Touch to View on Map*

*Scroll to View Additional Info*

FltPlan GO - Tracking - Main

## REFRESH DATA

There are two ways to refresh tracking data once an aircraft has been selected within the Tracking section. The User can touch  in the upper left corner, or  located on the right hand side to refresh data. A timestamp is created and displayed on the right hand side in the following format: MM/DD/YYYY and HH:MM (Zulu).

## MY AIRCRAFT

The second button on the Banner Menu is My Aircraft. Touch this button and a drop-down menu will appear, listing available aircraft.

**Tracking**

Tail number:  *Touch to Enter Info*

**Saved Tracking Files**

*Touch to Select* N2345B

**NBAA WHITE PLAINS REGIONAL FORUM**  
June 22, 2022 | WHITE PLAINS, NY  
[REGISTER NOW](#) [nbaa.org/2022hpn](http://nbaa.org/2022hpn)

*Touch to Exit* **CLOSE** **TRACK** *Touch to Add & Track Aircraft*

FltPlan GO - Tracking - My Aircraft

- FltPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index



**NOTE:** If the 'My Aircraft' list is empty/blank, or if an 'Error' is noted, the applicable account does not have any tracking services set-up via FltPlan.com. To add aircraft tracking services, touch **FltPlan.com > Flight Tracking > Flight Tracking** and enter the desired aircraft I.D. and email address for notifications.



**NOTE:** Some aircraft, such as military, are not available for tracking by the general public.

The screenshot shows the 'Aircraft Notifications' screen. At the top is a blue header with a plus icon and the word 'Aircraft'. Below this is a 'Notifications' section with three buttons: 'Planned ATC Route Info', 'EDCT Info', and 'Help'. A table follows with columns: '#', 'Tail# CallSign', 'ATC Route & EDCT', 'Proposed', 'T.O.', 'Landing', and 'E-mail address'. The first two rows are populated with aircraft data and checked boxes. The last two rows are empty. A 'Save' button is at the bottom right. A 'Test Email Address' link is at the bottom center. Callouts point to various elements: 'Touch to Expand/Collapse' (header), 'Touch to View/Select' (table row), 'Touch to Toggle On/Off' (checkboxes), 'Scroll to View Additional Info' (info buttons), 'Touch to Enter/Change Email' (email input), 'Touch to Save' (Save button), and 'Touch to Send Test Email' (Test Email Address link).

#	Tail# CallSign	ATC Route & EDCT	Proposed	T.O.	Landing	E-mail address
1	N861PP	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	TYLER.PEARCE@GARMIN.COM
2	N372GG	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	TYLER.PEARCE@GARMIN.COM
3		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
4		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	

FltPlan.com - Tracking - Aircraft - Notifications

## FLIGHT TRACKING MAP

After an aircraft has been added, touch My Aircraft to view the drop-down menu, then select the desired Aircraft ID from the list to display the Flight Tracking Map. The User can now view additional details regarding specific flights per aircraft, which includes the following information:

- Flight Number (if applicable)
- Departure Airport
- Departure Time
- Arrival Airport
- Estimated Arrival Time
- Time to Arrival
- Status
- Altitude (ft)
- Ground Speed (knots)
- Equipment

## SWITCHING AIRCRAFT

While viewing the flight tracking map, the User can switch the aircraft by touching the **My Aircraft** button in the top, center of the page. Select the desired Aircraft ID to switch and view flight tracking information.

### MAP OPTIONS

While viewing the flight tracking map, the User can toggle various menu's to adjust the data displayed, a vertical Flight Tracking menu, and a horizontal Map Options display menu.

**FltPlan.com** | N861PP | Touch to View My Aircraft

Touch to Refresh Data | Touch to Enter & Search Aircraft ID | Touch to Hide/View Menu | Touch to View Info | Touch to View Map Options

**N861PP Landed** - Last seen 12.2 hours ago

Departure	
KJEF	JEFFERSON CITY, MO
Arrival	
KFOE	TOPEKA, KS
Depart Actual	Arrival Actual
6/16/22	6/16/22
8:21 PM CDT	9:07 PM CDT
Depart Filed	Arrival Filed
6/16/22	6/16/22
7:25 PM CDT	9:07 PM CDT
Flight Time	
Actual - 0:46	
Model	Type
PC12	Turbo Prop Single
Filed Route	Amended Route
Not Following Airplane	
N861PP	KFOE
Last seen 12.2 hours ago	
21:07 CDT	
N861PP	KFSD - KJEF
Landed - 6/16 20:05 CDT	
N861PP	KBIS - KFSD
Landed - 6/16 15:38 CDT	
N861PP	KFOE - KBIS
Landed - 6/16 11:54 CDT	

Touch to Expand/Collapse | Touch to Toggle On/Off | Touch to View

Weather: Jun 17, 2022 02:07 UTC  
Hover for Key | Touch to View Legend


Leaflet | © OpenStreetMap © CartoDB

FltPlan GO - Tracking - Flight Details

## FLIGHT TRACKING MENU

The first menu is the vertical display on the lefthand side, which lists the following information:

- Aircraft ID and status (e.g. Landed).
- Departure & Arrival Airport
- Depart Time & Arrive Time Actual
- Flight Time
- Aircraft Model (e.g. C172) & Type.
- Filed & Amended Route.
- Flight Tracking Status. If an aircraft is not being tracked, 'Not Following Airplane' will be displayed with a red background. If an aircraft is being tracked, 'Following Airplane' will be displayed with a green background.



FltPlan GO - Tracking - Flight Details - Map Legend

## MAP OPTIONS MENU

While viewing the flight tracking map, touch Map Options towards the top of the screen, below the Banner Menu, to view the following display settings:

- Display Airports
- Light/Dark Map
- Display Routes (None, Airborne, or All)
- Display Day/Night

Adjust the settings as desired, then touch the dark blue FltPlan.com banner to close the Map Options menu.




FltPlan GO - Tracking - Flight Details - Map Options Banner Menu



## TOOLS

The Tools icon is tenth on the Home Menu, and displays two groups of icons, Tools & Calculators. The Tools group consists of the following items:

- PDC Service
- Cloud Tops
- Weight & Balance (W & B)
- eLogBook
- Contacts




The Calculators group consists of the following items:

- Numeric
- C° <-> F°
- Temperature
- Density Altitude
- Winds
- Airport Winds
- Conversions
- Equal Time

## PRE-DEPARTURE CLEARANCE (PDC) SERVICE

From the Tools Tab, touch  to view the PDC Service page, where the User can add/view PDC information, such as Tail Number, Departure Airport, and Arrival Airport.



FltPlan GO - Tools - Pre-Departure Clearance

### Entering PDC Info:

- 1) Touch **Tools** > .
- 2) Enter Aircraft Tail Number (e.g. N861PP).
- 3) Enter Departure Airport (ICAO ID).
- 4) Enter Arrival Airport (ICAO ID).
- 5) Touch **Get PDC**. The PDC will now be listed in the Saved PDCs section.

### Deleting PDC:

- 1) Touch **Tools** > **PDC Services**.
  - 2) Touch the red 'X' listed next to the Saved PDC to Delete.
- Or** Touch the **Delete All** button to delete all PDCs.

## ELOGBOOK

From the Tools Tab, touch  to view the eLogbook page, where the User can add/view Logbook entries.

### LOG-IN



**NOTE:** First time users must register their pilot license number with the FltPlan.com Logbook by visiting [logbook.fltplan.com](http://logbook.fltplan.com) before adding their pilot license number to [FltPlan.com](http://FltPlan.com). Upon completion, the information will be available in FltPlan Go.

#### Logging Into eLogbook:

- 1) Touch **Tools** > .
- 2) Enter Pilot Name, License (Certificate) Number, and Password.
- 3) Touch **Log In** to save and continue.

#### Entering eLogbook Piloting Info:

- 1) Touch **Tools** > .
- 2) Complete Log-In process.
- 3) At the top of the page, touch 'General Aviation' (the button will display the most recent selection) to view options, then select **General Aviation, Corporate, Air Taxi, or Scheduled Air Carrier**.
- 4) Touch 'Part 91' (the button will display the most recent selection) to view options, then select **Part 91, Part 121, or Part 135**.
- 4) Touch 'Pilot' (the button will display the most recent selection) to view options, then select **Pilot or Flight Instructor**.
- 6) Touch 'PIC' (the button will display the most recent selection) to view options, then select **PIC, SIC, Student, or PIC/Student**.
- 7) Touch the **Log Entry** button to save to the eLogbook.



FltPlan GO - Tools - eLogbook - Log In

### Entering eLogbook Info:

- 1) Touch **Tools** > .
- 2) Complete Log-In process.
- 3) Touch the **Info** tab.
- 4) Touch the **Aircraft** button to change and/or select aircraft profile.
- 5) Enter the Date (YYYY-MM-DD).
- 6) Enter the Departure Airport (ICAO ID).
- 7) Enter the Arrival Airport (ICAO ID).
- 8) Enter the Aircraft Make & Model.
- 9) Enter the Aircraft Tail Number (ID).
- 11) Enter the Estimated Time Enroute in the Flight Time data field (HH:MM).
- 12) Touch the **Log Entry** button to save to the eLogbook.


Date:	<input type="text" value="2022-06-07"/>
Dept. Airport:	<input type="text"/>
Arrival Airport:	<input type="text"/>
Make & Model:	<input type="text"/>
Tail Number:	<input type="text"/>
Flight Time:	<input type="text"/>

*Touch to Enter Info*

FltPlan GO - Tools - eLogbook - Log Entry - Date & Route

## Entering eLogbook Aircraft Category and Class Info:

- 1) Touch **Tools** > 
- 2) Complete Log-In process.
- 3) Scroll down to the Aircraft Category and Class section.
- 4) Touch the desired info, e.g. ASEL (Airplane Single Engine Land), High Performance, Aircraft less than 12,500 lbs.
- 5) Touch the **Log Entry** button to save to the eLogbook.



FltPlan GO - Tools - eLogbook - Log Entry - Aircraft Category & Class

**Entering eLogbook Conditions Info:**

- 1) Touch **Tools** > 
- 2) Complete Log-In process.
- 3) Scroll to the Conditions section.
- 4) Enter the necessary logbook entry info.
- 5) Touch the **Log Entry** button to save to the eLogbook.

### Conditions of Flight

Enroute Airports	<input type="text"/>	<i>Touch to Enter Airport I.D.</i>
<input checked="" type="checkbox"/> Solo	<input type="text"/>	<i>Touch to Enter Info</i>
<i>Touch to Select</i> <input checked="" type="checkbox"/> Dual Rec.	<input type="text"/>	
<input checked="" type="checkbox"/> Dual Given	<input type="text"/>	
<input checked="" type="checkbox"/> Cross Country	<input type="text"/>	
<input checked="" type="checkbox"/> Cross Country > 50 nm.	<input type="text"/>	
<input checked="" type="checkbox"/> Day	<input type="text"/>	
<input checked="" type="checkbox"/> Day Landings	<input type="text"/>	
<input checked="" type="checkbox"/> Night	<input type="text"/>	
<input checked="" type="checkbox"/> Night Landings	<input type="text"/>	
<input checked="" type="checkbox"/> IFR	<input type="text"/>	
<input checked="" type="checkbox"/> VFR	<input type="text"/>	
<input checked="" type="checkbox"/> Actual Instrument	<input type="text"/>	
<input checked="" type="checkbox"/> Simulator Instrument	<input type="text"/>	
<input checked="" type="checkbox"/> Flight Training Device	<input type="text"/>	
<input checked="" type="checkbox"/> # of Approaches	<input type="text"/>	
<input checked="" type="checkbox"/> Type of Approaches	<input type="text"/>	
<input checked="" type="checkbox"/> Remarks	<input type="text"/>	

FitPlan GO - Tools - eLogbook - Log Entry - Conditions

## CLOUD TOPS

From the Tools Tab, touch  and the feature will access the camera on the device, allowing the User to direct the camera towards the clouds and gather data visually.

### Obtaining Cloud Top Info:

- 1) Touch **Tools** > .
- 2) Aim the device, e.g. Samsung Galaxy S7 Tab, outside of the aircraft, with the center, green line touching the top of the clouds.
- 3) When satisfied, touch the **Lock** button, which prompts the device to take a screenshot.
- 4) To keep the screenshot, slide the Lock button to the Left or Right to save the screenshot.
- Or Repeat step 3 until the desired screenshot is captured.
- 5) Set the aircraft altitude by touching Aircraft Altitude, then scrolling until reaching the current altitude.
- 6) Set the distance (nm) by touching Distance and scrolling until reaching the current distance from the cloud tops.


No need to adjust the angle, it is automatically determined by the device camera. On the top of the screen, the center number displays the cloud height above Mean Sea Level (ft). The smaller numbers located above and below the MSL cloud height represent a margin of error of 0.1° in either direction. The number to the right of center displays the height of the clouds relative to the current aircraft location (ft). The distances will display green when flying above clouds, red when headed into/below clouds, and orange when close to clouds.

## WEIGHT & BALANCE



**NOTE:** Weight & Balance profiles are automatically synced from the User's FltPlan.com account. To add or edit an aircraft W&B profile, please go to [FltPlan.com](http://FltPlan.com). All W&B profiles will automatically download the first time to allow the User to access them offline.

From the Tools Tab, touch  to view Weight & Balance profiles associated with the active account. Touch the desired aircraft icon to view the current W&B set-up, and enter the necessary information.



FltPlan GO - Tools - Weight & Balance - Main

### Entering Weight & Balance Info:

- 1) Touch **Tools** > .
- 2) Touch the desired aircraft icon associated with the aircraft ID (N#).
- 3) Touch the **Plane** button to view a Top View of the seating and baggage arrangement for the particular aircraft.
- 4) Touch the **Legend** button to view the Chart Legend.
- 5) Enter info in the Flight Description.
- 6) Enter name of the PIC & SIC.
- 7) Enter the Departure Airport (ICAO ID).
- 8) Enter the Arrival Airport (ICAO ID).
- 9) Enter Pilot Notes, as desired.
- 10) Enter the number of Passengers.
- 11) Enter the weight of the pilots, passengers, baggage, and fuel capacity, and fuel burn (lbs or gals).
- 12) Toggle the Fuel Units to either **Pounds** or **Gallons.**, as necessary.
- 13) Touch the **Calculate** button at the top to display the Weight, Fwd Limit, C.G., Aft Limit, and % of MAC (if applicable). Scroll down to view Max Takeoff Weight (MTOW), the difference between the current weight, and the Zero Fuel Weight.



**NOTE:** If the current weight exceeds the MTOW, the difference will be highlighted in red text. If the current weight is less than the MTOW, the difference will be highlighted in green text.

- 14) Touch **Email W & B** to send the current W&B as an email associated with the active account.

- FitPlan
- Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

CESSNA-525 CITATIONJET CJ1

Flight Description

6/8/2022: Wichita to Chicago

PIC	Jill Pilot
SIC	Joe Pilot
DEPT <span style="border: 1px solid #ccc; padding: 2px 5px;">KICT</span>	ARRV <span style="border: 1px solid #ccc; padding: 2px 5px;">KMDW</span>
Pilot/Notes	<span style="border: 1px solid #ccc; padding: 2px 5px;">Giorgino's for PAX.</span>
Passengers	<span style="border: 1px solid #ccc; padding: 2px 5px;">2</span>
Basic Empty Weight	6400 lb
<span style="color: red;">Captain</span>	<span style="border: 1px solid #ccc; padding: 2px 5px;">165</span>
<span style="color: red;">Co-Pilot</span>	<span style="border: 1px solid #ccc; padding: 2px 5px;">210</span>
<span style="color: red;">Seat 1</span>	<span style="border: 1px solid #ccc; padding: 2px 5px;"></span>
<span style="color: red;">Seat 2</span>	<span style="border: 1px solid #ccc; padding: 2px 5px;"></span>
<span style="color: red;">Seat 3</span>	<span style="border: 1px solid #ccc; padding: 2px 5px;"></span>
<span style="color: red;">Seat 4</span>	<span style="border: 1px solid #ccc; padding: 2px 5px;"></span>
<span style="color: red;">Seat 5</span>	<span style="border: 1px solid #ccc; padding: 2px 5px;">215</span>
<span style="color: red;">Seat 6</span>	<span style="border: 1px solid #ccc; padding: 2px 5px;">195</span>
<span style="color: blue;">Baggage Comp. 1</span>	<span style="border: 1px solid #ccc; padding: 2px 5px;">10</span>
<span style="color: blue;">Baggage Comp. 2</span>	<span style="border: 1px solid #ccc; padding: 2px 5px;"></span>
<span style="color: blue;">Baggage Comp. 3</span>	<span style="border: 1px solid #ccc; padding: 2px 5px;">25</span>
Fuel Units	<input checked="" type="radio"/> Pounds <input type="radio"/> Gallons
<span style="color: green;">Fuel Tank 1 (Max. 3220 kg)</span>	<span style="border: 1px solid #ccc; padding: 2px 5px;">3100</span>
Fuel Burn	<span style="border: 1px solid #ccc; padding: 2px 5px;">1800</span>
Taxi Fuel Burn	<span style="border: 1px solid #ccc; padding: 2px 5px;">150</span>
Max. Takeoff Weight	10600 lb
Under Gross Weight	<span style="color: green;">430 lb</span>
Zero Fuel Weight	7220 lb

Touch to Enter/Edit

Aircraft Info

Touch to Enter/Edit

Touch to Select

Touch to Enter/Edit


Calculated Data

FltPlan GO - Tools - Weight & Balance - Flight Description - CJ1


- FitPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index



FitPlan GO - Tools - Weight & Balance - Chart - Calculated - CJ1



FitPlan GO - Tools - Weight & Balance - Chart Legend



FltPlan GO - Tools - Weight & Balance - Plane Image Legend

## CONTACTS

From the Tools Tab, touch  to view telephone numbers for Airlines, Hotels, and Rental Cars. The User can touch  in the upper right corner to refresh data. Select as desired, then touch the 'Back' button to exit.



FltPlan GO - Tools - Contacts

## CALCULATORS

Within the Tools Tab, the second group of icons are all various calculators, such as:


- Numeric
- Temperature Conversion
- ISA Temperature
- Density Altitude
- Fuel Conversions
- Equal Time Point
- Runway Wind Calculator
- Airport Winds

### NUMERIC

Touch  to display a generic, numeric calculator. Adjust as desired, then touch **Back** to exit.

### FAHRENHEIT/CELCIUS TEMPERATURE CONVERSION

Touch  to display a Fahrenheit to Celcius (or vice versa) Converter. Enter a temperature in either the F° or C° text box, and the conversion will autopopulate.




FltPlan GO - Tools - Calculators - Temp Conversion

## ISA TEMPERATURE CONVERSION

Touch  to view the ISA Temperature Calculator, where the User can input a Pressure Altitude (ft or meters), and a Temperature (C°), to calculate the ISA Temperature.

### Calculating ISA Temperature:

- 1) Touch **Tools** > .
- 2) Enter a Pressure Altitude (ft. or meters).
- 3) Enter a Temperature (C°).
- 4) Touch **Calculate**. The autogenerated data is listed below.
- 5) Touch 'X' to remove data.
- 6) Touch the '**Back**' button to exit.



The screenshot shows the ISA Temperature Calculator interface. It features two input fields: 'Pressure Altitude' with the value '832' and 'Temperature' with the value '34'. To the right of these fields are radio buttons for 'Feet' (selected) and 'Meters', and a 'C°' label. Below the inputs is a blue 'Calculate' button. The output section displays 'ISA @ 832 ft 13.4°C' and 'ISA Deviation +20.6°C', with a blue 'Clear' button below. Annotations include: 'Enter Info' pointing to the input fields; 'Touch to Adjust' pointing to the radio buttons; 'Touch to Calculate' pointing to the 'Calculate' button; and 'Touch to Clear Data' pointing to the 'Clear' button.

FltPlan GO - Tools - Calculators - ISA Temp Conversion


- FitPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

## DENSITY ALTITUDE

Touch  to view the Density Altitude Calculator, where User can select an airport to view the Elevation, Altimeter Setting, Pressure Altitude, Outside Air Temperature, and Density Altitude.

### Calculating Density Altitude:

- 1) Touch **Tools** > .
- 2) Touch the **Find Nearest Airport** button to automatically load the airport nearest the device location.
- 3) Touch the **View WX** button to view the latest weather information for the selected airport via FltPlan.com.
- 4) Enter the Current Altimeter Setting (inHG or mbar).
- 5) Enter the Outside Temperature (C° or F°).
- 6) The Pressure Altitude and Density Altitude will be calculated and displayed (ft. or meters).
- 7) Touch  to refresh the weather data.
- 8) Touch **Calculator** or the 'Back' button to return to the Density Altitude Calculator.



Touch to Load Nearest Airport

Touch to View Weather via FltPlan.com

Altitude for: KOJC

1096 ft m

Current Altimeter Setting

30.02 inHg mbar

Use standard pressure

Pressure Altitude (press to edit)

1005 ft m

Touch to Adjust

Outside Air Temperature

28 °F °C

ISA (+15) ISA @ 1005ft 13.0°C

Density Altitude

2727 ft m

FltPlan GO - Tools - Calculators - Density Altitude Conversion

KOJC 06/17/2022 10:28 CDT



CALCULATOR

*Touch to Return to Calculator*  
*Touch to Refresh Data*

## FltPlan.com

### Forecast

**KOJC**

Today	Tonight	Saturday	Saturday Night	Juneteenth	Sunday	Monday	Monday Night	Tuesday	Tuesday Night	Wednesday	Wednesday Night	Thursday
Sunny	Mostly Clear	Sunny	Mostly Clear	Sunny	Mostly Clear	Sunny	Mostly Clear	Sunny	Chance T-Storms	Chance Showers	Mostly Cloudy	Partly Sunny
High: 93°F	Low: 72°F	High: 92°F	Low: 72°F	High: 92°F	Low: 73°F	High: 94°F	Low: 75°F	High: 95°F	Low: 72°F	High: 89°F	Low: 71°F	High: 91°F

### Metar Report

06/17/2022 15:28 UTC

KOJC 171453Z 20009G16KT 10SM CLR 28/19 A3008 RMK AO2 SLP171 T02830189 55012

KOJC 171353Z 21011KT 10SM CLR 26/17 A3008 RMK AO2 SLP172 T02610172

KOJC 171253Z 19007KT 10SM CLR 24/18 A3010 RMK AO2 SLP179 T02440178

Temp (C°) & Altimeter

FltPlan GO - Tools - Calculators - Density Altitude Conversion - Get WX

- FitPlan
- Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

## FUEL CONVERSION



Touch  to view the Fuel Conversion page, where the User can select the fuel Type (AVGAS or Jet A), or enter a Custom Fuel Type, then enter the Fuel Amount, Fuel Price, Fuel Required, and Fuel Onboard. Once all the information has been entered, the fuel conversion and Total Price calculation can be viewed in either Pounds or Gallons.

### Converting Fuel:

- 1) Touch **Tools** > .
- 2) Select **AVGAS, Jet A,** or **Custom.**
- 3) Enter the amount of Fuel on Board.
- 4) Enter the amount of Fuel Required.
- 5) Touch the **Calculate** button to display the Fuel Needed. Toggle the **Pounds / Gallons** buttons as necessary.
- 6) Enter amount of Fuel Needed in the appropriate category, (e.g. Pounds, Gallons, Kilograms, Litres). The other fuel categories will autofill with the proper conversion.
- 7) Touch the **Gallon, GAL** button (the button will display the most recent selection) to select the unit of measurement, (e.g. gal, lit, lb, kg, IG).
- 8) Enter the fuel price per unit sold (e.g. \$10.50). The Total price will be calculated and displayed (U.S. \$).
- 9) Touch the **'Back'** button to exit.

**Fuel Type: JET A1 6.7 lb/gal**

×

1520

Pounds (lb)

×

226.866

Gallons (gal)

×

689.46

Kilograms (kg)

×

858.78

Litres (L)

\$

10.50

per

GALLON, GAL

\$

2382.09

Total

3300

Fuel Required

1780

Fuel on Board

CALCULATE

1520.03 Fuel Needed (lb)

Pounds

Gallons

Conversion Table:

1 lb	=	0.453592 kg
1 kg	=	2.204623 lb
1 gal	=	3.785411 L
1 L	=	0.264172 gal

Enter Info

Touch to Delete

Touch To Select

Touch to Calculate Fuel Needed

Touch To Select

FltPlan GO - Tools - Calculators - Fuel Conversion


- FitPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

## EQUAL TIME POINT

Touch  to view the Equal Time Point conversion page, where the User can enter the Route to Destination, Ground Speed Forward and Ground Speed Back.

### Calculating Equal Time Point:

- 1) Touch **Tools** > .
- 2) Enter the Route to Destination  
Or Toggle the **Use Present Position to Destination** button 'On'.
- 3) Enter the Ground Speed Forward (knots).  
Or Toggle the **Use Actual Ground Speed** button 'On'.
- 4) Enter the Ground Speed Back (knots).  
Or Toggle the **Use Actual Ground Speed** button 'On'.
- 5) Touch the **Calculate** button. The Equal Time Point will be displayed in Nautical Miles.
- 6) Touch **Clear** to remove all data.
- 7) Touch the **'Back'** button to exit.



FltPlan GO - Tools - Calculators -Equal Time Point

## RUNWAY WINDS

Touch  to view the Runway Winds Calculator, where User can enter the Runway Number, Wind Direction, Wind Velocity, Wind Gusts, Ref Speed, and set wind limitation Preferences.

### Entering/Adjusting Wind Calculator Preferences:

- 1) Touch **Tools** >  > **Preferences**.
- 2) Touch the desired text box and enter wind velocity (knots) and Target Speed preferences/limitations.
- 3) Touch **Steady State Wind** or **Head Wind Comp** to enter calculation(s).
- 4) Touch '-' or '+' to adjust percentage calculation(s) for Steady State Wind or Head Wind Comp, as desired.
- 5) Touch anywhere outside the Preferences dialogue box to exit, or touch the **Close** button to exit.

FltPlan Go - Tools - Calculators - Runway Wind Calculator - Preferences Menu

### Entering/Adjusting Wind Information:

- 1) Touch **Tools** > .
- 2) Adjust the Slider to the desired **Runway Number**. Touch '-' or '+' to make small adjustments.
- 3) Adjust the Slider to the desired number for **Wind From** (Radial Measure in Degrees, e.g. 090 = From the East, 180 = From the South, etc.). Touch '-' or '+' to make small adjustments.
- 4) Adjust the Slider to the desired number for **Wind Speed** (Knots). Touch '-' or '+' to make small adjustments.
- 5) If necessary, adjust the Slider to the desired number for **Gusting to** (Knots). Touch '-' or '+' to make small adjustments.
- 6) If necessary, touch within the 'Ref Speed' box to enter the desired number (Knots). Touch '-' or '+' to make small adjustments. The **Target Speed** will autocalculate as data is entered/adjusted.
- 7) Touch the 'Back' button to exit and return to the previous page.

Annotations in the screenshot:

- Headwind Component: G35.7
- Crosswind Component: G13.0
- Current Runway: 17
- Wind From: 190
- Wind Speed (knots): 22
- Gusting to (knots): 38
- Ref Speed: \_\_\_\_\_
- Target Speed: \_\_\_\_\_

FltPlan Go - Tools - Calculator - Runway Wind Calculator

## AIRPORT WINDS

Touch  and enter the Airport ID (ICAO), e.g. KOJC. The User will now be directed to the Runway Wind Calculator, as previously mentioned, but this time the available runways for the selected airport will be listed.

### Entering/Adjusting Wind Information:

- 1) Touch **Tools** > .
- 2) Enter the Airport ID (ICAO) and select desired runway.
- 3) Adjust the Slider to the desired number for **Wind From** (Radial Measure in Degrees, e.g. 090 = From the East, 180 = From the South, etc.). Touch '-' or '+' to make small adjustments.
- 4) Adjust the Slider to the desired number for **Wind Speed** (Knots). Touch '-' or '+' to make small adjustments.
- 5) If necessary, adjust the Slider to the desired number for **Wind Gusts** (Knots). Touch '-' or '+' to make small adjustments.
- 6) If necessary, touch within the 'Ref Speed' box to enter the desired number (Knots). Touch '-' or '+' to make small adjustments. The **Target Speed** will autocalculate as data is entered/adjusted.
- 7) Touch the 'Back' button to exit and return to the previous page.

The screenshot displays the 'Airport Winds Calculator' for KTEB. Key elements include:

- Change airport:** A button to switch airports.
- Preferences:** A button to view or edit preferences.
- Wind Components:** A box showing 'HEAD WIND' as G25.1 and 'CROSSWIND' as G14.5.
- Runway Selection:** A list of runways (01, 19, 06, 24) with 'X' or '!' markers indicating status. Runway 19 is selected.
- Wind From:** A slider set to 160 degrees, with a scale from 010 to 360.
- Wind Speed (knots):** A slider set to 21, with a scale from 0 to 50.
- Gusting to (knots):** A slider set to 29, with a scale from 0 to 50. A note says 'Adjust wind speed to turn off gusting wind'.
- Relative Wind & Runway:** A circular diagram showing wind direction relative to the runway.
- Speed Settings:** 'Ref Speed' set to 106 and 'Target Speed' set to 134 kts.

FltPlan Go - Tools - Calculators - Airport Winds Calculator

## SCRATCH PAD




The Scratch Pad icon is eleventh on the Home Menu, with seven buttons located in the Header Menu: Clear, Undo, Background, My Doodles, Save, Precise, and Color.

## MY DOODLES

### Creating a Doodle:

- 1) Touch the **My Doodles** button (the most recent selection will be displayed as the title, e.g. KDAL.PDF).
  - 2) Touch **New Noodle**.
  - 3) Select the desired Doodle Type, **Draw, Text, or Approach Plate**.
- Or Touch **Cancel** to exit.
- 4) Enter the Title of the New Doodle, then touch **Add**.
  - 5) Adjust as desired, then touch **Save**.
  - 6) Touch the My Doodles button, then select the recently created Doodle to view/adjust.




FltPlan Go - Scratch Pad - Select Doodle Type

## ANNOTATING A DOODLE

Touch **Background** to search for the desired Airport, then select a chart to annotate. Touch **Color** to select the color of the penstroke, e.g. Black, Red, Blue, Green, Yellow, etc. Touch **Size** to select the size of the penstroke. Touch the **Undo** arrow to remove the most recent annotation. Touch the **Paintbrush** to annotate. Touch the **Pencil** to draw freehand. Touch the 'Square' icon to create a square shaped annotation. Touch the 'Circle' icon to create a circular annotation. Touch the 'Save' icon to save the most recent annotation(s). Touch **Done** to exit the annotate process.




FltPlan Go - Scratch Pad - Banner Menu



FltPlan Go - ScratchPad - Approach Plate - Annotate Icons

Touch to View My Doodles

Touch to Adjust



SC-2, 19 MAY 2022 to 16 JUN 2022

SC-2, 19 MAY 2022 to 16 JUN 2022

HIBIL THREE ARRIVA

FitPlan Go - Scratch Pad - Approach Plate - Annotate - STAR

- FitPlan
- Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

### Annotating a Doodle:


- 1) Touch the **My Doodles** button (the most recent selection will be displayed as the title, e.g. KDAL.PDF).
  - 2) Select the desired Doodle from the list.
- Or** Touch **Background** to select an new airport and chart.
- 3) Touch **Size** to adjust the penstroke size.
  - 4) Touch **Color** to adjust the penstroke color.
  - 5) Touch the 'Square' icon to create a square annotation.
  - 6) Touch the 'Circle' icon to create a circular annotation.
  - 7) Touch **Undo** to remove the most recent annotation.
  - 8) Touch **Save** to save annotations.

### Viewing My Doodles:

- 1) Touch the **My Doodles** button (the most recent selection will be displayed as the title, e.g. AFD).
- 2) Select the desired Doodle from the list.
- 3) Annotate as desired, then touch **Save**. The Doodle will now be saved to the My Doodles list.

### Deleting My Doodles:

- 1) From the My Doodles menu, touch  across from the Doodle Title.
- 2) Touch **Close** to exit.



FItPlan GO - Scratch Pad - My Doodles Menu

## DOWNLOADS




The Downloads icon is twelfth on the Home Menu, and allows the User to download and update various charts for offline use. Available charts include Maps, Procedures, Documents, and AF/D. The Banner Menu consists of six buttons, Failed Downloads, Update All, Cancel All, Delete, Save, and Refresh.



FitPlan Go - Downloads - Banner Menu

## FAILED DOWNLOADS


Touch the Failed Downloads button to view all unsuccessful downloads. Select the desired download to retry, or touch **Retry All Failed Downloads** (if applicable).



FitPlan GO - Downloads - Failed Downloads Menu

## UPDATE ALL

Touch the **Update All** button in the Banner Menu to download all available downloads for Maps, Procedures, Documents, AF/D, and Misc. The User will also have the option to select **Update Expired Maps**, **Update Expired Procedures**, **Download Future Procedures**, and **Update Expired AFDS**.



FitPlan GO - Downloads - Update All Menu


# CANCEL ALL

Touch the **Cancel All** button in the Banner Menu to stop all active or queued downloads.

# DELETE

## Deleting Files:

- 1) Touch  to display a window entitled 'Delete Files'.
- 2) Touch the desired section to delete files, e.g. Maps.



FltPlan GO - Downloads - Delete Menu

- 3) Touch  next to the desired file to Delete.
- Or Touch **Delete All Expired Files**.
- 4) Touch **Back** to return to the 'Delete Files' window.
- Or Touch **Close** to exit.



FltPlan GO - Downloads - Delete - Maps - Jet High


## MAPS

The Maps section within Downloads allows the User to view, download, and delete a variety of charts, such as:

- Jet High (USA, Canada, and Caribbean)
- Victor Low (USA, Canada, and Caribbean)
- IFR Area Charts (USA and Canada)
- Sectionals (USA and Canada)
- Terminal Aera Charts (USA and Canada)
- Helicopter Charts (KDCA, KBOS, KORD, KDAL, KDET, Gulf, KHOU, KLAX, and New York)
- Reference Maps (North America and World)
- Layers (Airports, State Borders, Civil Air Patrol Grid, and Runway Centerlines)

### Downloading Maps:

- 1) From the Downloads Page, touch **Maps > Select**.
  - Or From the Downloads Page, touch **Maps > Update All**.
  - 2) Touch the desired chart on the map to display the Select Map menu.
  - 3) Select the desired chart from the Select Map menu to start the download.
- Or Touch **Download All** to download all available charts for the current selection, e.g. Victor Low - USA. The chart queue will scroll across the top of the Downloads screen as the selected items are downloaded.



- FitPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

FltPlan Go - Downloads - Maps - All CAR

FltPlan Go - Downloads - Maps - Select CAR

## CHART STATUS

Within Maps section of the Downloads Page, the Chart Status is located next to the Select button. When there is an update available, touch the dark blue Update button to start downloading the appropriate data. When the data has downloaded successfully, the button will display Current and change to the color green. When there are expired charts, the Update button will be red.



**NOTE:** The Chart Status only represents maps that are downloaded.

The screenshot shows the 'Downloads' screen in FltPlan GO, specifically the 'Maps - Updates Needed' section. At the top, there are buttons for 'FAILED DOWNLOADS', 'UPDATE ALL', and 'CANCEL ALL'. A progress bar shows 'Cape Lisburne 2203' is downloading at 6.7 MB/s with 10 seconds left. Below this is a category selection bar with 'Maps' selected. The main content area lists various chart categories: Jet High, Victor Low, IFR Area Charts, Sectional, TAC Charts, Helicopter Charts, Reference Maps, and Layers. Each category has a list of items with status indicators (Current, Expired, Future, Queued, Not Downloaded). A legend at the bottom explains the status indicators.

**Annotations:**

- Touch to View Chart Name, File Size, & Download Progress:** Points to the 'Cape Lisburne 2203' entry.
- Touch to Update All:** Points to the 'UPDATE ALL' button.
- Touch to Cancel All:** Points to the 'CANCEL ALL' button.
- Touch to Delete:** Points to the trash icon.
- Touch to Save:** Points to the save icon.
- Touch to Refresh:** Points to the refresh icon.
- Touch to Cancel:** Points to the 'X' icon.
- Touch to View:** Points to the 'Maps' button in the category selection bar.
- Current & Successfully Downloaded:** Points to the 'Current' status buttons for USA, CAN, and CAR in the Jet High category.
- Nothing Downloaded:** Points to the 'Select' buttons for USA, CAN, and CAR in the Victor Low category.
- Expired Chart(s):** Points to the 'Update' button for USA in the Sectional category.
- Helicopter Charts Queued:** Points to the yellow 'Queued' buttons for DCA, BOS, ORD, DAL, DET, Gulf, HOU, LAX, and NYC.

**Legend:**

- Current: Green button
- Expired: Red button
- Future: Blue button
- Current/Future: Green and blue button
- Current/Expired: Green and red button
- Important: Orange button
- Queued: Yellow button
- Not Downloaded: Grey button

FltPlan GO - Downloads - Maps - Updates Needed

- Account
- FitPlan
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

**Downloading Helicopter Charts:**

- 1) From the Downloads Page, touch **Maps**. Scroll down to the Helicopter Charts section.
- 2) Touch the desired chart ID (Three Letter Airport ID's are listed except for the Gult Coast and the New York City area) to begin downloading. Once complete, the chart ID will be green.

**Downloading Reference Maps:**

- 1) From the Downloads Page, touch **Maps**. Scroll down to the Reference Maps section.
- 2) Touch the desired map, **North America (NA)** or **World Map (WM)** to begin downloading.


**Downloading Layers:**

- 1) From the Downloads Page, touch **Maps**. Scroll down to the Layers section.
- 2) Touch the desired layer, **Airports Layer (ARP)**, **State Borders (STB)**, **CAP Grid**, or **Runway Centerlines (CEN)** to begin downloading.

**PROCEDURES**

The Procedures section within Downloads allows the user to view the download/currency status for the U.S. (Current and Future), Canada, and the Caribbean (Current and Future). Touch the desired icon to download the applicable chart(s).

Touch the **Update All** button in the Banner Menu to download all available downloads for Maps, Procedures, Documents, AF/D, and Misc. The User will also have the option to select **Update Expired Maps**, **Update Expired Procedures**, **Download Future Procedures**, and **Update Expired AFDS**.



FitPlan GO - Downloads - Update All Menu

Legend			
Current	Expired	Future	Current/Future
Current/Expired	Important	Queued	Not Downloaded

FitPlan GO - Downloads - Legend

Touch to View **FAILED DOWNLOADS** **UPDATE ALL** **CANCEL ALL** Touch to Update All Touch to Cancel All Touch to Delete Touch to Save Touch to Refresh

Chart Name, File Size, & Download Progress **Procedure: New York** 94.0 MB 5 Secs Left Touch to Cancel

Current Selection **Downloading** 8.2 MB/s Touch to View

Maps **Procedures** Documents A/FD Misc

**US**

NE CT MA ME NH RI VT

EA DE MD NJ NY PA VA WV

SO AL FL GA KY MS NC PR SC TN

VI

GL IL IN MI MN ND OH SD WI

CE IA KS MO NE

NW AK CO ID MT OR UT WA WY

WP AZ CA HI NV

SW AR LA NM OK TX

**Canada**

CN AB BC MB NB NL NT NS NU ON

PE QC SK YT

**Caribbean**

CR DR


FltPlan GO - Downloads - Procedures

- FitPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads**
- Settings
- Index


## DOCUMENTS

The Documents section within Downloads allows the user to view the download/currency status of various aviation documents. Imported documents will appear at the top of the list. Touch the desired document title to download. Touch and hold the document title to Delete.

Touch the **Update All** button in the Banner Menu to download all available downloads for Maps, Procedures, Documents, AF/D, and Misc. The User will also have the option to select **Update Expired Maps**, **Update Expired Procedures**, **Download Future Procedures**, and **Update Expired AFDS**.



FitPlan GO - Downloads - Update All Menu




FitPlan GO - Downloads - Documents


### A/FD

The A/FD section within Downloads allows the user to view the download/currency status of various AF/D's throughout the U.S. as well as the Canadian Flight Supplement.

Touch the **Update All** button in the Banner Menu to download all available downloads for Maps, Procedures, Documents, AF/D, and Misc. The User will also have the option to select **Update Expired Maps**, **Update Expired Procedures**, **Download Future Procedures**, and **Update Expired AFDS**.




FltPlan GO - Downloads - Update All Menu



FltPlan GO - Downloads - A/FD

## MISCELLANEOUS

The Misc. section within Downloads allows the user to view the download/currency status of the Airports Database, FBO Icons, and Airport Diagrams. Touch the desired button to start downloading the relevant data.



FltPlan GO - Downloads - Miscellaneous

- FltPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings
- Index

### SETTINGS



The thirteenth and final icon in the Main Menu is Settings. Here, the User can adjust how the device interacts with the FltPlan Go program, such as:

- Toggle Sleep Mode
- Enable Night Mode
- Toggle Background GPS
- Minimum Runway Length
- Email Support
- Messages From FltPlan
- Privacy Policy
- Help Guide & Tutorial
- Open Source Licenses
- App Build Version



**NOTE:** If the device is set to 'Auto Brightness', the User will not be able to Enable Night Mode. Please adjust the device settings accordingly to allow the FltPlan Go program to 'Enable Night Mode'.

### TOGGLE SLEEP MODE

When toggled On, the device will go into sleep mode. When toggled Off, the device will not go into sleep mode while FltPlan Go is open

### ENABLE NIGHT MODE

When toggled On, the screen brightness will automatically dim to a low setting favorable for night flight and/or battery conservation.

### TOGGLE BACKGROUND GPS

When toggled On, FltPlan Go will continue to use GPS while the app is closed. Enabling this feature is important when using the Breadcrumbs feature

### MINIMUM RUNWAY LENGTH (FT)

Touch to view a pop-up window listing runways distances in feet from 1,000 to 10,000. Select the desired minimum runway length. Once a selection has been made, FltPlan Go will only display airports with the set runway length in the Airports Page

### RECEIVE NOTIFICATIONS

When toggled On, flight plan and NavLog updates will be displayed within FltPlan Go. When toggled Off, the updates will still be received, but void of a notification.

### EMAIL SUPPORT

Touch **Email Support** to draft an email to Garmin Support via tech@fltplan.com. The device information, software version, FltPlan Build Number, and Short Build Number will autopopulate in the signature block for reference/troubleshooting/diagnostics.

### MESSAGES FROM FLTPLAN.COM

Touch to view a pop-up window listing any notes from FltPlan.com, e.g. Compatibility testing status for Android updates.

- FitPlan Account
- Airports
- Maps
- NavLogs
- External
- Checklists
- Binders
- Weather
- Flight Tracking
- Tools
- Scratch Pad
- Downloads
- Settings**
- Index

## PRIVACY POLICY

Touch to view Garmin's Privacy Policy via web browser.

## HELP GUIDE & TUTORIAL

Touch **Help Guide & Tutorial** at the top of the Settings Menu to view the FltPlan Go manual in a browser window.

## OPEN SOURCE LICENSES

Touch to view textural information regarding open source licenses.

## APP VERSION

This tab informs the user which version of the app is currently installed, in addition to the build number. This information may be helpful in troubleshooting issues.

The screenshot shows the 'Settings' screen of the FltPlan Go app. The settings are organized into several sections:

- DEVICE**
  - Toggle Sleep Mode: If enabled, the screen will turn off while the app is active. (checked)
  - Enable Night Mode: This mode dims your device so it's easier to use in a dark cockpit. (checked)
- GPS SETTINGS**
  - Toggle Background GPS: Uses GPS while app is in the background. (checked) — *Touch to Toggle 'On/Off'*
- AIRPORTS**
  - Minimum runway (No filter): Change the minimum runway length to find airports easier. — *Touch to View/Adjust*
- NOTIFICATIONS**
  - Receive notifications: Receive notifications from FltPlan.com when you have account data available. (checked)
- ABOUT & HELP**
  - Email Support: Email Support@Fltplan.com for support. — *Touch to Compose Email*
  - Messages from FltPlan: Up to date information about this app
  - Privacy Policy: View Privacy Policy — *Touch to View*
  - Help Guide & Tutorial: View the FltPlan Go Android User's Manual
  - Open source licenses: License details for open source software
  - App build version: Version 5.0.13 build 3744

At the bottom right of the settings list, there is a green **CLOSE** button — *Touch to Exit*.

FltPlan Go - Settings

FitPlan  
Account

Airports

Maps

NavLogs

External

Checklists

Binders

Weather

Flight  
Tracking

Tools

Scratch  
Pad

Downloads

Settings

Index

Blank Page

# INDEX

## A

ADS-B 25, 26  
 Aircraft 28  
 Airport Diagram 16, 17, 22  
 Airport of Entry 20  
 Annotate 17  
 Approach 27  
 AWOS 85

## B

Breadcrumbs 34

## C

Calculator 11, 131, 132, 137, 139  
 Canada 9  
 CTAF 85  
 Customs 27, 49

## D

Device 4  
 Documents 4

## E

EMAS 27

## F

FAA 27  
 FBO 4, 19  
 FDC 26  
 Fuel 20, 84, 85

## G

GPS 32

## H

Headwind 11  
 Helicopter 32  
 Howgozit 35

## I

ICAO 82, 84, 85  
 Information 4, 10, 14, 19, 20, 22, 24, 25, 26, 27, 28, 29, 38, 83, 85

## J

Jet 20, 32, 99

## K

KML 34

## M

MOS 25

## N

NOTAMs 7, 26

## P

Print 100  
 Procedure 57

## R

Runway Wind Calculator 11, 139

## S

ScratchPad 35  
 SIDs 22  
 Split Screen 35, 57  
 STARs 22

## T

Tailwind 11  
 TFRs 42  
 Tool 40

## V

Visibility 25

## W

Waypoint 63  
 Weight & Balance 4, 38

## X

X-Wind 11

Blank Page

FitPlan  
Account

Airports

Maps

NavLogs

External

Checklists

Binders

Weather

Flight  
Tracking

Tools

Scratch  
Pad

Downloads

Settings

Index



Garmin International, Inc.  
1200 East 151st Street  
Olathe, Kansas 66062, U.S.A.

Garmin AT, Inc.  
2345 Turner Road SE  
Salem, OR 97302, U.S.A.

Garmin (Europe) Ltd.  
Liberty House, Hounslow Business Park  
Southampton, Hampshire SO40 9LR U.K.

Garmin Corporation  
No. 68, Zhangshu 2nd Road  
Xizhi District, New Taipei City, Taiwan

Contact Garmin Product Support at  
[www.flygarmin.com](http://www.flygarmin.com)